Accurate GPS Time-Linked Data Acquisition System (ATLAS II) User's Manual

Jose Zayas & Perry Jones Wind Energy Technology Department Sandia National Laboratories Albuquerque, NM 87185-0708

> Juan Ortiz-Moyet PrimeCore Systems, Inc. Albuquerque, NM 87111

Prepared by Sandia National Laboratories Albuquerque, New Mexico 87185 and Livermore, California 94550

Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company, for the United States Department of Energy's National Nuclear Security Administration under contract DE-AC04-94AL85000.

Approved for public release; further dissemination unlimited.



SAND2004-0481 Unlimited Release Printed February 2004

ISSUED BY SANDIA NATIONAL LABORATORIES, OPERATED FOR THE UNITED STATES

Department of Energy by Sandia Corporation.

NOTICE: This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government, nor any agency thereof, nor any of their employees, nor any of their contractors, subcontractors, or their employees, make any warranty, express or implied, or assume any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represent that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government, any agency thereof, or any of their contractors or subcontractors. The views and opinions expressed herein do not necessarily state or reflect those of the United States Government, any agency thereof, or any of their contractors.

Printed in the United States of America. This report has been reproduced directly from the best available copy.

Available to DOE and DOE contractors from U.S. Department of Energy Office of Scientific and Technical Information P.O. Box 62 Oak Ridge, TN 37831

Telephone:(865)576-8401Facsimile:(865)576-5728E-Mail:reports@adonis.osti.govOnline ordering:http://www.DOE.gov/bridge

Available to the public from U.S. Department of Commerce National Technical Information Service 5285 Port Royal Rd Springfield, VA 22161

Telephone:(800)553-6847Facsimile:(703)605-6900E-Mail:orders@ntis.fedworld.govOnline ordering:http://www.ntis.gov/ordering.htm



SAND2004-0481 Unlimited Release SAND2004-0481 Unlimited Release Printed February 2004

Accurate GPS Time-Linked Data Acquisition System (ATLAS II) User's Manual

Jose Zayas and Perry Jones Wind Energy Technology Sandia National Laboratories P.O. Box 5800 Albuquerque, NM 87185-0708

Juan Ortiz-Moyet PrimeCore Systems Inc. 8421 Osuna Rd NE. Suite C-1 Albuquerque, NM 87111

Abstract

The Accurate Time-Linked data Acquisition System (ATLAS II) is a small, lightweight, time-synchronized, robust data acquisition system that is capable of acquiring simultaneous long-term time-series data from both a wind turbine rotor and ground-based instrumentation. This document is a user's manual for the ATLAS II hardware and software. It describes the hardware and software components of ATLAS II, and explains how to install and execute the software.

Frontispiece



Micon 65 Turbines in Bushland, Texas, Equipped with the Accurate GPS Time-Linked data Acquisition System (ATLAS II)

Acronyms

1PPS	One Pulse-per-Second
ADAS	Advanced Data Acquisition System
AGND	Analog Ground
ATLAS II	Accurate GPS Time-Linked data Acquisition System
DAM	Data Acquisition Module
DAQ	Data Acquisition
DAS	Data Acquisition Subsystem
DCLK	Digital Clock
DCS	Data Communication Subsystem
DGND	Digital Ground
DMM	Digital Multimeter
ESD	Electrostatic Discharge
EU	Engineering Units
GBCU	Ground-Based Computer Unit
GBU	Ground-Based Unit
GND	Ground
GPS	Global Positioning Satellite
NREL	National Renewable Energy Laboratory
ODBC	Open Database Connectivity
PATSyM	Programmable Accurate Time Synchronization Module
PCM	Pulse Code Modulated
PLD	Programmable Logic Device
PPS	Pulse-per-Second
PROM	Programmable Read-Only Memory
RAM	Random Access Memory
RBU	Rotor-Based Unit
RX_CLK	Receive Clock
RX_DATA	Receive Data
SDAS	Smart Data Acquisition System
SNL	Sandia National Laboratories
TSLD	Time Since Last Dropout
TSS	Timing Synchronization Subsystem
TTL	Transistor/Transistor Logic
UPS	Uninterruptible Power Supply
UTC	Universal Time Clock

This page intentionally left blank.

Foreword

This user's manual provides sufficient information for scientists, engineers, and technicians to install, operate, and maintain an Accurate GPS Time-Linked data Acquisition System (ATLAS II).

Various NOTES, CAUTIONS, and WARNINGS are used throughout this manual to emphasize important and critical instructions and should be heeded under the following conditions:



Operating procedures, conditions, etc., that are essential to highlight.

CAUTION

Operating procedures, practices, etc., which, if not strictly observed, will result in damage to, or destruction of, equipment.



Operating procedures, practices, etc., which, if not strictly observed, will result in personal injury or loss of life.

This page intentionally left blank.

CHAPTER 1. GETTING STARTED	11
1.1 Overview of the ATLAS II Hardware	11
1.2 Overview of the ATLAS II Software	14
1.2.1 Installing and Configuring the ATLAS II Software	14
1.2.2 Set Up the System Computer	
1.2.3 Install the ATLAS II Software	16
CHAPTER 2. ATLAS II HARDWARE DESCRIPTION	21
2.1 Data Acquisition Subsystem	21
2.1.1 DAS Chassis	
2.1.2 Encoder Module	
2.1.3 Instrumentation Modules	
2.1.4 Merger/Decoder Module	
2.2 Data Communication Subsystem	
2.3 Programmable Accurate Time Synchronization Module	
2.4 Lightning Protection Equipment	
2.5 Power Supplies	
2.6 Connectors	
2.7 ATLAS II Application-Specific Configuration	
2.7.1 Application Planning	
2.7.2 General Fabrication Notes	
2.7.3 Ground-Based Unit Assembly	
2.7.4 Rotor-Based Unit Assembly	
CHAPTER 3. ATLAS II SOFTWARE DESCRIPTION	
3.1 Capabilities of the ATLAS II software	
3.2 Introduction to the ATLAS II software	
3.3 Configuring the ATLAS II software	
3.3.1 Creating a hardware setup	
3.3.2 Configuring ATLAS II DAMs	
3.3.2.1 KAM/ENC/003 - Encoder module parameters	
3.3.2.2 KAM/ENC/007 - RS-232 Encoder module parameters	
3.3.2.3 KAM/DEC/002 - Merger/Decoder module parameters	
3.3.2.4 KAM/ADC/005 - Analog input module parameters 3.3.2.5 KAM/ADC/009/S2 - Bridge analog input module parameters	
3.3.2.6 KAM/DSI/002 - Discrete input module parameters	
3.3.2.7 GPS/001 - GPS receiver/timing reference module parameters	
3.3.3 Configuring Frame Parameters	
3.4 Programming the ATLAS II hardware	
3.4.1 Programming a Chassis	
3.4.2 Programming the active DAM	
3.5 Other Software Configuration functions	
3.5.1 Managing Setup files	
3.5.1.1 Creating a new setup	
3.5.1.2 Opening an existing setup	87
3.5.1.3 Saving a setup	
3.5.1.4 Using an existing setup as a template	
3.5.2 Managing a Chassis	
3.5.2.1 Modifying a Chassis' properties	

3.5.2.2 Adding a Chassis to a setup	
3.5.2.3 Removing a Chassis from a setup	
3.5.3 Finding a signal's definition	92
3.6 Acquiring Data	94
3.6.1 Starting a DAQ session	94
3.6.2 Stopping a DAQ session	
3.6.3 Reading the DAQ Satus information	
3.7 Displaying Data	
3.7.1 Displaying Graphical Data	
3.7.1.1 Display/Monitor a signal3.7.1.2 Creating a Display setup.	
3.7.1.3 Loading a Display setup	
3.7.1.4 Displaying Processed (EU) data	
3.7.1.5 Customizing the Graphing window	
3.7.1.6 Optimizing the Display's performance	
3.7.2 Displaying Digital Data	
3.8 Controlling the System Update Rate	
3.9 Processing Data	
3.9.1 Configuring Data Processing	
3.9.1.1 Creating a processing setup	
3.9.1.2 Opening an existing processing setup	
3.9.1.3 Saving a processing setup	
3.9.1.4 Using an existing processing setup as a template	
3.9.2 Enabling/Disabling Data Processing	
3.10 Reviewing the Active System Configuration	
3.11 Recording (Archiving) Data	
3.11.1 Starting a Data Recording session	
3.11.2 Stopping a Data Recording session	
3.11.3 Reading the Data Recording Status information	127
3.12 Using System Events (Automating ATLAS II)	129
3.12.1 Introduction to System Events	129
3.12.2 Creating a new events setup	
3.12.2.1 Defining a system event	
3.12.2.2 Defining a response to an event	
3.12.3 Editing an event setup	
3.12.3.1 Editing a system event	
3.12.3.2 Editing a response to an event	
3.12.4 Managing System Events Setup files	
3.12.4.1 Opening an existing system events setup	
3.12.4.2 Saving a system events setup	
3.12.4.3 Using an existing system events setup as a template	
3.13 Other Software Utilities	
3.13.1 PATSyM Diagnostics Utility	
CHAPTER 4. REFERENCES	
CHAPTER 5. TECHNICAL SUPPORT	
	155

Chapter 1. Getting Started

The <u>A</u>ccurate <u>T</u>ime-<u>L</u>inked data <u>A</u>cquisition <u>System</u> (ATLAS II) is a small, lightweight, time-synchronized, robust data acquisition system that is capable of acquiring simultaneous long-term time-series data from both a wind turbine rotor and ground-based instrumentation. These data are post-processed to provide a complete set of data on wind turbine performance under specific wind speeds, turbulence levels, and temperatures. ATLAS II consists of various hardware components, a personal computer and application software that together interface with the user, control the hardware, and store and process the data.




Figure 1-1. Schematic of a typical ATLAS II system.

1.1 Overview of the ATLAS II Hardware

A data acquisition subsystem (DAS) chassis is the hardware unit that actually acquires the data utilizing a number of plug-in data acquisition modules (DAMs) to interface with the sensors. One of those DAMs, the programmable accurate-time synchronization module (PATSyM) utilizes the Global Positioning System (GPS) to ensure data is acquired at precisely the same time by each DAM in a

chassis. Moreover, an optional data communications subsystem (DCS) can be used to provide communications between multiple chassis and between a chassis and the system computer. The combination of a chassis (populated with appropriate DAMs and a PATSyM), a DCS, and a power supply unit constitute a Data Acquisition Subsystem (DAS). A DAS is the basic data acquisition unit in an ATLAS II system.

The main strengths of the ATLAS II system are its modularity and flexibility. This is evident in practice where these components are usually packaged into three different types of DAS units: a rotor-based unit (RBU) and two different ground-based units (GBU). The user assembles a complete test system by connecting any number of DAS units in a master/slave(s) configuration. For the ATLAS II system, the master is defined as the DAS unit that merges the incoming streams from other units and sends the combined data stream to the computer. This way, the user can develop an initial system and easily add more (or remove) DAS units to the system later on as the test requirements change.

A typical test system consists of one RBU, three GBUs, and a system computer (see Figure 1-1). One of the GBUs is designated the master DAS, while all the other DAS units (GBUs and the RBU) are slaves and operate under the control of the master unit. The master unit accepts data streams from the RBU and the slave GBUs, merges these data streams with the data it acquires, and sends the resultant data stream to the system computer. Data transfers between the slaves and the master and between the master and the system computer are normally accomplished with the use of DCS components.

DCS components work in pairs. If the master unit uses a DCS to transfer data to the system computer, the system computer must contain a DCS to receive that data from the master. If the RBU uses a DCS, the system computer must contain an additional RS-232 radio-modem (not a complete DCS) to communicate with the RBU.

Next, we describe each of the components of an ATLAS II test system in detail:

A rotor-based unit (RBU) typically consists of:

- One Chassis.
- One DCS (optional).
 - Typically consisting of two wireless modems, one for hardware programming and the other for transmitting data to either a master unit or to the system computer.
- One PATSyM.
 - Including one GPS antenna and receiver.
- One or more DAMs.
- One power supply.

- One power conditioning unit.
 Typically consisting of an 8V voltage regulator, a 5V voltage regulator, and a terminal strip.
- Lightning protection equipment (optional).

Additional information on RBU components and assembly may be found in Section 2.7.4.

A ground-based unit (GBU) typically consists of:

- One Chassis.
- One DCS (optional).
 - Typically consisting of one fiber-optics modem for communications to the master unit or to the system computer.
- One PATSyM.
 - Including one GPS antenna and receiver.
- One or more DAMs.
- One power supply unit.
 - This is a separate box including a 24V DC UPS and its battery pack.
- One power conditioning unit.
 - Typically consisting of a 24V to 8V DC-DC converter, a 5V voltage regulator, and a terminal strip.
- Lightning protection equipment (optional).

Additional information on GBU components and assembly may be found in Section 2.7.3 of this manual.

The system computer consists of:

- One IBM PC-compatible computer
 - Refer to Table 1-2 in Section 1.2.2 for the minimum hardware requirements.
- One DCS (optional)
 - Typically consisting of two modems, one for bi-directional RS-232 communications and the other for receiving data from the master unit.
- One or two PCMCIA decoder cards (Pocket Decoder).
- ATLAS II software.

More detailed descriptions of the ATLAS II hardware components are provided in Chapter 2.

1.2 Overview of the ATLAS II Software

The ATLAS II software is a user-friendly software package that gives the user complete control over the ATLAS II hardware. The main functionality of the ATLAS II Software includes the following features:

- 1. Data acquisition from a virtually unlimited number of high-level analog, discrete (digital) input, and strain-gauge channels,
- 2. Simultaneous data acquisition from all channels,
- 3. Long-term, continuous data acquisition at throughput rates that are only limited by the available processing power of the system computer,
- 4. Single-event or continuous recording of all acquired data channels,
- 5. Hardware programming and control via personal computer,
- 6. Programmable filtering and gain on each analog and strain-gauge channel,
- 7. Bridge completion circuitry and programmable bridge excitation levels for all strain-gauge channels.

More detailed descriptions of the ATLAS II software components are provided in Chapter 3.

1.2.1 Installing and Configuring the ATLAS II Software

The ATLAS II software installation and configuration procedure consists of the following operations:

- 1. Installing the ATLAS II software.
- 2. Executing and configuring the ATLAS II software for the first time.
- 3. Checking the communication between the computer and each DAS.

The ATLAS II components that are required for a typical installation are listed in

Table 1-1.

Item	Component	Quantity
1	DAS	Two or more
2	GPS antenna/receiver	Two or more
3	DAM	Two or more
4	PATSyM	Two or more
5	DCS	Two, if using telemetry data and communications links for the RBU. Additional pairs if using telemetry links for some or all GBUs.
		Zero, if using hardwire connections between the RBU and the master GBU, between the slave GBUs and the master GBU, and between the master GBU and the SYSTEM COMPUTER.
6	PCMCIA Decoder Card	One or two (to be installed in PCMCIA adapters – most laptop computers have this, but it may be necessary to add one if using a desktop computer).
7	Miscellaneous cables	Number, length, and connectors vary.
8	ATLAS II Software Disk	One CD

Table 1-1. ATLAS II Hardware Components

1.2.2 Set Up the System Computer

The system computer is the nucleus of the ATLAS II test system. It is the platform on which the interface software runs and on which the data is stored and processed.

ATLAS II utilizes an application-specific type II PCMCIA card to decode the PCM data stream. Most laptop computers come with a PCMCIA adapter installed. If a desktop PC (typically built without a PCMCIA adapter) will be used for ATLAS II, purchase and install the PCMCIA adapter in the computer before installing the ATLAS II software (adapters from Antec seem to work well and are readily available). Insert the ACRA PCMCIA decoder card (the Pocket Decoder) in the adapter and be sure that it is properly seated.

The complete computer requirements necessary to run the ATLAS II software package are given in Table 1-2.

Parameter	Particulars
Processor	Pentium 400 MHz (minimum)
Operating System	Windows [®] 2000 or later
Random access memory (RAM)	128 megabytes (minimum)
Mass storage	32 MB for software, plus more for data storage.*
Monitor resolution	1024 × 768 (required)
PCMCIA Adapter	PCMCIA Type II (minimum)

 Table 1-2. Minimum Computer Requirements to Run ATLAS II software.

* For example: 47 channels, 10 minutes, at 30 Hz = approximately 10 megabytes.

1.2.3 Install the ATLAS II Software

To install the ATLAS II software, insert the supplied ATLAS II CD into the CD drive on the system computer. The installation should start automatically. If it doesn't, click the "Start" button on the desktop. Select "Run" and use "Browse" to locate and select "ATLAS II.bat" on the CD. Click on "OK" and follow the instructions on the screen as they appear. Figures 1-2 through 1-5 show the initial installation screens.




Figure 1-2. Wait for the installer to set itself up.




Figure 1-3. Read the Warning and Click on "Next" to Continue with the Setup.

🖶 ATLAS - InstallShield Wizard	×
Customer Information	
Please enter your information.	
User Name:	
JOM	
Organization:	
Sandia National Laboratories	
Install this application for:	
Anyone who uses this computer (all users)	
Only for me (JOM)	
InstallShield	
< <u>B</u> ack <u>N</u> ext >	Cancel

Figure 1-4. Enter user information and the installation rights.

	to install to this folder		Contraction of the local division of the loc
Tidito salo	none of the names in	install to a different f aces.	iolder.
	Install ATLAS to: C:\atlas\		Change
stallShield —			

Figure 1-5. If the Default Destination is Appropriate, Click "Next." If not, click on "Change". Notice the file path warning."

If the user wishes to install the program in another directory, choose **Change** and select the disk location where ATLAS II should be installed. See Figure 1-6 for an example of the directory list. Notice that there's a warning when choosing a destination folder for the installation: "Make sure none of the names in the path include spaces". Some of ATLAS II' low-level routines may fail if there are spaces in the file path. It is for this reason that installation in the "Program Files" folder is not recommended.

Figure 1-7 through Figure 1-9 detail the rest of the installation process. The ATLAS II installation actually consists of two parts: installing the ATLAS II application files and installing the LabVIEW Run-Time engine. The installation of the LabVIEW Run-Time engine is silent (there are no windows to interface with) and actually happens before the installation of the ATLAS II application itself.

After all of the files have been copied to the computer, ATLAS II is ready to run for the first time. As part of the installation, ATLAS II will create a shortcut to the application that will appear in the **Start>>Programs** menu.

TLAS - InstallShield Wizard	
nange Current Destination Folder	
Browse to the destination folder.	
Look in:	
🚔 atlas	- E 🖻
Eolder name:	
C:\atlas\	
llShield	

Figure 1-6. ATLAS II will ask the user to choose a folder. After a folder is chosen, click "OK" and then "Next."

y to Install the Program wizard is ready to begin installation. ou want to review or change any of your installa the wizard. ent Settings: up Type: stination Folder: C:\atlas\	ation set	ttings, clic	:k Back.	Click Cane	cel to
the wizard. ent Settings: up Type: stination Folder:	ation sel	ttings, clic	:k Back.	Click Cano	cel to
stination Folder:					
C:\atlas\					
r Information:					
Name: JOM					
Company: Sandia National Laboratories					
eld					
< <u>B</u> ack			all	Ca	ancel

Figure 1-7. ATLAS II Displays the Information Entered. Click "Install".




Figure 1-8. Actual installation of the files will take several seconds.




Figure 1-9. Window showing successful installation of ATLAS II.

Chapter 2. ATLAS II Hardware Description

ATLAS II utilizes several hardware subsystems to obtain continuous, time-synchronized data from a wind turbine rotor, tower, nacelle, and associated meteorological instrumentation over extended periods of time. These subsystems are assembled in application-specific configurations for each turbine application. The various pieces of hardware and the process of assembling the ATLAS II are described in the following sections.

2.1 Data Acquisition Subsystem

ATLAS II uses a commercially available DAS known as the ACRA Control KAM-500. This hardware, shown in Figure 2-1, was sold in the U.S. as the Nicolet MicroPro for several years, but it is now sold around the world exclusively by ACRA Control Inc¹ as the KAM-500.



Figure 2-1. ACRA KAM-500 DAS

The KAM-500 is a small, rugged, modular, lightweight DAS with a relatively low power consumption that is designed for remote operation in harsh environments. Its operational temperature range is from -40° C to $+85^{\circ}$ C (-40° F to $+185^{\circ}$ F), and it can withstand 100-g shock loads. The basic unit of the DAS is referred to as a chassis. Each chassis includes one or more power supplies and a data encoder module. The encoder module controls the chassis and outputs the acquired data in a pulse-code modulated (PCM) digital data stream. The unit operates on 24 VDC input power (voltage must be between 18 and 40 VDC), and power consumption can range from 5 W to approximately 35 W depending on the numbers and types of data channels being acquired. The KAM-500 chassis are available in four different configurations with 3, 6, 9, or 13 user slots.

Each user slot of the KAM-500 chassis accepts a single data acquisition module (DAM). Each DAM plugs into a connector on the back plane of the chassis (see Figure 2-2 for examples of DAMS). The DAM obtains power and control information from the chassis

¹ ACRA Control, Inc., Landscape House, Landscape Road, Dublin, Ireland.

and at the same time, furnishes the chassis with digitized sensor information obtained by the DAM. Data is acquired simultaneously from all channels on all DAMs, and a usersupplied synchronization pulse can specify the precise acquisition time. Standard instrumentation modules for the KAM-500 include digital, high-level analog, strain gauge, accelerometer, thermocouple, and serial data input. The characteristics of the digital, analog, and strain gauge input modules are summarized in Tables 2-1, 2-2, and 2-3, respectively. Additional information on these and other modules may be found in the KAM-500 technical manuals from ACRA Control.

ATLAS II typically utilizes two or more chassis in a master/slave arrangement – one chassis is identified as the master and all other chassis are slaves to that master. In a typical master/slave arrangement, the master clock drives the data acquisition of each of the slaves so data is acquired at precisely the same time on all units. Each slave transfers its data to the master, and the master merges those data streams with its own data into a single data stream for transmission to the system computer. The merger/decoder module described in Table 2-4 is utilized to merge the data from each slave into the master data stream. Each merger/decoder DAM can merge data from up to two slave units. For the ATLAS II, the master/slave arrangement can be configured in two ways. This can be accomplished by sharing the master clock for all units, if that is not possible the PATSyM module can be used to generate the clock and synchronization for all units. In either case both the master and the slave data acquisitions take place at exactly the same time

As mentioned earlier, the digitized data for each chassis (whether master or slave) is output as a PCM digital serial stream consisting of a continuous series of data frames. Each frame begins with a data synchronization word to ensure data integrity, followed by one data word for each data channel. Data words are typically either 12 bits or 16 bits in length, and the data synchronization word is usually twice the data word length. The PCM data stream can be transmitted in RS-422 or TTL format by hardwire, fiber-optic cable, or telemetry, in any of several PCM formats. The PCM data from a slave is normally transmitted to the master chassis' merger/decoder module, while PCM data from the master is normally transmitted to the PCM decoder card installed in the system computer.



Figure 2-2. Example DAMs.

Parameter	Particulars
Number of digital inputs per module	24 bits (2 12-bit words)
Input voltage range	0 - 20 Vdc; < 0.8 Vdc sensed as low (0), >2 Vdc sensed as high (1)
Number of counters/timers per module	8
Event counting range	0-65535
Period counter resolution	125 ns – 8 μs
Period measurement range	125 ns – 32.76 ms
Frequency counter resolution	1 Hz – 100 Hz
Frequency measurement range	1 Hz – 409.5 kHz
Current consumption (5 VDC)	304 mA

Table 2-1	Digital Signal-Co	onditioning Modul	e Characteristics
-----------	-------------------	-------------------	-------------------

Table 2-2. High-Level Analog Serial-Conditioning Module Characteristics

Parameter	Features
Number of channels	8 differential input
A/D converter	(Better than) 12-bit A/D per channel
Maximum sample rate	100,000 samples/sec per channel 500,000 samples/sec aggregate
Input ranges	±10 mV, ±100 mV, ±1.0 V, ±10.0 V
Gain	1, 10, 100, 1000
Filter	Programmable cut-off frequency; 31-tap FIR digital filter per channel
Offset range	±75% of input range
Input Impedance (ON state)	1 GΩ
Input Impedance (OFF state)	22 kΩ
Current consumption (5 VDC)	180 mA
Current consumption (+12 VDC)	90 mA
Current consumption (-12 VDC)	90 mA

Table 2-3. Strain-Gauge Signal-Conditioning Module Characteristics

Parameter	Features
Number of channels	8 differential
A/D converter	12-bit A/D per channel (0.25% resolution)
Maximum sample rate	20,000 samples per sec per channel

Input ranges	±10 mV, ±100 mV, ±1.0 V, ±10.0 V
Gain	1, 10, 100, 1000
Filter	Programmable cut-off frequency; 31-tap FIR digital filter per channel
Offset range	$\pm 75\%$ of input range
Bridge excitation voltage	0 to ± 5.1 V in ± 1.7 mV steps
Bridge type	¹ / ₄ bridge, ¹ / ₂ bridge, or full bridge (factory set)
Bridge resistance	120 - 1000Ω
Input Impedance (ON state)	1 GΩ
Input Impedance (OFF state)	22 kΩ
Current consumption (5 VDC)	180 mA
Current consumption (+12 VDC)	90 mA
Current consumption (-12 VDC)	90 mA

Table 2-4. Merger/Decoder Module Characteristics

Parameter	Particulars
Frame Format	Up to 16 formats may be defined
Bit Rate	Up to 2 Mbps
PCM Codes	BΙφ-L or NRZ-L
PCM Polarity	True/Inverse
DCLK Polarity	True/Inverse
Word Length	4 – 64 Bits
Syncword Length	10 – 32 Bits
Syncword Mask	Any bits in syncword
Minor Frame Length	2 - 4k Words
Most Significant Bit Transfer	First/Last
Current Consumption (5 VDC)	625 mA

The system computer uses a PCMCIA-format PCM decoder, an essential part of the system. This device decodes the PCM data stream coming from the master DAS into individual data words and places those words into computer memory for later retrieval and manipulation by software such as the ATLAS II software (discussed in Chapter 3).

Each chassis in the system has to be programmed by the system computer using the ATLAS II software. The user can specify the master/slave configuration information, data channel selections, data sampling rates, filter cut-off frequencies, channel gains and offsets, bridge excitation voltages, PCM format, and communication formats with the ATLAS II software. This information can be transferred to each chassis via hardwire or radio RS-232 link (separate from the RS-422 or TTL data link described above) at any

time to actually program the various DAS units. Programming a chassis interrupts data acquisition for that unit, but the unit resumes acquisition immediately upon completion of programming.

2.1.1 DAS Chassis

The KAM-500 chassis consists of a power supply and individual slots for the various modules. The power supply cannot be removed from the chassis. It contains a single 9-pin power connector; the pin assignment is shown in Figure 2-3.

User-supplied DC power must be connected to pins 1 and 2. Although the input power should be nominally 24 VDC, the unit can actually operate in the range of 18–40 VDC. The amperage requirement for the chassis will vary depending on the type and number of DAMs installed. The KAM-500 passes the input power through a DC/DC converter and regulates it to generate clean internal power with a voltage ripple of less than ± 50 mV. Pins 3 and 4 output regulated ± 12 VDC to power external devices, and pins 5 and 7 are a connection to the common digital ground for the KAM-500.

Pin	Name	I/O	Description	Comment
1	POWER+	Aircraft power	Nominal KAM-500 28V supply	Isolated internally
2	POWER-	Aircraft power	Return for nominal 28V	Isolated internally
3	+12V	+12 volt out	KAM-500 internal +12V	Current depends on int. loading
4	-12V	-12 volt out	KAM-500 internal -12V	Current depends on int. loading
5	GND		KAM-500 internal ground	
6	+5V	+5 volt out	KAM-500 internal +5V	Current depends on int. loading
7	GND		KAM-500 internal ground	
8	NC			Do not connect
9	NC			Do not connect

Figure 2-3. KAM-500 Power Supply Connector Pin Assignment.



The GND digital ground pin ties directly to the back plane of the chassis and is directly connected to the GND pin on the encoder or any instrumentation module.

2.1.2 Encoder Module

The KAM-500 encoder module is located in the chassis immediately adjacent to the power supply (it is the only module that can be installed there), and can be removed from the chassis. It contains the "smarts" for the KAM-500, controls the data acquisition, and outputs the PCM stream in both RS-422 and TTL format. Figure 2-4 describes the pin assignment on the 51-pin encoder connector. The format select pins (1, 2, 3, and 8) determine which of the sixteen possible formats is to be executed. Typically, only a single format is loaded into each DAS, so these pins should be hardwired to DGND to force the use of format 1. If a chassis is to run off its internal clock (not the normal mode for an

ATLAS II application), pins 4-7 (the Chassis ID pins) are not to be connected. If a PAT-SyM is used in a chassis (as in an ATLAS II configuration), pins 11-14 are connected to the PATSyM connector (see Figure 2-12 for PATSyM pin assignment) to provide synchronization of data acquisition, and pins 4-7 must be hardwired to a +5 VDC source to force the DAS to accept the input from pins 11-14. If the ATLAS II system includes multiple slave chassis, make sure that a unique combination for the Chassis ID signals (think of these lines as an address) is used. Pins 22 and 23 output the PCM data stream in TTL mode. Pins 15-18 output the PCM data stream in RS-422 mode. Pins 25-28 provide the interface signals needed to program the DAS.



Both RS-422 and TTL PCM data streams are output by the KAM-500, regardless of whether the RS-422 or TTL communications mode is specified when programming the DAS with the ATLAS II software.

2.1.3 Instrumentation Modules

As mentioned above, the instrumentation modules typically used in ATLAS II include the digital, high-level analog, and strain-gauge modules. Figure 2-5 describes the pin assignment on the 51-pin connector of the digital input module. Pins 1–48 are treated as discrete input lines. A voltage level below 0.8 VDC is interpreted as 0 and a voltage level of 2.0 VDC or higher is interpreted as 1. Avoid voltages in the 0.8 –2.0 V range as their interpretation is undefined, i.e., they could be interpreted as either a logic "1" or a logic "0". Maximum allowable voltage levels are ± 20 VDC. The DGND pin (pin 51) is connected to the chassis back plane and to the DGND pin of any other DAS connector.

Pin	Name	I/O	Description	Comment
1	FORMAT(0)	BTTL In	Format select line	LSB, Internally pulled to 0
2	FORMAT(1)	BTTL In	Format select line	Internally pulled to 0
3	FORMAT(2)	BTTL In	Format select line	Internally pulled to 0
4	CHASSIS_ID(0)	BTTL In	Chassis identifier/address	LSB, Internally pulled to 0
5	CHASSIS_ID(1)	BTTL In	Chassis identifier/address	Internally pulled to 0
6	CHASSIS_ID(2)	BTTL In	Chassis identifier/address	Internally pulled to 0
7	CHASSIS_ID(3)	BTTL In	Chassis identifier/address	MSB, Internally pulled to 0
8	FORMAT(3)	BTTL In	Format select line	MSB, Internally pulled to 0
9	GND		KAM-500 internal ground	
10	BVDD	5V Out	5V buffered with 220Ω resistor	Used to set format and CHASSIS_ID
11	X_CLK_IN+	RS-422 In	Ext. 1MHz sync. clock	Not internally terminated
12	X_CLK_IN-	RS-422 In	Ext. 1MHz sync. clock	Not internally terminated
13	X_SYNC_IN+	RS-422 In	Ext. sync. pulse	Not internally terminated
14	X_SYNC_IN-	RS-422 In	Ext. sync. pulse	Not internally terminated
15	DATA+	RS-422 Out	PCM output	Internally terminated with 1200
16	DATA-	RS-422 Out	PCM output	Internally terminated with 1200
17	DCLK+	RS-422 Out	Bit clock for PCM	Internally terminated with 1200
18	DCLK-	RS-422 Out	Bit clock for PCM	High for last half of bit
19	WORD_PULSE	BTTL Out	Indicates end of word	High for last bit of word
20	MINOR_PULSE	BTTL Out	Indicates minor frame end	High for last word of minor frame
21	MAJOR_PULSE	BTTL Out	Indicates major frame end	High for last word of major frame
22	DATA	BTTL Out	PCM output	
23	DCLK	BTTL Out	Bit clock for PCM	High for last half of bit
24	NRZ_L	BTTL Out	Uncoded PCM output	
25	PROG_DATA+	RS-422 I/O	Programming data line	Not internally terminated
26	PROG_DATA-	RS-422 I/O	Programming data line	Not internally terminated
27	PROG_DCLK+	RS-422 In	Programming clock line	Not internally terminated
28	PROG_DCLK-	RS-422 In	Programming clock line	Not internally terminated
29	PROG_DATA+			Shorted to pin 25
30	PROG_DATA-			Shorted to pin 26
31	PROG_DCLK+			Shorted to pin 27
32	PROG_DCLK-			Shorted to pin 28
33	X_CLK_OUT+	RS-422 Out	1MHz synchronization clock	Internally terminated with 1200
34	X_CLK_OUT-	RS-422 Out	1MHz synchronization clock	Internally terminated with 1200
35	X_SYNC_OUT+	RS-422 Out	Synchronization pulse	Internally terminated with 1200
36	X_SYNC_OUT-	RS-422 Out	Synchronization pulse	Internally terminated with 1200
37	NC			Do not connect
38	NC			Do not connect
39	NC			Do not connect
40	NC			Do not connect
41	NC			Do not connect

Figure 2-4. KAM-500 Encoder Pin Assignment.



Voltages outside the range of ± 20 V applied to the discrete input pins may damage the module.

Pin	Name	I/O	Description	Comment
1	DISCRETE(0)+	Discrete D/E In	Discrete Input	Also connected to counter 0
2	DISCRETE(0)-	Discrete D/E In	Discrete Input	Also connected to counter 0
3	DISCRETE(1)+	Discrete D/E In	Discrete Input	Also connected to counter 1
4	DISCRETE(1)-	Discrete D/E In	Discrete Input	Also connected to counter 1
5	DISCRETE(2)+	Discrete D/E In	Discrete Input	Also connected to counter 2
6	DISCRETE(2)-	Discrete D/E In	Discrete Input	Also connected to counter 2
7	DISCRETE(3)+	Discrete D/E In	Discrete Input	Also connected to counter 3
8	DISCRETE(3)-	Discrete D/E In	Discrete Input	Also connected to counter 3
9	DISCRETE(4)+	Discrete D/E In	Discrete Input	Also connected to counter 4
10	DISCRETE(4)-	Discrete D/E In	Discrete Input	Also connected to counter 4
11	DISCRETE(5)+	Discrete D/E In	Discrete Input	Also connected to counter 5
12	DISCRETE(5)-	Discrete D/E In	Discrete Input	Also connected to counter 5
13	DISCRETE(6)+	Discrete D/E In	Discrete Input	Also connected to counter 6
14	DISCRETE(6)-	Discrete D/E In	Discrete Input	Also connected to counter 6
15	DISCRETE(7)+	Discrete D/E In	Discrete Input	Also connected to counter 7
16	DISCRETE(7)-	Discrete D/E In	Discrete Input	Also connected to counter 7
17	DISCRETE(8)+	Discrete D/E In	Discrete Input	
18	DISCRETE(8)-	Discrete D/E In	Discrete Input	
19	DISCRETE(9)+	Discrete D/E In	Discrete Input	
20	DISCRETE(9)-	Discrete D/E In	Discrete Input	
21	DISCRETE(10)+	Discrete D/E In	Discrete Input	
22	DISCRETE(10)-	Discrete D/E In	Discrete Input	
23	DISCRETE(11)+	Discrete D/E In	Discrete Input	
24	DISCRETE(11)-	Discrete D/E In	Discrete Input	
25	DISCRETE(12)+	Discrete D/E In	Discrete Input	
26	DISCRETE(12)-	Discrete D/E In	Discrete Input	
27	DISCRETE(13)+	Discrete D/E In	Discrete Input	
28	DISCRETE(13)-	Discrete D/E In	Discrete Input	
29	DISCRETE(14)+	Discrete D/E In	Discrete Input	
30	DISCRETE(14)-	Discrete D/E In	Discrete Input	
31	DISCRETE(15)+	Discrete D/E In	Discrete Input	
32	DISCRETE(15)-	Discrete D/E In	Discrete Input	
33	DISCRETE(16)+	Discrete D/E In	Discrete Input	
34	DISCRETE(16)-	Discrete D/E In	Discrete Input	
35	DISCRETE(17)+	Discrete D/E In	Discrete Input	
36	DISCRETE(17)-	Discrete D/E In	Discrete Input	
37	DISCRETE(18)+	Discrete D/E In	Discrete Input	
38	DISCRETE(18)-	Discrete D/E In	Discrete Input	
39	DISCRETE(19)+	Discrete D/E In	Discrete Input	
40	DISCRETE(19)-	Discrete D/E In	Discrete Input	
41	DISCRETE(20)+	Discrete D/E In	Discrete Input	
42	DISCRETE(20)-	Discrete D/E In	Discrete Input	
43	DISCRETE(21)+	Discrete D/E In	Discrete Input	
44	DISCRETE(21)-	Discrete D/E In	Discrete Input	
45	DISCRETE(22)+	Discrete D/E In	Discrete Input	
46	DISCRETE(22)-	Discrete D/E In	Discrete Input	
47	DISCRETE(23)+	Discrete D/E In	Discrete Input	
48	DISCRETE(23)-	Discrete D/E In	Discrete Input	
49	NC			Do not connect
50	NC			Do not connect
51	GND		KAM-500 internal ground	

Figure 2-5. KAM-500 Digital Input Card Pin Assignment.

Figure 2-6 shows the pin assignment on the 51-pin connector of the high-level analog module. The pins not shown in the figure are not used (they are not connected inside the DAM). The module senses the differential voltage present between two-pin pairs. This voltage must be limited to ± 10 V to be properly sensed by the card. Voltages beyond those limits will be sensed as -10 V or +10 V. The analog ground (GND) pin should be wired to the GND (pin 2) on the power connector.

CAUTION	

Differential voltages outside the range of ± 40 V may damage the module.

Pin	Name	I/O	Description	Comment
1	ANALOG(0)+	Analog D/E In	Analog input	
2	ANALOG(0)-	Analog D/E In	Analog input	
3	ANALOG(1)+	Analog D/E In	Analog input	
4	ANALOG(1)-	Analog D/E In	Analog input	
5	ANALOG(2)+	Analog D/E In	Analog input	
6	ANALOG(2)-	Analog D/E In	Analog input	
7	ANALOG(3)+	Analog D/E In	Analog input	
8	ANALOG(3)-	Analog D/E In	Analog input	
9	ANALOG(4)+	Analog D/E In	Analog input	
10	ANALOG(4)-	Analog D/E In	Analog input	
11	ANALOG(5)+	Analog D/E In	Analog input	
12	ANALOG(5)-	Analog D/E In	Analog input	
13	ANALOG(6)+	Analog D/E In	Analog input	
14	ANALOG(6)-	Analog D/E In	Analog input	
15	ANALOG(7)+	Analog D/E In	Analog input	
16	ANALOG(7)-	Analog D/E In	Analog input	
17	GND		KAM-500 internal ground	
18	NC			Do not connect
19	NC			Do not connect
20	NC			Do not connect

Figure 2-6. KAM-500 Analog Module Pin Assignment.

Figure 2-7 describes the pin assignment for the 51-pin connector of the strain-gauge module. The first 48 pins are divided into eight groups of six, each group dedicated to one strain gauge. Figure 2-8 is a schematic diagram of a typical full-bridge strain gauge and illustrates the connection points for the six pins allocated to each channel on the module. In general, the SENSE+ pin of each channel is tied to the EXC_V+ pin of that channel and the SENSE- pin is tied to the EXC_V- pin. Thus the EXC_V± pins provide excitation and this in turn is sensed at the SENSE± pins. If the system configuration is such that it doesn't require the use of the SENSE lines, they can be left disconnected without any problems. The power supply in the chassis provides the excitation voltage for the strain gauges sensed by this module. The voltage at these pins must be at least 20% above the highest user-specified voltage level for bridge excitation. The input excitation voltage is converted down to the user-specified excitation voltage level (set with the ATLAS II software) and then output to the bridge through the EXC_V± pins of each channel. Pin 51 (GND) should be tied to GND (pin 2) of the 9-pin power connector; see Figure 2-3.

Pin No.	Name	I/O	Description	Comment
1	SENSE(0)+	Sense In	Sense line from top of bridge	
2	EXC_V(0)+	Excitation pos.	Excitation to top of bridge	
3	EXC_V(0)-	Excitation neg.	Excitation to bottom of bridge	
4	ANALOG(0)-	Analog D/E In	Analog input	Connected to internal adjust
5	ANALOG(0)+	Analog D/E In	Analog input	
6	SENSE(0)-	Sense In	Sense line from bottom of bridge	
7	SENSE(1)+	Sense In	Sense line from top of bridge	
8	EXC_V(1)+	Excitation pos.	Excitation to top of bridge	
9	EXC_V(1)-	Excitation neg.	Excitation to bottom of bridge	
10	ANALOG(1)-	Analog D/E In	Analog input	Connected to internal adjust
11	ANALOG(1)+	Analog D/E In	Analog input	
12	SENSE(1)-	Sense In	Sense line from bottom of bridge	
13	SENSE(2)+	Sense In	Sense line from top of bridge	
14	EXC_V(2)+	Excitation pos.	Excitation to top of bridge	
15	EXC_V(2)-	Excitation neg.	Excitation to bottom of bridge	
16	ANALOG(2)-	Analog D/E In	Analog input	Connected to internal adjust
17	ANALOG(2)+	Analog D/E In	Analog input	
18	SENSE(2)-	Sense In	Sense line from bottom of bridge	
19	SENSE(3)+	Sense In	Sense line from top of bridge	
20	EXC V(3)+	Excitation pos.	Excitation to top of bridge	
21	EXC_V(3)-	Excitation neg.	Excitation to bottom of bridge	
22	ANALOG(3)-	Analog D/E In	Analog input	Connected to internal adjust
23	ANALOG(3)+	Analog D/E In	Analog input	
24	SENSE(3)-	Sense In	Sense line from bottom of bridge	
25	SENSE(4)+	Sense In	Sense line from top of bridge	
26	EXC_V(4)+	Excitation pos.	Excitation to top of bridge	
27	EXC_V(4)-	Excitation neg.	Excitation to bottom of bridge	
28	ANALOG(4)-	Analog D/E In	Analog input	Connected to internal adjust
29	ANALOG(4)+	Analog D/E In	Analog input	
30	SENSE(4)-	Sense In	Sense line from bottom of bridge	
31	SENSE(5)+	Sense In	Sense line from top of bridge	
32	EXC_V(5)+	Excitation pos.	Excitation to top of bridge	
33	EXC_V(5)-	Excitation neg.	Excitation to bottom of bridge	
34	ANALOG(5)-	Analog D/E In	Analog input	Connected to internal adjust
35	ANALOG(5)+	Analog D/E In	Analog input	
36	SENSE(5)-	Sense In	Sense line from bottom of bridge	
37	SENSE(6)+	Sense In	Sense line from top of bridge	
38	EXC_V(6)+	Excitation pos.	Excitation to top of bridge	
39	EXC_V(6)-	Excitation neg.	Excitation to bottom of bridge	
40	ANALOG(6)-	Analog D/E In	Analog input	Connected to internal adjust
41	ANALOG(6)+	Analog D/E In	Analog input	
42	SENSE(6)-	Sense In	Sense line from bottom of bridge	
43	SENSE(7)+	Sense In	Sense line from top of bridge	
44	EXC_V(7)+	Excitation pos.	Excitation to top of bridge	
45	EXC_V(7)-	Excitation neg.	Excitation to bottom of bridge	Connected to internal a first
	ANALOG(7)-	Analog D/E In	Analog input Analog input	Connected to internal adjust
47	ANALOG(7)+	Analog D/E In Sense In	Analog input Sease line from bottom of bridge	
48	SENSE(7)- NC	Jense In	Sense line from bottom of bridge	Do not connect
49	NC			Do not connect
50	GND		KAM-500 internal ground	Do not connect
51	GND		rona-odu internai ground	

Figure 2-7. KAM-500 Strain-Gauge Module Pin Assignments.



Amplifier output voltages (the product of the maximum input voltage times the gain) outside the range of ± 40 V may damage the module. An amplifier output voltage outside the range of ± 10 V will not be sampled correctly (the sampled value will appear as ± 10 V).




Figure 2-8. Full-bridge Strain Gauge Schematic.

2.1.4 Merger/Decoder Module

Figure 2-9 describes the pin assignment for the 51-pin connector of the merger/decoder module. This module is inserted in the master DAS to merge the data streams from up to two slaves into the data stream output by the master. During system programming, specify which communications channel will be used to transfer data from each slave to the master. Even though every encoder DAM generates both TTL and RS-422 PCM data streams, the merger/decoder DAMs only accept RS-422 data streams. For example, for proper operation to merger/decoder bus1, connect pins 15 (RS-422 TX+), 16 (RS-422 TX-), 17 (RS-422 Data Clock+), 18 (RS-422 Data Clock-), and 9 (DGND) from the slave encoder connector to pins 1, 2, 3, 4, and 11, respectively, of the merger/decoder.

Pin	Name	I/O	Description	Comment
1	DATA(0)+	RS-422 In	PCM data	First bus
2	DATA(0)-	RS-422 In	PCM data	First bus
3	DCLK(0)+	RS-422 In	PCM data clock	First bus
4	DCLK(0)-	RS-422 In	PCM data clock	First bus
5	DATA(1)+	RS-422 In	PCM data	Second bus
6	DATA(1)-	RS-422 In	PCM data	Second bus
7	DCLK(1)+	RS-422 In	PCM data clock	Second bus
8	DCLK(1)-	RS-422 In	PCM data clock	Second bus
9	NC			Do not connect
10	NC			Do not connect
11	GND		KAM-500 internal ground	
12	GND		KAM-500 internal ground	
13	NC			Do not connect
14	NC			Do not connect
15	NC			Do not connect
16	NC			Do not connect
17	NC			Do not connect
18	NC			Do not connect
19	NC			Do not connect

Figure 2-9. KAM-500 Merger/Decoder Pin Assignment.

2.2 Data Communication Subsystem

PCM data transfer from the slaves to the master and from the master to the system computer may be accomplished via hardwire, fiber optics, or telemetry. This data transfer occurs concurrent with data acquisition to enable data acquisition to continue over an indefinite period. For some applications, hardwire communications are possible between the slaves and the master and between the master and the system computer. For many applications, however, hardwire communications between all the slave units and the master is not possible. In particular, the turbine's rotor may not include slip rings or other provisions for transferring information between the rotor and the tower or the ground, making hardwire communications with the rotor unit impossible. To enable communications in these situations, ATLAS II includes a data communications subsystem (DCS).

The DCS utilizes low-cost, frequency-hopping, spread-spectrum radio modems, from Cirronet Corp.², to transmit PCM data from any slave to the master or from the master to the system computer (the PCM data link). A modem is also utilized to transmit control and programming information between the system computer and any slave using the RS-232 programming link. The RS-232 link and data link each consist of a pair of Cirronet WIT-2410 wireless modems. These modems are programmed to operate as separate, independent networks and do not interfere with each other (16 separate network numbers are available). The WIT-2410 modems operate at a frequency of 2.4 GHz, incorporate a transparent error-correction feature that automatically requests retransmission of any data not received properly, and are capable of data rates as high as 256 kbps (thousands of bits per second). The spread-spectrum technology makes the radio link much less susceptible to the interference found in a wind-turbine environment than conventional technologies. (single-frequency radio links, for example). The radio systems require no license for operation, and the maximum transmit power of 100 mW minimizes interference with other radio systems. Each radio modem module is $2.4 \times 2.0 \times 0.6$ in. in size and consumes a maximum of 1.5 W of power. These units are programmed to operate in the asynchronous transfer mode for the RS-232 link and in the synchronous transfer mode for the PCM data link.

2.3 Programmable Accurate Time Synchronization Module

Precise time sequence and phase information from all parts of the turbine and the anemometry is necessary to understand the load and response phasing, the loading sequences, and the load paths of the turbine. Therefore, data must be simultaneously acquired by all of the DASs on a turbine, whether they are located on the turbine rotor, the turbine tower, the meteorological tower, or the ground. Normally, the chassis' internal clock drives the actual data acquisition time for each DAS unit. If these clocks are independent, their inherent inaccuracies will result in the time for each clock drifting with respect to the other clocks. For a typical clock accuracy of one part in one million, the drift between two clocks could be as much as 170 milliseconds in 24 hours. This difference will result in

² Cirronet Corporation, 5375 Oakbrook Parkway, Norcross, GA, 30093, (770) 564-5540

data acquisition at different absolute times for each DAS unit and can make time correlation of the data from the various DAS units difficult.

To maintain very accurate clock synchronization between the DAS units over long periods of time, ATLAS II utilizes the GPS system. In normal operating mode, each GPS satellite continually transmits its orbital parameters, along with the precise universal time clock (UTC). GPS receivers decode that information and utilize triangulation techniques to accurately determine their position and UTC. The internal clock in each GPS receiver is continually adjusted to keep it in agreement with UTC. If the DAS clocks are slaved to GPS receiver time (UTC), they will not drift with respect to each other.

The Programmable Accurate Time Synchronization Module (PATSyM), developed by Sandia National Laboratories (SNL) specifically for the ATLAS II application, utilizes a commercial Jupiter GPS receiver³ to do exactly that. As long as the Jupiter antenna is receiving signals from three or more GPS satellites, the receiver will remain synchronized with UTC within $\pm 1 \mu s$. Thus, the clocks in two of these receivers will vary with respect to each other by a maximum of 2 µs, regardless of how long they have been operating. The Jupiter receiver also generates a one pulse per second (1PPS) signal, with the rising edge of the pulse occurring exactly on the UTC second. The PATSyM, shown in Figure 2-10, utilizes this 1PPS signal to generate two clock pulse trains that are precisely synchronized to UTC. These pulse trains control the actual data acquisition times of all the DAS units, forcing them to acquire data within 2 µs of each other, indefinitely. The actual data acquisition time, accurate to $\pm 1 \mu s$, is available from each PATSvM and can be included in the PCM data stream (i.e., the data from each DAS can be time-stamped). This information can then be used to associate the data acquired by one DAS at a specific time with the data acquired by other DASs at that same time. In practice, using modems to transfer data from the rotor delays the data by one sample period (for 30 Hz data) – the rotor data received in a data frame usually corresponds to the ground-based data received one sample data frame earlier.

³ Conexant Systems, Inc., 4311 Jamboree Road, P.O. Box C, Newport Beach, CA, 92658-8902, (949) 483-4600.



Figure 2-10. The Programmable Accurate Time Synchronization Module

The PATSyM is a custom-built eight-layer card that fits in the KAM-500 chassis. It incorporates an ALTERA[®] 10K70 programmable logic device (PLD) from ALTERA[®] Corporation⁴ and associated hardware. An SNL-developed logic program controls the operation of the PLD and, thus, the PATSyM. In addition to providing time synchronization for the DAS, the PATSyM also handles all RS-232 communications with the user; all communications and data interchange between the DAS and the DCS, and subsystem activity coordination in order to meet the system requirements. Berg et al. (1999) contains additional technical information on PATSyM. Characteristics of the module are summarized in Table 2-5.

Parameter	Value
Drift with respect to GPS (UTC) time	Maximum of one microsecond, assuring 1×10^{-6} clock accuracy
Frequency of resync with GPS time	Once per second
RS-232 comm speed for GPS data	9,600 bits per second
RS-232 comm speed for programming KAM/500	115,200 bits per second
Current consumption (5 VDC)	200 mA

 Table 2-5.
 PATSyM Characteristics

⁴ Altera Corporation, 2610 Orchard Parkway, San Jose, CA 95134-2020.

The GPS receiver in each PATSyM must be connected to an antenna with a generally unobstructed view of the sky. The GPS signals will pass through small amounts of common building materials, such as glass, wood, brick, and concrete block, but will usually not pass through metal objects. A general rule of thumb is that the GPS antenna must be mounted outside of any building, but some antennas may work inside some buildings. The receiver requires signal reception from at least three satellites before it can synchronize, or "lock," its internal clock to UTC. Even if the antenna is placed so it has an unobstructed view of the sky, a receiver may take as long as five minutes to acquire lock after the receiver power is turned on. Keep in mind that an antennas must be mounted on the rotor to provide GPS signals to the RBU. The ability of the rotor-mounted GPS receiver to retain satellite communications and time lock is dependent on both the antenna rotation speed and antenna configuration. A half-wavelength antenna configuration (about 3 in. in diameter) is adequate for maintaining time lock at rotation speeds as high as 350 rpm. Experience has shown that an antenna mounted on a non-rotating wind-turbine rotor will usually lock onto six or more satellites. As the antenna rotation speed is gradually increased, the number of satellites that the receiver is locked onto gradually decreases. At 350 rpm, the receiver is usually locked onto only three or four satellites at any one time, and the actual satellites in lock change frequently (perhaps every revolution). Momentary satellite communication dropouts, which might occur during brief periods of higher rotation speed, are not a problem because the clock in the receiver will continue to run and produce the 1PPS signal, although that clock will slowly drift with respect to UTC. Once the antenna rpm drops to 350 or less, the receiver will reestablish communications with three or more satellites, and the receiver clock will be quickly relocked to UTC time. SNL has always mounted the rotor antenna so that its axis of rotation coincides with the rotor axis of rotation to minimize rotation-caused motion. Antenna wobble due to mounting the antenna so that its axis is offset several centimeters from the rotor axis is not expected to cause loss of lock at low rpm (100 rpm or below), but this has not been verified. It is important that the antenna be mounted so it always has an unobstructed view of the sky throughout its rotation.

NOTE

Be sure that each GPS receiver is receiving messages from at least three satellites, because only then is the internal clock locked to the UTC. The status of each GPS receiver can be determined by monitoring the GPS output from that receiver (see Section 3.13.1 "PATSyM Diagnostics Utility").

The GPS signals are relatively weak and mounting the GPS receiver as close to the antenna as possible enhances signal reception from the maximum number of satellites. The communications between the receiver and PATSyM consist of RS-232 and high-level pulse trains, so the receiver can be mounted several meters away from the PATSyM without causing communications degradation. The receiver may be placed in a weatherproof box that can also serve as a mount for the GPS antenna, as shown in Figure 2-11.



Figure 2-11. GPS Receiver/Antenna Configuration.

Figure 2-12 illustrates the pin assignment on the 51-pin connector of the PATSyM. Inputs on pins 1-3 must supply 12 VDC and 5 VDC power to the module. Pin 4 outputs 12 VDC that can be switched off by a user-controlled (usually closed) relay on the module. Pins 11 and 12 output the external clock pulse-trains that are input to encoder pins 4 and 5, respectively, as shown in Figure 2-4. Pins 13 and 14, shown in Figure 2-12, receive the TTL-level PCM data from encoder pins 11 and 12. Pins 15 and 16 are connected to the encoder RS-232 serial communications pins 13 and 14, respectively. Pins 19 and 30–34 are connected to the GPS receiver/antenna unit, wired to the pins with the same labels on the GPS connector.

Pins 15–18 and 48–50 are usually used only in a rotor-mounted DAS configuration when all serial communications (RS-232) must go through a single modem. In this case, the user can utilize the "GPS Data" routine in the ATLAS II software (see Section 3.2.4.1) to switch the serial communications between receiving GPS data and programming the KAM-500. Pin 50 then determines which set of communication lines is active.

Pins 17 and 18 provide TTL-level RS-232 serial communications (internally connected to pins 16 and 15, respectively) when pin 50 is grounded, and they are disconnected when pin 50 is allowed to float high. Pins 48 and 49 (internally connected to the receive and transmit pins, respectively, on the RS-232 data modem) provide CMOS-level communi-

cations signals (internally connected to pins 16 and 15, respectively) when pin 50 is allowed to float high, and they are disconnected when pin 50 is grounded.

Pin #	in # Pin Name Pin Description						
1	+5V	5 V input					
2	DGND	Digital ground					
3	+12V	12 V input					
4	+12V_SWITCH	Switched 12 V output					
5	NC	Do not connect					
6	NC	Do not connect					
7	NC	Do not connect					
8	NC	Do not connect					
9	NC	Do not connect					
10	NC	Do not connect					
11	EXT_SYNC	External sync pulse output					
12	EXT_CLK	External clock pulse output					
13	PCM_DATA	PCM data input (in user-specified code)					
14	DCLK	Data clock input					
15	S_IN2	RS-232 transmit from encoder, input					
16	S_OUT2	RS-232 receive to encoder, output					
17	S_IN1	RS-232 input from hardwire connection					
18	S_OUT1	RS-232 output to hardwire connection					
19	GPS_TX	RS-232 link to GPS receiver, output					
20	NC	Do not connect					
 29	NC	Do not connect					
29 30	PWR IN	5V switched power for GPS receiver,					
50		output					
31	M RST	Master reset for GPS receiver, output					
32	1 PPS	1 pulse per second from GPS receiver,					
54	1-115	input					
33	10_HZ_GPS	10 Hz pulse train from GPS receiver, input					
34	GPS RX	RS-232 line to GPS receiver, input					
35	NC	Do not connect					
47	NC	Do not connect					
48	USIN2	CMOS-level RS-232 input from modem					
49	USOUT2	CMOS-level RS-232 output to modem					
50	TTL/RS232	User-select switch for CMOS/RS-232					
		selection, input					
51	NC	Do not connect					

Figure 2-12.	PATSyM Pin	Assignment.
1 igui c 2-12.	17115ym11m	Assignment.

Figure 2-13 illustrates the pin assignment for the 13-pin connector on the GPS antenna/receiver box. Pin 1 should be connected to a constant source of 5 VDC. This maintains the GPS satellite information when the antenna/receiver unit is placed in the sleep mode. Pin 2 must be connected to the DAS digital ground. Pins 3 and 4 provide RS-232 communication between the GPS receiver and the PATSyM. Pin 5 causes a master reset of the GPS (a cold start) when tied to ground. Pin 6 is the time mark 1PPS used by PATSyM to synchronize the generated pulse trains to UTC, and pin 7 is a 10 kHz pulse train output by the GPS receiver. Pin 8 is the primary power supply to the GPS. When this is pulled to ground, the GPS receiver and antenna shut down. If power is supplied on pin 1 during this time, the system will come up much quicker than would be the case if pin 1 were not kept high because the satellite location table is kept current.

		(2 1 (0) (3 (1) (0) (4 (12 (1) (0)) (3 (1) (0)) (3 (1) (0)) (4 (12 (1) (0)) (4 (12 (1) (1))) (5 (1) (1)) (5 (1)) (6 (1)) (6 (1)) (6 (1)) (7 (1				
Pin #	Pin Name	Pin Description				
1	+5V	+5 VDC power input (stay-alive power))				
2	DGND	Digital ground				
3	GPS TX	GPS TX GPS RS-232 transmission				
4	GPS RX-	GPS RS-232 receive				
5	M RST	Master reset (active low)				
6	1_PPS	One pulse per second time mark output				
7	10kHz_GPS	10 KHz clock output				
8	PWR IN	Primary +5 VDC power input				
9	NC	Do not connect				
10	NC	Do not connect				
11	NC	Do not connect				
12	NC	Do not connect				
13	NC	Do not connect				
Connecto	or: 13-pin miniature circ	ular shell, female				
Connecto		ular shell , female				

Figure 2-13. GPS Antenna/Receiver Pin Assignment.

2.4 Lightning Protection Equipment

DAS units and all other ATLAS II components are susceptible to damage from high voltages due to lightning or other types of electrostatic discharge (ESD). It is important to include over-voltage protection for these components. The Citel E280-6V and-12V lightning protection modules from Citel Corporation⁵ have worked well for the ATLAS II. Specification sheets on this product may be found in Appendix A. Each module supplies protection for two pairs of signal lines at a cost of 40-50 per module.

The Citel units contain both a quick-switching silicon avalanche diode and a gas tube between the lines being protected and ground, along with a small resistor that causes current to flow through the gas tube when it is switched. The avalanche diode provides quick response to an electrostatic discharge such as lightning, but it cannot discharge much power. The gas tube, on the other hand, does not switch quickly and needs a voltage potential of about 100 V to fire, but it can discharge large amounts of power. The Citel specification sheet claims a response time of less than 1 nanosecond, with a peak current capacity of 10 kA for these units. If one of these devices is placed in series in the bridge excitation line for a strain-gauge instrumentation module, the current drawn by the bridge (a few milliamps) will create a small voltage drop across that resistor. That voltage drop will result in an excitation voltage at the strain-gauge bridge that is lower than that specified by the user during system configuration; a significant problem in some applications. The bridge signal lines, however, carry very little current, so the voltage drop due to the resistor in a Citel device placed in the signal line is very small. Thus the Citel devices can easily be used to protect these lines. The Citels are used to protect all of the bridge lines, but they are connected as a shunt to ground (the line from the instrumentation module to the bridge is connected to the line terminal on the Citel unit) on the excitation lines and in series (the lead from the instrumentation module is connected to the equipment side of the Citel unit and the lead to the bridge is connected to the line side of the Citel) on the signal lines. These connections are illustrated in the wiring schematic for the LIST units in Appendices B and C. In these configurations, the Citel devices can protect the bridge excitation lines from over-voltage events with up to 85 A currents, and the signal lines are protected for up to 10,000 A currents. While the 10,000 A protection should be sufficient for protection against most direct lightning strikes, the 85 A protection certainly is not - it does, however, offer protection from handling-induced ESD.

If the Citels do trigger, they will automatically reset as soon as the voltage level drops to normal operating voltage, and they will provide protection against future over-voltage effects. However, the gas tubes tend to lose their charge over a period of time and eventually they cease to provide protection, so each module should be tested to ensure that it functions properly every two to three years.

Another device that appears to be well suited for providing general over-voltage protection: is the SIDACtor, made by Teccor Electronics, Inc.⁶ These small devices have a very high off-state impedance, but turn on quickly (within 5 ns) when their break-over voltage is exceeded. They do *not* require the insertion of a resistor in a line in order to protect that line. In the "on" state, they create a short to ground, preventing high voltage from reaching the protected device, and they remain in this state until the current drops

⁵ Citel Corporation, 1111 Park Centre Boulevard, Suite 340, Miami, FL 33169, (305) 621-0022, www.citelprotection.com

⁶ Teccor Electronis, Inc, 1800 Hurd Drive, Irving, TX 75038, (972) 580-7777, <u>www.teccor.com</u>

below a holding value. Their protection capability does not deteriorate with time. These devices can shunt approximately 200–500 A to ground for short periods of time. They provide more protection than is provided by the Citel devices on the bridge excitation lines, but much lower than the protection provided by the Citel devices on the bridge signal lines. It should be sufficient to protect against most over-voltage events, such as ESD or nearby lightning, but probably will not protect against a direct lighting hit. However, the Citel modules may also prove to be inadequate in case of a direct lightning hit. In the two years that ATLAS II has been deployed at the Bushland, TX site, numerous thunderstorms have occurred in the immediate vicinity, but no direct lightning hits on the system have occurred. These devices should be considered for lightning protection, as they are much smaller than the Citels, do not degrade over time, and do not cause a voltage drop in the line being protected, regardless of the amount of current flowing through that line.

2.5 Power Supplies

A DAS power supply must not only supply power for the DAS and the instrumentation modules contained within it, but it must also supply power the PATSyM module, and perhaps supply excitation to the analog instrumentation being monitored, depending on the particular application. If telemetry is used, the RBU power supply must also power two independent modems. The strain gauge and analog excitation can be supplied through the KAM-500 (within the limits listed on the specification sheet), or directly from the power supply. As noted above, the strain-gauge instrumentation module has two pins for bridge excitation input. The voltage at these inputs must be at least 20% above the highest user-specified level for bridge excitation. This voltage is converted down to the user-specified bridge-excitation voltage level and then output to the actual bridge through the 51-pin module connector (see the connector pin assignment in Figure 2-7). Information on estimating the power supply requirements for the DAS may be found in Appendix D. Pick a power supply that can supply more current than the amount needed, to allow for the possible addition of more instrumentation. Power supply size and weight are of much more importance for an RBU than for a GBU, due to size constraints.



If a switching power supply is used, do not connect multiple units in parallel to achieve the necessary current – the feedback circuits in the power supplies will "buck" each other and the resultant voltage and current output levels will be unstable.

The power supply voltage for the DAS can range from 18 to 40 VDC. Noise regulation of the power supply is not particularly important if all of the power is to be passed through the KAM-500, as the KAM-500 filters the incoming power. However, if the power supply is to provide instrument excitation voltage directly (rather than through the KAM-500 voltage output lines), the power supply should be regulated to ± 50 mVDC or better. The COSEL MMB75A-2 24 VDC power supply has worked well for this

application. This unit operates off 110 VAC, single phase, and supplies two 12 VDC outputs; one with 3 A of output, the other with 1.5 A of output. By connecting the negative side of the 3 A output to the positive side of the 1.5 A output, the output votages can be changed to +24 VDC (3 A) and -24 VDC (1.5 A). This unit provides enough current to power most DAS configurations.

2.6 Connectors

Connectors are needed to connect the DAS units with data, communication, and power lines. The following description describes the approach taken when designing and selecting the connectors for these units.

Using the same connectors for both indoor- and outdoor-mounted units makes it easy to interchange units, minimizes the number of connector configurations required, and minimizes the number of test cables needed. The cylindrical military/aerospace weatherproof connectors supplied by ITT Cannon, AMP, and other connector manufacturers offer good quality at reasonable prices. Using JT07-14-18S (bulkhead connector)/JT06-14-18P (cable connector) 18 pin connectors and JT07-12-98S (bulkhead connector)/JT06-12-98P (cable connector) 10 pin connectors to connect strain gauge signals to the DAS units works quite well. The same connectors (JT07-14-18P for bulkhead/JT06-14-18S for cable, etc.), in reverse polarity, are used to connect all analog signals. Although these connector pairs contain the same number of pins, the connector polarity is reversed between the strain-gauge connectors and the analog connectors. For the strain gauge connections, the cable connector contains pins. For the analog connections, the cable connector contains sockets. The difference in polarity prevents possible damage to instrumentation and DAMs due to accidental connection of strain gauge DAMs to analog instrumentation and vice versa. JT07-16-26S/JT06-16-26P 16-pin connector pairs work well for digital input. A JT07-8-3P/JT06-8-3S (3-pin) connector works well for the AC power connection, JT07-10-13P/JT06-10-13S (13 pin) connectors for the GPS antenna connection, and LJT07-11-13S/LJT06-11-13P (13-pin) connectors for the communications cable connection. These connectors are readily available from Spacecraft Components Corporation'. Connections to the KAM-500 power and signal lines require the use of female subminiature D connectors in 9, 15, and 51-pin configurations. Pre-wired cables with these connectors are marketed by Cinch and Cannon and are commercially available.

2.7 ATLAS II Application-Specific Configuration

2.7.1 Application Planning

The hardware components of ATLAS II can be configured in many different ways to tailor the system to specific applications. The first step in assembling an ATLAS II for a new application is to determine the hardware needed for the particular application and separate that hardware into the distinct data acquisition units. The RBU contains the ac-

⁷ Spacecraft Components Corporation, 14137 Chadron Avenue, Box Number 5027, Hawthorne, CA 90251, (310) 973-6400.

quisition hardware that will be mounted on and rotate with the turbine rotor. The GBUs contain the rest of the acquisition hardware; that hardware which will be mounted on the meteorological tower, the nacelle, the turbine tower, the turbine base, and perhaps other turbine components.

The RBU typically contains a DAS with associated DAMs and a PATSyM, the telemetry modems that make up the DCS (if telemetry data and communications links will be used), a power supply, lightning-protection equipment, and a GPS receiver/antenna unit. All of these components must be mounted inside a weatherproof container as shown in Figure 2-14. Typical RBU components are shown in Figure 2-15.



Figure 2-14. Typical RBU Weatherproof Case.




Figure 2-15. RBU components.

A GBU typically contains a DAS with associated DAMs and a PATSyM, a power supply, lightning-protection equipment, and fiber-optic units if needed. All GBU units are now enclosed in an aluminum NEMA case, and all AC power has been eliminated from inside the unit. A separate power supply consisting of a 24 volt DC UPS with a backup battery capable of powering the system for 30 minutes, is shown in Figure 2-16.



Figure 2-16. ATLAS II GBU and power supply

The master GBU receives data from other GBUs, merges all the data into one data stream, and sends that data stream to the system computer. Data links between the Slaves and the master may be hardwire, fiber-optic, or telemetry. The master GBU must contain the receiving modem for any telemetry link that is used. It must also contain one merger/decoder module to merge RBU data into the master data stream, one additional merger/decoder module for every two slave GBUs (to merge their data streams), and one or more DAMs to acquire data from local sensors.

The system computer is usually located in a building and includes the PCM decoder and the ATLAS II software. The full data stream is typically transmitted from the master GBU to the decoder via either hardwire or fiber-optic cable. The system computer must also contain hardwire, fiber optic, or telemetry RS-232 communication links with the RBU and each GBU.

The actual hardware configuration of the system must now be planned to determine the number and type of DAMs to be placed in each DAS, and thus the minimum allowable size (i.e., the number of slots) of each DAS.



All DAS units should be located close to the sensors and indicators from which they are acquiring data in order to minimize contamination of the data by electrical noise picked up by analog signal wires.

The following steps will aid in identifying the components to be included in the RBU and the GBUs for a specific application.

- 1. Determine the number of data sensors to be monitored and the type of data to be acquired from each sensor.
 - a) Digital sensors will require the use of a digital input module (see Table 2-1 and Figure 2-5) with one line per bit connecting the sensor to the module and additional lines to provide sensor excitation, as needed. A digital input module will sample up to 48 bits of digital input.
 - b) Analog sensors $(0 \pm 10 \text{ V} \text{ output})$ will require the use of a high-level analog input module (see Table 2-2 and Figure 2-6), with two lines connecting each signal to the module. A high-level analog module will sample up to eight differential analog inputs.
 - c) Strain-gauge sensors will require the use of a strain-gauge input module (see Table 2-3 and Figure 2-7). Strain gauges are normally connected to the instrumentation module with four wires per gauge (+ and excitation and + and signal). If the excitation wires between the module and the gauge are long enough that the voltage drop that will occur is of concern, run a 5th line (the B lead) between the two to permit sensing (and control) of the excitation voltage at the gauge itself. A strain-gauge module will handle as many as eight gauges. The normal strain-gauge modules will work with 120, 350, or 1000 Ω full-bridge configurations. Strain-gauge modules can also be *factory* configured to work with half-bridge or quarter-bridge strain gauge arrangements.
- 2. Determine the number of DAS units that will be used to acquire the data of interest. It is preferable to put a DAS close to each major group of sensors to minimize noise caused by long wires between the sensor and the associated DAS.
- 3. Determine the number of DAMs required in each DAS. As noted above, a single DAM will acquire up to eight channels of strain-gauge data, eight channels of highlevel analog data, or 48 bits of digital data. Use this information to determine the minimum number of slots needed in each DAS. DAS units are available with 3, 6, 9, or 13 module slots.

- 4. The DAS that will be mounted on the rotor and used to acquire the rotor data becomes the RBU. All of the other DASs are called GBUs.
- 5. The RBU and each GBU will require a PATSyM to sychronize the acquisition timing (see Table 2-5 and Figure 2-12). It is possible to use a single PATSyM to synchronize two GBUs. However, the GBUs should be quite close to each other or the PATSyM clock pulse trains may degrade to the point where they will not properly trigger the DAS. It may be possible to drive three or more GBUs with a single PATSyM, but this has not yet been demonstrated.
- 6. Designate one GBU as the master. All GBUs, other than the master, will be considered slaves. As indicated above, the master unit receives the data streams from the slave GBUs and merges all of them into a single data stream for transmission to the system computer and storage to disk. One merger/decoder DAM will be required in the master to receive the data for every two slave GBU units. (see Table 2-4 and Figure 2-9).
- 7. Determine the number of lightning protection modules required for the RBU and each GBU.
- 8. Determine the number of power supplies required and the current requirements of each.
- 9. Determine the number and types of connectors needed.
- 10. Gather the necessary DAS units, DAMs, PATSyMs, the system computer, the power supplies, the lightning protection equipment, and the connectors. Although the usual procedure is to purchase everything required for an ATLAS II application, an agreement with SNL or National Renewable Energy Laboratory (NREL) may provide for the loan of DAS units and DAMs. In any case, the power supplies, lightning protection equipment, and connectors will probably have to be purchased. Be sure to purchase a few extra connectors to accommodate changes in instrumentation and communications.

Assembly of the ATLAS II for the specific application can now begin.

2.7.2 General Fabrication Notes

All lines into and out of the GBU or RBU should be shielded to minimize the possibility of introducing noise or induced voltages into those lines. The shield should be grounded either at the GBU/RBU or at the instrumentation end of the line, but not at both. Grounding at both ends creates a potential for a ground loop and could lead to inaccurate data. The power supply should also be shielded to keep the electrical noise generated by it from feeding noise into the data lines.

All DAS units, including the RBU and the master GBU, should have encoder pin 6 wired to a +5 VDC or higher source whenever power is supplied to the DAS. This is necessary for the DAS to accept the clock information furnished to it by the PATSyM.



The necessary cables must be built to connect the components within each GBU and RBU and to connect those units to the instrumentation. See Appendices B and C for typical cable schematics.

For both GBUs and RBUs, the systems are wired so all serial data goes through the PAT-SyM. The user must switch the operating mode of the PATSyM to "DAS" in the ATLAS II "GPS Data" routine (see Section 3.2.4) before programming the RBU DAS. After the DAS is programmed, return to the ATLAS II "GPS Data" routine to switch the PATSyM mode back to "GPS" for normal operation. This is necessary to permit the user to both receive GPS serial data and program the DAS with only one RS-232 cable or modem pair.

2.7.3 Ground-Based Unit Assembly

As mentioned earlier, the GBUs are custom-built for each data acquisition installation, using the standard components described above. Examples of GBUs SNL has built may be found in Appendix C. The basic procedure to be followed is contained in the follow-ing paragraphs.

The components for each GBU must be mounted in an enclosure suitable for the environment in which that GBU will be located. Keep in mind that the DAS units generate heat when operating, and that heat must be dissipated. Since the size and weight of the GBU are not usually serious issues, consider utilizing metal weatherproof boxes for all external GBUs, and mount the DAS units directly to the metal floor of the boxes. For indoor applications, mount the DAS units on metal shelves in instrumentation racks.

Additional information on KAM-500 instrumentation module operation and wiring may be found in the manuals supplied by ACRA Control with those units.

2.7.4 Rotor-Based Unit Assembly

The RBUs are also custom-built for each particular application. In general, they are built very much like the GBUs, but with the added requirements of small size and lightweight. The requirement to reduce weight has led SNL to use a waterproof SerPac R-Series case⁸ for the container. These cases are made of lightweight structural resin, are stout enough to provide a solid base for the RBU components, and withstand the weather and sunlight well. They include an integral handle, which makes them easy to transport and maneu-


⁸ Serpac Cases, 619 Commercial Ave., Covina, CA 91723

ver. However, the cases must be modified by cutting out the bottom of the case and inserting a metal mounting plate. The joint between the plate and the case must be carefully sealed to insure that the modified case weatherproof. The plate serves as a solid mounting for the DAS and other components of the RBU, provides a means of mounting the RBU to the rotor hub, and provides a good heat conduction path from the DAS into the rotor hub.

As mentioned earlier, two Digital Wireless WIT-2400 modems are used for RBU radio communications, one to handle the user-interface communications with the GPS and the DAS, and the other to transfer the PCM data stream from the DAS to the ground receiving station. The RBU assembly uses only the actual modem module shown in the lower right-hand section of Figure 2-15, without the RS-232 interface, indicator lights, and power supply that are found in a modem enclosure, as shown in the upper right-hand section of Figure 2-15. The CMOS-level signals of the PATSyM (pins 48 and 49) directly to the radio module (receive and transmit, respectively) to minimize space requirements, and to keep complexity and power consumption to a minimum. The radio modems are mounted either on the DAS unit or very close to it.

Schematics of RBUs SNL has built are included in Appendix C and photos of those units are included in Appendix F.

The receiving data modem, normally located near the master GBU, must be modified to bring the RX_CLK, the RX_DATA, and GND lines out directly from the radio module into the appropriate merger/decoder module. The ground-based RS-232 modem, on the other hand, requires no modification – it is simply attached to the system computer serial port via a standard 9-pin serial cable. The two RBU modems and the two receiving modems must be programmed before the RBU is assembled. Details of the programming may be found in Appendix G.



Failure to switch the PATSyM operating mode to "DAS" prior to attempting to program the RBU will cause the program routine to fail – it will "hang up" attempting to program the RBU. If programming takes over 10 minutes, press the "Cancel" button and wait for the routine to terminate.

Chapter 3. ATLAS II Software Description

3.1 Capabilities of the ATLAS II software

The functionality of the ATLAS II system software can be described by three major functions: programming the KAM hardware, data acquisition, and data processing (data display, conversion and archiving). These functions implement the complete test process by allowing the user to configure the system, acquire data, and analyze it. This chapter explains each of those functions in detail.

3.2 Introduction to the ATLAS II software

Launch the ATLAS II software (see Section 1.2.3 for help with the installation process). The ATLAS II Main Window, shown in Figure 3-1, will appear.

🔁 ATLAS II - System Status			_ 🗆	×
System Acquisition Recording	Utilities	<u>H</u> elp		
System Setup			Even	
Data Acquisition Status				_
Sampling Rate 0.0 Cha	annels 0	Bit Rate 0	.000E+0	
Chassis	Link	Dropouts	TSLD	
N/A	0	0	N/A	
N/A	0	0	N/A	
N/A			N/A	
N/A			N/A	
Data Recording Status				_
Conditional Setup default.drs		cording Mode	071	
File Format		ata Format		
File Duration 600 [se		Mode		
Status Data record	-			
		the set		
			exit	

Figure 3-1. ATLAS II Main Window.

ATLAS II' main widow is first and foremost a status window. A quick glance at this window allows the user to get a complete picture of the data acquisition system. Fur-

thermore, in order to enhance visibility, the information in the window is separated into three main groups: control, acquisition, and archiving.

To control the ATLAS II system the user operates the drop-down menus in the menubar, shown in Figure 3-2.

stem <u>A</u> cquisition <u>R</u> ecording <u>U</u> tilities <u>H</u> elp

Figure 3-2. Main Window's menubar.

Every command function in the program is accessed through these menus (this is the only part of the main window the user can give input to). The rest of this section is devoted to describing the options of these menus. The only function of the rest of ATLAS II' main window is to output system status information to the user.

Figure 3-3 shows the hardware system setup indicator (The figure also shows the System Events indicator which will be described later on in this section). A hardware system setup is the name given to a complete hardware description. Hardware descriptions will be studied in detail in the next section. For now, it is sufficient to know that most of the ATLAS II software's functions operate within the context of a hardware system setup. This indicator in the main window tells the user which hardware setup is the active one. If there is more than one setup active at a time, they will be separated by a semi-colon (;).

System Setup	Events

Figure 3-3. Active hardware system setup indicator.

The middle of the main window displays the Data Acquisition Status area. Figure 3-4 shows this area. This is the most prominent area of the main window and gives the user complete information on the status of the data acquisition task. The first row of this window area displays the main parameters of the active data acquisition task: sampling rate, total number of channels being acquired, total system bit rate, and activity LED (the square indicator next to the Bit Rate indicator).

Data Acquisition Status -			
Sampling Rate 0.0	Channels 0	Bit Rate 0.0	000E+0
Chassis	Link	Dropouts	TSLD
N/A			N/A

Figure 3-4. Data Acquisition Status area.

If the system is currently acquiring data, the activity LED has a green color and the word ON. If no acquisition has been started, the LED has a red color and the word OFF (shown in Figure 3-4). Whenever the activity LED is red, any information displayed in the rest of this status area that is different from that shown in Figure 3-4 is data from a previous DAQ session and does not reflect the current status of the DAQ process. Most of the time the status area will show as in Figure 3-4 when the acquisition is stopped, but there may be instances (like when the acquisition is abnormally stopped) when the last status update may be displayed after acquisition has been stopped. Therefore, the user can find out if the system is active at any time just by looking at the activity LED.

The table section of the main window displays information about the number of DAS units the software is acquiring data from. The current version of the software can communicate simultaneously with a maximum of four DAS units. Each DAS reports several parameters: Its chassis' name, link status LED, number of dropouts, and the time-since-last-dropout (TSLD). The chassis name is defined in the Hardware Configuration window (See Section 3.3 for more information on the Hardware Configuration window).

The link indicator describes whether the DAS is currently communicating (green color) or if communications have been lost (red color). The number in the center of the link indicator describes the acquisition backlog (See Section 3.6.3 for more information on Data Acquisition parameters).



The link LED is not the same as the activity LED. The link LED is only meaningful if the system is currently acquiring data. In other words, its only meaningful when the activity LED is green.

Whenever there is a communications problem (between a slave DAS and its master DAS or between a master DAS and the system computer), the link indicator will turn red. This condition is called a dropout (a data frame has been dropped or lost) and causes the drop-

outs counter to increment by one. Thus, the dropouts counter reflects the number of times there's been a communications problem with a particular chassis since the start of the acquisition session. It is possible for the dropouts counter to show a high number of dropouts even though the link indicator is a solid green. Such a condition is evidence of a big disturbance in the test system earlier in the acquisition session. The TSLD is a good indicator of when the system has encountered some problem.

The TSLD counter's sole purpose is to count how long the system (or better yet, a particular DAS) has been running error-free (in communications terms). The TSLD counter only resets when a dropout is detected, otherwise it will continue counting throughout the duration of the acquisition session. In the previous example, looking at the TSLD would help the user determine if the dropouts occurred in a short interval (one-time event) or whether they're distributed over time (indicating a systemic problem).

The bottom of the main window shown in Figure 3-5 displays the Data Recording Status area.

Data Recording Status
Conditional Setup default.drs Recording Mode
File Format Data Format
File Duration 600 [sec] File Mode
Status Data recording is disabled.

Figure 3-5. Data Recording Status area.

This section of the window displays information about ATLAS II archiving operations. Data recording has several parameters: name of the conditional-recording setup file, recording activity LED, general recording status, and several parameters describing the format of the data files. Refer to Section 3.11 "Recording (Archiving) Data" for more information on the Data Recording parameters. In this section two elements of this window will be described: the recording activity LED and the status indicator.

The recording activity LED is similar in function to the DAQ activity LED discussed previously. It tells the user whether ATLAS II is currently archiving data (green color with ON label) or not (red color with OFF label). As was the case with the data acquisition status information, the data recording status information is only meaningful when the recording activity LED is green. Whenever the activity LED is red, the status indicator will display a "Data recording is disabled." message.

When data recording is active, the status indicator will display a "Filling Buffer: ## of ## Samples." message. The ## in the message will continuously update to reflect the current data buffer being saved.

3.3 Configuring the ATLAS II software

The first step in the data acquisition task is to describe the test system to the ATLAS II software. Without this description the ATLAS II software cannot understand the data streams it receives from the DAS units in the system. To enter this information, select **System>>Configure Hardware...** from the menubar in the main window as shown in Figure 3-6. The Hardware Configuration window shown in Figure 3-7 will appear on the screen.

Figure 3-7 shows the Hardware Configuration window as it will appear for the first time. As soon as the user saves a system description (setup) file, the ATLAS II software will record the name of the setup as the last active setup. This setup will be displayed automatically the next time the Hardware Configuration window is opened.

Before we delve into the details of describing a system, it is worthwhile to introduce the concept behind the setup files. As introduced in Section 3.2, the hardware setup is the name given to a complete hardware system description. The Hardware Configuration window is the interface to the hardware system files. This window allows the user to open, create, edit, and save system files.

The active chassis area (shown in Figure 3-8), gives the user a virtual representation of a DAS chassis. Figure 3-8 shows how an empty chassis will display in the window. Again, this image will be seen only the very first time the Hardware Configuration window is accessed. For comparison, Figure 3-9 shows how this window looks for an empty (only an encoder DAM is present in the chassis) 6-slot chassis. If Figure 3-9 is compared to Figure 2-1, the resemblance between the top view of a KAM chassis and the active chassis area in the Hardware Configuration window can be seen. This resemblance is designed to make it more intuitive to use the software. Furthermore, it allows the user to quickly make an association between the ATLAS II hardware, its physical connections and their respective signals within the software.

🔁 ATLAS II - System Status			_	
		<u>H</u> elp		
Configure <u>H</u> ardware	Ctrl+C		E	ents
Configure Data Processing	Ctrl+P			_
Configure System Events Enable System Events Disable System Events	Ctrl+E Ctrl+N Ctrl+M	Bit Rate 0.1 Dropouts	DOOE+0	-1
E <u>x</u> it	Ctrl+W		N/A	
N/A		0	N/A	
N/A	0	0	N/A	
N/A	0	0	N/A	
Data Recording Status		Г		
Conditional Setup default.drs		cording Mode		277
File Format	Da	ta Format		
File Duration 600 [sec	:) File N	1ode		
Status Data recordi	ng is disabl	ed.		
			exit	

Figure 3-6. Configuring the ATLAS II software.




Figure 3-7. Hardware Configuration window.

Notice that the "Current Chassis" drop-down-list control in Figure 3-9 shows a "chassis_0" label instead of the "Select a Chassis" text shown in Figure 3-8. The function of this control is to allow the user to view all chassis in a multiple-chassis setup. When the control displays the "Select a Chassis" text, the window is not displaying any setup. Once a setup is loaded or created, its first (or only) chassis will be displayed and the "Current Chassis" control will change to list that chassis' name. If the user wants to display the configuration of another chassis in the setup, just left-click on the chassis name and select the desired chassis from the list to display.




Figure 3-8. Active Chassis area.




Figure 3-9. Active Chassis area showing empty 6-slot chassis.

When the user selects a chassis in the drop-down-list control, the area below the control (chassis display area) changes automatically to reflect the specified chassis' size (number of slots) and its configuration. Each slot in the chassis is labeled with a "J-slot" number, just as in the actual hardware. Next to the slot number, a description tells what type of data acquisition module (DAM) is installed into that slot. If there's no DAM in a particular slot, the text "EMPTY/SPARE" will be displayed.

In order to acquire data from different types of sensors (voltages, strains, pulse, etc.), the ATLAS II system supports the use of DAMs. Each DAM is designed to digitize a specific type of signal efficiently. To select what DAM to "install" in a chassis slot, just right-click in the appropriate slot label in the chassis display area. A context menu will appear giving the user the option to select what type of DAM will be in that slot. Figure 3-10 shows the DAM context menu.

Whenever a different DAM is selected (other than the current one) in the context menu, ATLAS II will ask the user to confirm the change before implementing it. As soon as the change is confirmed, the active module area will change to display the parameters for the newly added DAM. To manage the configuration of a DAM, the user must work in the active module area.

ATLAS II - Editing "demo" Con Setup Chassis Frame	nfiguration			
Current Chassis chassis_0	iin Gauge jer/Decoder ete Input der der (R5232)			
				Done Cancel

Figure 3-10. Configuration window showing DAM context menu.

The active module area (shown in Figure 3-11) shows a virtual representation of a DAM. Figure 3-11 shows how an "EMPTY/SPARE" chassis slot will be displayed in the window. For comparison, Figure 3-12 shows how this window looks for a discrete input (DSI/2) DAM. We will describe the view for each of the supported DAM types in the next section.



Figure 3-11. Active module area of the Hardware Configuration window.

Figure 3-12. Active module showing DSI/2 DAM parameters.

If the user wants to look at the active configuration for the DAM in another slot, just leftclick its slot label in the chassis display area. The active module area of the window will immediately change to display the parameters for the DAM in that slot.

Below is a list of the important parameter of the Hardware Configuration window:

- The "Current Chassis" control allows the user to specify a particular chassis within a hardware setup.
- The chassis display just below the "Current Chassis" control gives the user a complete picture of the size and contents of a chassis.
- Left-clicking on the slot label in the chassis display area will cause the ATLAS II software to display the active configuration for that slot in the DAM.
- Right-clicking on the slot label in the chassis display area will enable the user to change the DAM installed in that slot.
- The active module area lets the user manage each of the parameters associated with each of the DAMs installed in the "Current Chassis".

3.3.1 Creating a hardware setup

To create a hardware setup, select **Setup>>New** from the menubar in the Hardware Configuration window as shown in Figure 3-13. ATLAS II will then prompt the user for the name of the new setup as shown in Figure 3-14. Names for ATLAS II setups are limited to eight (8) characters and cannot include spaces. If a space is typed in the setup name field, ATLAS II will immediately replace it with an underscore () character. Furthermore, if the setup name is longer than eight characters, ATLAS II will truncate it to the first eight characters.

Notice in Figure 3-14 that a path to the folder where the setup will be stored cannot be specified. ATLAS II automatically saves all system configuration files to the "configurations" folder. The "configurations" folder is created during the installation of ATLAS II and is located in the same folder ATLAS II was installed.




Figure 3-13. Creating a hardware setup.

ATLAS II - Create Setup 🛛 🔀
– System Identifier
Specify Name demo
OK Cancel

Figure 3-14. Enter a name for the new hardware setup.

By default, every time a setup is created, ATLAS II will give it a basic configuration that includes the following parameters:

- 1. Only one chassis in the setup. The chassis is called "chassis_0".
- 2. An encoder DAM (part KAM/ENC/003) is put in slot J2. The encoder has the following configuration:
 - a. Set encoder to be a slave unit.
 - b. Encoder name is "chassis_0_J2_enc".
 - c. Define one signal to be generated by the encoder. The signal is called "chassis_0_J2_enc_0" and outputs a fixed value of zero (0).
- 3. The setup will sample the signals at 30 Hz and encode the PCM data stream using the NRZ-L format.

This is the most basic configuration an ATLAS II setup can have: one chassis with an encoder in its first slot. If the DAS unit being configured is a stand-alone unit or a master in a master/slave system, uncheck the box in the active module area labeled "**Slave**". Next, click the "**Save Changes**" button in the active module area. The setup is now complete. Figure 3-15 shows how the Hardware Configuration window will look.

🔁 ATLAS II - Editing "demo" Configuration	X
Setup Chassis Frame	
Current Chassis Current Module	
chassis_0 Name chassis_0_12_enc 32 Slave	
32 KAM/ENC/003 - Tx Signal Name Bits Value	
J3 EMPTY/SPARE ✓ chassis_0_J2_enc_0 16 0	
34 EMPTY/SPARE 35 EMPTY/SPARE 16 0	
37 EMPTY/SPARE 16 d 0	
J8 EMPTY/SPARE	
16 d 0	
Save Changes Cancel	
Done	ancel

Figure 3-15. A basic ATLAS II setup.

Notice that the text in the title bar of the Hardware Configuration window changes to display the name of the setup being edited, in this case "demo".

Now that a basic setup has been created, the next sections will describe all the configuration parameters available with the different DAMs supported by ATLAS II. This will let the user create ATLAS II systems with high degrees of sophistication.

3.3.2 Configuring ATLAS II DAMs

As of this release ATLAS II includes support for the following data acquisition modules (DAMs):

- 1. KAM/ENC/003: encoder/controller module with RS-422 programming interface.
- 2. KAM/ENC/007: encoder/ controller module with RS-232 programming interface.
- 3. KAM/DEC/002: 2-channel merger/decoder module.
- 4. KAM/ADC/005: 8-channel differential analog to digital converter with signal conditioning.
- 5. KAM/ADC/009/S2: 8-channel bridge analog to digital converter with excitation, sense and signal conditioning.
- 6. KAM/DSI/002: 24-channel discrete input module with counters.
- 7. GPS/001: GPS receiver/timing reference module.

The rest of this section describes each module in detail. In the discussion, every time that a name is specified (for example for a Module Name or a Signal Name), ATLAS II will allow the user to enter up to 25 characters. The limit is not specific because the maximum number of characters that can be displayed will depend on system settings such as the type and attributes of the active system font.

3.3.2.1 KAM/ENC/003 - Encoder module parameters

The KAM/ENC/003 is the brains of every DAS unit. Its job is to build the PCM data stream using the just-acquired samples from all of the DAMs in a DAS' chassis. Data cannot be acquired from a DAS unit and none of the installed DAMs can be programmed if a KAM/ENC/003 is not installed in the DAS unit. KAM/ENC/003 DAMs can only be installed in a chassis on the J2 slot. Furthermore, no other DAM (other than encoder DAMs) can be installed in the chassis' J2 slot.

Figure 3-16 shows the active module area of the Hardware Configuration window when configuring a KAM/ENC/003 module. The parameters available for configuration in this window are:

• Name – Name used by ATLAS II to identify this module as a signal source. The user can specify any name. Do not use spaces in the name (if spaces are used, ATLAS II will replace them with underscore (_) characters).

- Slave attribute If this flag is set the chassis in which this encoder resides will be configured as a slave chassis (needs clock reference). Otherwise, the chassis is considered a master chassis (outputs clock reference).
- **Transmitted signal (Tx)** This flag specifies whether or not the signal to which it corresponds will be acquired and transmitted in the PCM stream. Leave the flag unchecked to remove a signal from acquisition, but keep its configuration in place for possible future use.
- Signal Name Name given to a data word. This is the name that ATLAS II will use whenever data from this signal is plotted, analyzed, and stored.
- **Bits** The number of bits used to digitize a data word. By default, all ATLAS II signals are 16-bit signals. However, the user can specify any bit-length in the range 4 to 16 bits.
- Value Encoder data words are always fixed-value signals. The value specified for this control is the value that will be digitized for every sample. In Figure 3-16, a small letter in the left border of the value control can be seen. This is actually a control that lets the user select the *format* of the value displayed. The format options are: Decimal, Hexadecimal, Octal, Binary and SI notation. Left-click on the small letter and a pop-up menu will appear, giving the user the option to select the format to use. The same format will be applied to all of the signals from the same DAM.

🔁 ATLAS II - Editing "demo" Co	onfiguration	×
Setup Chassis Frame		
Current Chassis	Current Module	
chassis_0 💌	Name chassis_0_J2_enc J2 Slave	
J2 KAM/ENC/003 -	Tx Signal Name Bits Value	
J3 EMPTY/SPARE J4 EMPTY/SPARE	✓ chassis_0_32_enc_0 16 d 0	
J5 EMPTY/SPARE	16 d O	
J6 EMPTY/SPARE		
J7 EMPTY/SPARE		
J8 EMPTY/SPARE		
	16 d 0	
	16 d 0	
	16 d 0	
	Save Changes Cancel	
	Done	Cancel

Figure 3-16. Configuring a KAM/ENC/003 module.

Once all encoder signal(s) have been setup, click the **"Save Changes"** button. If a DAM window is closed without saving changes, all setting changes since the last save will be lost. If the previous DAM configuration is needed, click the **"Cancel"** button.

Do not worry about the signal definition areas that are not defined (empty). ATLAS II will not acquire or transmit any signal that has either an unchecked Transmit (Tx) flag or one that has an empty name string.

3.3.2.2 KAM/ENC/007 - RS-232 Encoder module parameters

If the user needs to build an ATLAS II system in which communications are restricted to low-bandwidth links, the KAM/ENC/003 cannot be used. The KAM/ENC/003 communicates with the KAM hardware at a rate of 1 Mb/s when programming the hardware. In those cases, the KAM/ENC/007 is the alternative. Its only difference from the KAM/ENC/003 is its use of the RS-232 standard for the programming link to the system computer. In every other respect (including data transfer), the KAM/ENC/003 and the KAM/ENC/007 are identical.

Figure 3-17 shows the active module area of the Hardware Configuration window when configuring a KAM/ENC/007 module. The parameters available for configuring this module are the same as those used for setting up the KAM/ENC/003 (described in the previous section), with one exception. For this reason, in this section we'll only describe that additional parameter. Refer to Section 3.3.2.1 for a description of the other parameters. The additional parameter available when setting up a KAM/ENC/007 is the following:

• **COMM Port** – The comm (RS-232) port refers to the serial communication port in the computer that will be used to communicate with the chassis. The user does not have to worry about the settings for the port as ATLAS II handles it automatically.

E ATLAS II - Editing "demo" Configuration	×
Setup Chassis Frame	
Current Chassis Current Module	
chassis_0 Name chassis_0_12_enc J2 Slave 2 COMM Port	
J2 KAM/ENC/007 - Tx Signal Name Bits Value	
J3 EMPTY/SPARE Chassis_0_12_enc_0 16	
J4 EMPTY/SPARE J5 EMPTY/SPARE I6 0	
16 EMPTY/SPADE	
37 EMPTY/SPARE 16 0	
16 d 0	
16 d 0	
16 d 0	
16 d 0	
16 d 0	
Save Changes Cancel	
Done Can	:el

Figure 3-17. Configuring a KAM/ENC/007 module.

Once all encoder signal(s) have been setup, click the **"Save Changes"** button. If the display of a DAM is closed without saving changes, all setting changes since the last save will be lost. If the previous DAM configuration is needed, click the **"Cancel"** button.

Do not worry about the signal definition areas that are not defined (empty). ATLAS II will not acquire or transmit any signal that has either an unchecked Tx flag or one that has an empty name string.

3.3.2.3 KAM/DEC/002 - Merger/Decoder module parameters

If the ATLAS II hardware setup includes at least one slave unit, a KAM/DEC/002 DAM must be used. Each of these modules will merge the PCM stream from up to two slave DAS units into the PCM stream of the master DAS unit. Make sure that the KAM/DEC/002 DAM(s) is(are) installed in the slot(s) right next to the encoder in the master chassis (think of them as an extension to the encoder DAM).

Figure 3-18 shows the active module area of the Hardware Configuration window when configuring a KAM/DEC/002 module. The parameters available for configuration in this window are:

• Name – Name used by ATLAS II to identify this module as a signal source. The user can specify any name. Do not use spaces in the name (if spaces are used ATLAS II will replace them with underscore (_) characters).

- **Transmitted signal (Tx)** This flag specifies whether or not the signal to which it corresponds will be acquired and transmitted in the PCM stream. Leave the flag unchecked to remove a signal from acquisition, but keep its configuration in place for possible future use.
- **Channel** Every KAM/DEC/002 module can merge the PCM data stream of two different slave DAS units. This control lets the user specify what slave unit is wired to each of the input channels of the merger module.
- Signal Name Name given to a data word. This is the name that ATLAS II will use whenever data from this signal is plotted, analyzed, and stored.
- **Bits** The number of bits used to digitize a data word. By default, all ATLAS II signals are 16-bit signals. However, the user can specify any bit-length in the range 4 to 16 bits.
- Chassis The name of the slave chassis whose data stream is being merged.
- **Encoder** The name of the encoder in the slave chassis whose data stream is being merged.

🔁 ATLA	AS II - Editing "demo" Cor	nfiguration						×
<u>S</u> etup	⊆hassis Fr॒ame							
	Current Chassis	Current Module						
	chassis_0 💽	Name chassis_0_32	2_dec J2					
J2	KAM/DEC/002 -	Tx Channel	Signal Name	Bits	Chassis	Encoder		
J3	EMPTY/SPARE	V O v chas	ssis_0_J2_dec_0	16			_	
34	EMPTY/SPARE		sis_0_J2_dec_1	16			_	
J5 J6	EMPTY/SPARE EMPTY/SPARE		ssis_U_J2_dec_1	16				
37	EMPTY/SPARE							
38	EMPTY/SPARE							
		Save Changes	Cancel					
							Done	Capital
							Done	Cancel

Figure 3-18. Configuring a KAM/DEC/002 module.

When the KAM/DEC/002's signal is sampled, only one value of interest will be displayed: 4096. The value of a KAM/DEC/002's signal is a status code showing the status of the communications link to a slave unit. A value other than from 4096 (typically a value of zero) tells the user that there is a problem in the link between the master and slave DAS units. Whenever this is the case, the data words received from the slave unit should be considered "bad" data and thus discarded. Once the merger/decoder signal(s) have been setup, click the **"Save Changes"** button. If the DAM display is closed without saving changes, all setting changes since the last save will be lost. If the previous DAM configuration is needed, click the **"Cancel"** button.

Do not worry about the signal definition areas that are not defined (empty). ATLAS II will not acquire or transmit any signal that has either an unchecked Tx flag or one that has an empty name string.

3.3.2.4 KAM/ADC/005 - Analog input module parameters

The KAM/ADC/005 is the most widely used DAM in a typical ATLAS II system. It is a generic analog-to-digital converter module with integrated signal conditioning. Its versatility is due for the most part to its amplification and filtering capabilities. The KAM/ADC/005 can capture signals with amplitudes from millivolts to 10 Volts. Moreover, it uses digital filters to produce highly accurate, non-distorted samples.

🔁 ATL	AS II - Editing "demo" Cor	figuration	×
<u>S</u> etup	⊆hassis F <u>r</u> ame		
	Current Chassis	Current Module	
	chassis_0 🗸	Name chassis_0_J2_analog J2	
32	KAM/ADC/005 -	Tx Channel Signal Name Bits Max	Min Filter Cutoff
J3 J4	EMPTY/SPARE EMPTY/SPARE	▼ 0 ▼ chassis_0_32_analog_0 16 10.000	0 -9.995 Fs/4 🗸
35	EMPTY/SPARE	▼ 1 - chassis_0_J2_analog_1 16 10.000	0 -9.995 Fs/4 💌
J6	EMPTY/SPARE	✓ 2 v chassis_0_J2_analog_2 16 10,000	0 -9.995 Fs/4 V
37	EMPTY/SPARE		
38	EMPTY/SPARE	✓ 3 _ chassis_0_J2_analog_3 16 10.000	0 -9.995 Fs/4 🗸
		✓ 4 chassis_0_J2_analog_4 16 10.000	0 -9.995 Fs/4 💌
		▼ 5 ▼ chassis_0_J2_analog_5 16 10.000	0 -9.995 Fs/4 🗸
		✓ 6 ✓ chassis_0_J2_analog_6 16 10.000	0 -9.995 Fs/4 💌
		7 chassis_0_32_analog_7 16 10.000	0 -9.995 Fs/4 🔽
		Save Changes Cancel Set all like fi	first signal
			Done Cancel

Figure 3-19. Configuring a KAM/ADC/005 module.

Figure 3-19 shows the active module area of the Hardware Configuration window when configuring a KAM/ADC/005 module. The parameters available for configuration in this window are:

• Name – Name used by ATLAS II to identify this module as a signal source. The user can specify any name (up to 25 characters). Do not use spaces in the name (if spaces are used, ATLAS II will replace them with underscore (_) characters).

- **Transmitted signal (Tx)** This flag specifies whether or not the signal to which it corresponds will be acquired and transmitted in the PCM stream. Leave the flag unchecked to remove a signal from acquisition, but keep its configuration in place for possible future use.
- **Channel** Each KAM/ADC/005 can sample up to eight (8) different signals. This control lets the user specify which physical channel in the DAM is receiving a given signal.
- **Signal Name** Name given to a data word. This is the name that ATLAS II will use whenever data from this signal is plotted, analyzed, and stored.
- **Bits** The number of bits used to digitize a data word. By default, all ATLAS II signals are 16-bit signals. However, the user can specify any bit-length in the range 4 to 16 bits.
- Max This control specifies the maximum input value (in Volts) that will be present at the KAM/ADC/005's input terminals for a given signal. The maximum acceptable value is 10.0V. If the user specifies anything larger than 10V, ATLAS II will limit the input to 10V.
- Min This control specifies the minimum input value (in Volts) that will be present at the KAM/ADC/005's input terminals for a given signal. The minimum acceptable value is –9.995V. If the user specifies anything smaller than –9.995V, ATLAS II will limit the input to –9.995V.
- Filter Cutoff Drop-down control that lets the user specify the 3dB point of a given signal's digital filter. The frequency is expressed as a multiple of the sampling frequency (Fs). This setting will also determine the magnitude of the time delay associated with the filtering operation. That delay is governed by the following relationship:

 $T_d = 13/Fc$, where Fc is the filter cutoff frequency.

For example, if a filter cutoff frequency of Fs/4 is specified for a signal that's been sampled at 30 Hz, expect a time delay of approximately 1.73 seconds.

To simplify setting up a KAM/ADC/005 DAM, ATLAS II includes the **"Set all like first signal"** button. As its name implies, clicking this button will set all of the parameters for all of the active DAM's signals to those set for the first signal. The signal name parameter will also be copied, but a "_#" (where # will be replaced by the signal's channel number) will be appended to every name that's created.

Once all analog signal(s) have been setup, click the **"Save Changes"** button. If the DAM display is closed without saving changes, all settings changes since the last save will be lost. If the previous DAM configuration is needed, click the **"Cancel"** button.

Do not worry about the signal definition areas that are not defined (empty). ATLAS II will not acquire or transmit any signal that has either an unchecked Tx flag or one that has an empty name string.

3.3.2.5 KAM/ADC/009/S2 - Bridge analog input module parameters

The KAM/ADC/009 includes eight channels of bridge analog-to-digital converters. It is designed to be used with strain gauge sensors, but can be used with other asymmetric bridge transducers (accelerometers, pressure transducers, etc.) as long as re-calibration is carried out on a channel by channel basis.

🔁 ATLA	S II - Editing "demo" Co	nfiguration		×
Setup 🤇	Ihassis Frame			
	Current Chassis	Current Module		
	chassis_0 🗾	Name chassis_0_J2_strain J2		
32	KAM/ADC/009 -	Tx Channel Signal Name	Bits Max Min Filter Cutoff ExVolt ExOffset	
33 34	EMPTY/SPARE EMPTY/SPARE	♥ 0 ▪ chassis_0_J2_strain_0	16 10.000 -9.995 Fs/4 🔹 5.100 0.000	
35	EMPTY/SPARE	V 1 chassis_0_J2_strain_1	16 10.000 -9.995 Fs/4 - 5.100 0.000	
36	EMPTY/SPARE	2 chassis_0_J2_strain_2	16 10.000 -9.995 Fs/4 V 5.100 0.000	
37 38	EMPTY/SPARE EMPTY/SPARE	✓ 3	16 10.000 -9.995 Fs/4 V 5.100 0.000	
3 <u>-</u> 1-		4 chassis_0_J2_strain_4	16 10.000 -9.995 Fs/4 - 5.100 0.000	
		▼ 5 ▼ chassis_0_J2_strain_5	16 10.000 -9.995 Fs/4 💌 5.100 0.000	
		6 chassis_0_32_strain_6	16 10.000 -9.995 Fs/4 • 5.100 0.000	
		7 chassis_0_32_strain_7	16 10.000 -9.995 Fs/4 💌 5.100 0.000	
		Save Changes Cancel	Set all like first signal	
				Done Cancel

Figure 3-20. Configuring a KAM/ADC/009 module.

Figure 3-20 shows the active module area of the Hardware Configuration window when configuring a KAM/ADC/009 module. The parameters available for configuration in this window are:

- Name Name used by ATLAS II to identify this module as a signal source. The user can specify any name (up to 25 characters). Do not use spaces in the name (if spaces are used, ATLAS II will replace them with underscore (_) characters).
- **Transmitted signal (Tx)** This flag specifies whether or not the signal to which it corresponds will be acquired and transmitted in the PCM stream. Leave the

flag unchecked to remove a signal from acquisition, but keep its configuration in place for possible future use.

- **Channel** Each KAM/ADC/009 can sample up to eight (8) different signals. This control lets the user specify which physical channel in the DAM is receiving a given signal.
- **Signal Name** Name given to a data word. This is the name that ATLAS II will use whenever data from this signal is plotted, analyzed, and stored.
- **Bits** The number of bits used to digitize a data word. By default, all ATLAS II signals are 16-bit signals. However, the user can specify any bit-length in the range 4 to 16 bits.
- Max This control specifies the maximum input value (in Volts) that will be present at the KAM/ADC/009's input terminals for a given signal. The maximum acceptable value is 10.0V. If a value larger than 10V is specified, ATLAS II will limit the input to 10V. For sampling strain gauge transducers, a setting of 0.010 V will typically provide the best dynamic range and resolution.
- Min This control specifies the minimum input value (in Volts) that will be present at the KAM/ADC/009's input terminals for a given signal. The minimum acceptable value is –9.995V. If a value smaller than –9.995V is specified, ATLAS II will limit the input to –9.995V.
- Filter Cutoff Drop-down control that lets the user specify the 3dB point of a given signal's digital filter. The frequency is expressed as a multiple of the sampling frequency (Fs). This setting will also determine the magnitude of the time delay associated with the filtering operation. That delay is governed by the following relationship:

 $T_d = 13/Fc$, where Fc is the filter cutoff frequency.

For example, if a filter cutoff of Fs/4 is selected for a signal that's been sampled at 30 Hz, a time delay of approximately 1.73 seconds can be expected.

- **ExVolt** Specifies the voltage across half-bridge. A value of 2.5V will result in a voltage of 5V being present across the bridge. This parameter has a range of 5.1V to 0.0V. If a value outside that range is specified, ATLAS II will limit the input to force it within range.
- **ExOffset** Specifies a voltage to be added to the excitation voltage (ExVolt) to balance a given signal's bridge. This parameter has a range of 2.5V to –2.5V. If a value outside that range is specified, ATLAS II will limit the input to force it within range.

To simplify setting up a KAM/ADC/009 DAM, ATLAS II includes the **"Set all like first signal"** button. As its name implies, clicking this button will set all of the parameters for all of the active DAM's signals to those set for the first signal. The signal name parameter will also be copied, but a "_#" (where # will be replaced by the signal's channel number) will be appended to every name that's created.

Once all bridge signal(s) have been setup, click the **"Save Changes"** button. If the DAM display is closed without saving changes, all setting changes since the last save will be lost. If the previous DAM configuration is needed, click the **"Cancel"** button.

Do not worry about the signal definition areas that are not defined (empty). ATLAS II will not acquire or transmit any signal that has either an unchecked Tx flag or one that has an empty name string.

3.3.2.6 KAM/DSI/002 - Discrete input module parameters

The KAM/DSI/002 is used to monitor the status (high/low) of up to 24 differential-ended discrete channels. The first eight (8) channels have alternate functions as programmable counters. When the inputs are used as a status word (instead of as a counter), the data sampled from a KAM/DSI/002 is typically read as two 12-bit words.

Figure 3-21 shows how the active module area of the Hardware Configuration window looks when configuring a KAM/DSI/002 module. The parameters available for configuration in this window are:

- Name Name used by ATLAS II to identify this module as a signal source. The user can specify any name (up to 25 characters). Do not use spaces in the name (if spaces are used, ATLAS II will replace them with underscore (_) characters).
- **Transmitted signal (Tx)** This flag specifies whether or not the signal to which it corresponds will be acquired and transmitted in the PCM stream. Leave the flag unchecked to remove a signal from acquisition, but keep its configuration in place for possible future use.

Current Chassis	Current Module						
chassis_0	Name chassis_0_J2_digit	al J2					
KAM/DSI/002		Signal Name	Bits	Туре	Edge	Period	ThresholdVoltage
EMPTY/SPARE		chassis_0_J2_digital_0	16	N/A	▼ N/A	• N/A •	Pins 0-5 1.50
EMPTY/SPARE EMPTY/SPARE		chassis_0_J2_digital_1	16	N/A	• N/A	▼ N/A ▼	Pins 6-11 1.50
EMPTY/SPARE EMPTY/SPARE	Counter 2 🗸	chassis_0_J2_digital_2	16	N/A	N/A	• N/A •	Pins 12-17 1.50
EMPTY/SPARE		chassis_0_J2_digital_3	16	N/A	• N/A	• N/A •	Pins 18-23 1.50
	Counter_4	chassis_0_J2_digital_4	16	N/A	N/A	• N/A •	
	Counter_5 💽	chassis_0_J2_digital_5	16	N/A	N/A	• N/A •	
	Counter_6	chassis_0_J2_digital_6	16	N/A	• N/A	• N/A •	
	Counter_7	chassis_0_J2_digital_7	16	N/A	▼ N/A	▼ N/A ▼	
	Save Changes Can	cel 📔	Set all	like first sig	nal		-

Figure 3-21. Configuring a KAM/DSI/002 module.

- **Channel** The KAM/DSI/002 can be programmed to work in one of two modes: logic monitor or counter. This control lets the user specify what mode to use for a given signal. Figure 3-21 shows how to select each of the eight counters. The selections "Status_11_0" and "Status_Lo" are interchangeable and let ATLAS II know to sample the first group of 12 twelve channels as logic monitors. The selections "Status_23_12" and "Status_Hi" have the same meaning, but referring to the second group of 12 channels in the DAM.
- **Signal Name** Name given to a data word. This is the name that ATLAS II will use whenever data from this signal is plotted, analyzed, and stored.
- **Bits** The number of bits used to digitize a data word. By default, all ATLAS II signals are 16-bit signals. However, the user can specify any bit-length in the range 4 to 16 bits.
- **Type** When a channel is configured as a counter, this control lets the user specify what type of counter to use. When a channel is configured as a logic monitor, this parameter is ignored. The counter type options are:
 - *Frequency* This mode counts the number of events in a defined clock period.
 - *Period* This mode counts the number of clock periods between events.
 - Event Since This mode counts the number of events between samples.

- *Elapsed* This mode counts the number of defined clock periods between samples.
- *Count* This mode counts the number of events since power-up, updating on sample. It will rollover to zero (0) on the next count after 65,535.
- *Timer* This mode counts the total number of defined clock periods since the last event occurred. It is updated every sample.
- *Read* This mode counts the total number of samples since power-up. It will rollover to zero (0) on the next count after 65,535.
- \circ *Event* This mode counts the number of samples between events, updating upon sample. It resets to one (1) when a new event is detected.
- Edge The edge (of a square wave), which is considered an event. The options are: Rising and Falling.
- **Period** The length of a "tick" being counted. This parameter is very important in the setup the DSI/002 DAM. The DSI/002 will sample a counter once every period interval. This means that the user must be very careful when setting the *period* value so that the DAM always returns meaningful data. For example, if the frequency of a signal is to be measured, the period parameter must be set high enough to give the DAM time to detect at least a couple of transitions of the source signal. If the period is set too low, the DAM will not detect enough pulse transitions in the sampling period to calculate the correct signal frequency.

The counts value in a DSI/002's counter is updated every *period* seconds regardless of the system's sampling rate. If the system is sampling faster than the period interval, it will just read the same value until the DAM updates the counter again.

• ThresholdVoltage – This parameter specifies the actual voltage applied to determine whether the channel is at logic level "1" or "0". This parameter is specified for groups of four channels. A voltage within the range ±7.5Vcan be specified. If a value is specified outside that range, ATLAS II will limit the input to keep it within range.

To simplify setting up a KAM/DSI/002 DAM, ATLAS II includes the **"Set all like first signal"** button. As its name implies, clicking this button will set all of the parameters (including ThresholdVoltage) for all of the active DAM's signals to those set for the first signal. The signal name parameter will also be copied, but a "_#" (where # will be replaced by the signal's channel number) will be appended to every name that's created.

Once all bridge signal(s) have been setup, click the **"Save Changes"** button. If the DAM display is closed without saving changes, all setting changes since the last save will be lost. If the previous DAM configuration is needed, click the **"Cancel"** button.

Do not worry about the signal definition areas that are not defined (empty). ATLAS II will not acquire or transmit any signal that has either an unchecked Tx flag or one that has an empty name string.

3.3.2.7 GPS/001 - GPS receiver/timing reference module parameters

Unlike all other DAMs, ACRA Control does not manufacture the GPS/001 module. Currently, Sandia National Laboratories' Wind Energy Group manufactures this DAM. What sets this DAM apart from the others is that it is designed to work both as the timing source for a chassis and as a data acquisition DAM.

The GPS/001 accepts GPS signals from the GPS receiver in the DAS unit. It uses these signals to generate an acquisition clock that controls every sampling period in the DAS. Furthermore, the GPS/0001 takes care of keeping this sampling clock synchronized to the GPS source. The synchronization of the clocks to the GPS source (±microseconds) will continue for as long as the DAS unit is operational.

Even though using the GPS/001 as a timing source is what gives ATLAS II its name and separates it from other data acquisition systems, a GPS/001 DAM can be used in a DAS unit exclusively as a data acquisition module if its timing signals are not connected to the DAS' encoder. In this configuration the GPS/001 can still output timing information that can be included in the data stream. However, the DAS will be using its internal clock for controlling the sampling operations of all the DAMs in the DAS.

Figure 3-22 shows the active module area of the Hardware Configuration window when configuring a KAM/GPS/001 module. The parameters available for configuration in this window are:

- Name Name used by ATLAS II to identify this module as a signal source. The user can specify any name. Do not use spaces in the name (if spaces are used, ATLAS II will replace them with underscore (_) characters).
- **Transmitted signal (Tx)** This flag specifies whether or not the signal to which it corresponds will be acquired and transmitted in the PCM stream. Leave the flag unchecked to remove a signal from acquisition, but keep its configuration in place for possible future use.

Current Chassis	Current Module			
chassis_0	Name chassis_0_32_patsym T× Signal Name	J2 e Bits		
EMPTY/SPARE EMPTY/SPARE	chassis_0_J2_GP5_Hour		NOTE: Set the sampling frequency for the system BEFORE saving this module's data. The frequency is required to	
EMPTY/SPARE	chassis_0_J2_GP5_Seco	onds 16	correctly setup this module.	
EMPTY/SPARE EMPTY/SPARE	chassis_0_J2_GPS_Micro	oseconds 16		
EMPTY/SPARE	chassis_0_J2_GPS_Mon	th-Day 16		
	chassis_0_J2_GP5_Year	16		
	Save Changes Cancel	1		

Figure 3-22. Configuring a KAM/GPS/001 module.

- **Signal Name** Name given to a data word. This is the name that ATLAS II will use whenever data from this signal is plotted, analyzed, and stored. Unlike all other DAM's signals, GPS/001 signals have pre-defined names. The user cannot change the name of any of the GPS/001's signals.
- **Bits** The number of bits used to digitize a data word. By default, all ATLAS II signals are 16-bit signals. GPS/001 signals have pre-defined bit-lengths. The bit-length cannot be changed for any of the GPS/001's signals.

Notice in Figure 3-22 that there's a warning about configuring a GPS/0001 DAM. Because this DAM can be used to control the system's sampling rate, the user must be aware of that rate's current value at the time the GPS/001 is configured. ATLAS II will use the current system's sampling rate to program the GPS/001. If the GPS/001 DAM is configured and later on the system's sampling rate is changed, the user must go back to the GPS/001's configuration window and re-save its settings. There's no need to change any parameters in the window itself because the change is internal to ATLAS II, the save simply forces the software to perform an update.

Once all GPS signal(s) have been setup, click the **"Save Changes"** button. If the DAM display is closed without saving changes, all setting changes since the last save will be lost. If the previous DAM configuration is needed, click the **"Cancel"** button.

3.3.3 Configuring Frame Parameters

Now that a setup can be created using any of the supported DAMs, the data-frame parameters can be described. As discussed in Section 1.1 "Overview of the ATLAS II Hardware", all of the data acquired by the system is transferred to the system computer in a PCM data stream. This stream consists of the continuous generation of data frames by a master DAS and their corresponding acquisition, in real time, by the system computer.

The format of a data frame is mostly defined by a setup's configuration. All signals in a DAM are placed in the frame in the order they're shown in the DAM's configuration window. All DAMs in a chassis are placed in the frame in the order they are installed in a chassis (ascending slot number). Finally, all chassis in a setup are placed in the frame in the order they show up in the setup.

The remaining frame parameters are defined in a separate window. To get to this window select **Frame>>Edit Frame Properties** from the menubar in the Hardware Configuration window as shown in Figure 3-23. The Frame Properties window, shown in Figure 3-24, will pop up.

E ATLA	S II - Editing "demo" Co	nfiguration				×
Setup (<u>Chassis</u> F <u>r</u> ame					
	Curr					
	C Show Signal Defi	inition Ctrl+Z	_J2_patsym J2			
32	KAM/GP5/001 -	Τ×	Signal Name	Bits		
33 34	EMPTY/SPARE EMPTY/SPARE	Chassis_0	J2_GPS_Hour-Min	16	NOTE: Set the sampling frequency for the system BEFORE saving this module's data. The frequency is required to	
J5	EMPTY/SPARE	chassis_0	J2_GPS_Seconds	16	correctly setup this module.	
36	EMPTY/SPARE	✓ chassis_0	J2_GP5_Microseconds	16		
37	EMPTY/SPARE					
38	EMPTY/SPARE		_J2_GPS_Month-Day	16		
		chassis_0	_J2_GP5_Year	16		
		1				
		Save Changes	Cancel			
					Do	ne Cancel

Figure 3-23. Opening the Frame Properties window.

ATLAS II - Frame Properties
Wire Protocol
PCM Code NRZ-L 💌
Invert DCLK 🔽 Invert PCM 🗖
Synchronization Strategy
Sampling Rate 30,000E+0
Frame Words 7
Frame Bits 128
Baudrate 3.840E+3
Actual Sample Rate 29.9976
Apply Reset Done

Figure 3-24. Frame Properties window.

The Frame Properties window is separated into two sections: wire protocol and synchronization strategy.

The wire protocol section lets the user specify the protocols that define the electrical characteristics of data transmission. The parameters available for configuration are:

- **PCM Code** This parameter determines how to encode a binary state (one or zero) in the electrical signal. A complete discussion of these formats is an extensive topic and therefore beyond the scope of this manual. For reference purposes, all available options are listed below:
 - o NRZ-L: Non Return to Zero Low
 - BIØ-L: Bi-Æ Low
 - RZ: Return to Zero
 - o NRZ-M: Non Return to Zero Mark
 - NRZ-S: Non Return to Zero Space
 - DBIØ –S: Dual Bi-Æ Space

- DBIØ-M: Dual Bi-Æ Mark
- BIØ-M: Bi-Æ Mark
- BIØ-S: Bi-Æ Space
- DM-M: Delay Modulation Mark (Miller code)
- DM-S: Delay Modulation Space (Miller code)
- RNRZ-L-(11): 11-bit Random Non Return to Zero
- RNRZ-L-(13): 13-bit Random Non Return to Zero
- RNRZ-L-(15): 15-bit Random Non Return to Zero
- RNRZ-L-(17): 17-bit Random Non Return to Zero
- Invert DCLK Controls whether data clock is inverted or not.
- Invert PCM Controls whether PCM is inverted or not.

The synchronization strategy section has only one parameter that the user can modify:

• Sampling Rate – This is the system-wide sampling rate. All signals in the setup will be sampled at this rate. Any rate in the range of 1 Hz to 10000 Hz can be specified. If the value specified is outside that range, ATLAS II will limit the input to force it within range. Notice that even though a high sampling rate can be specified, the maximum throughput the system can support will ultimately depend on the mixture of hardware used the system configuration. As a general rule, bitrates higher than 200 kbps are beyond the processing capabilities of a low-level PC.

Notice that there are several other parameters in this section. All those parameters (shown in white letters with a black background) are *outputs* of the system. They are calculated based on the specified system sampling rate. The parameters shown are:

- Frame Words Displays the number of data words in a single frame. This number should always be at least two words larger than the number of signals in the setup. Those extra words are system words (sync word, SFID, etc.), necessary for frame synchronization.
- Frame Bits Displays the total number of bits in a single frame. This number includes bits used by the system words.

- **Baudrate** Also know as the system bit-rate, this parameter shows the total system data rate, expressed in bits per second.
- Actual Sample Rate When a sample rate is specified, ATLAS II tries to program the system in such a way that it can match all of the parameter requests. However, because of the discrete nature of the timing source, the system's actual data rate may vary from the rate requested. This control lets the user verify the difference between the requested rate and the rate the system will use.

ATLAS II allows the user to examine how changes to the sampling rate will affect the system throughput. Enter any data rate of interest and then click the "Apply" button. This tells ATLAS II to calculate and update all the transmission parameters. If the results meet the test criteria, click the "Done" button to exit this window and then select "Setup>>Save..." from the Hardware Configuration window's menubar to save the setup. This last step is very important if the changes made are intended to be active and permanent. If the setup changes are not saved after making the changes, the Frame Properties window will keep the original configuration.

If the changes made to the sampling rate produce unsatisfactory throughput parameters, click the **"Reset"** button. ATLAS II will discard the changes and re-load the last-saved (for the active setup) frame parameters.

3.4 Programming the ATLAS II hardware

Once a setup that matches the test requirements has been created, the ATLAS II hardware must be programmed with that setup. The programming operation basically downloads the setup's parameters into each DAM in the system and makes that setup the default power-up format. After successfully programming the hardware once, all signals will always be sampled according to the selected criteria. The programming information will stay resident in all the hardware units (even through power cycles) until the system is reprogrammed (barring any failure of the hardware).

3.4.1 Programming a Chassis

Only one chassis can be programmed at a time. The user must ensure that the proper chassis is connected to the system computer. The hardware setup must also be loaded into the ATLAS II software before attempting to program the hardware.

To program the hardware, select **"Chassis>>Program a Chassis"** from the menubar in the Hardware Configuration window as shown in Figure 3-25.

E ATLA	S II - Editing "demo" Conf	iguration					×
Setup	Chassis Frame		-				
	<u>A</u> dd a Chassis	Ctrl+A	ule				
32	Program a Chassis Program Active <u>M</u> odule	Ctrl+P Ctrl+M	Signal Name	Bits			
- 33	Change Chassis Properties	Ctrl+C	Hour-Min	16	NOTE: Set the sampling frequency for the system BEFORE saving this module's data. The frequency is required to		
34 35	<u>R</u> emove a Chassis	Ctrl+D	Seconds	16	correctly setup this module.		
J6 J7	EMPTY/SPARE EMPTY/SPARE	GPS	_Microseconds	16			
J8	EMPTY/SPARE	GPS	_Month-Day	16			
		GPS	_Year	16			
		Save Char	iges Cancel				
					Do	ne Ca	ancel

Figure 3-25. Starting a hardware-programming operation.

If the setup includes multiple chassis, the window in Figure 3-26 will appear. This window lets the user select which chassis (from the active setup) to program. Click on the "Current Names" drop-down list to see the complete list of chassis.

Select the appropriate chassis, click the **"OK"** button and the programming operation will start. If the programming sequence must be stopped, click the **"Cancel"** button. The chassis selection window will close and no hardware programming will take place.

Beware that once the **"OK**" button is clicked, there is no way to cancel the programming operation. Furthermore, interrupting a hardware-programming operation will leave the hardware in an unknown state. The unit will need to be re-programmed before it can be used again.

ATLAS II - Seleo	ct Chassis	×
— System Chassis		Ī
Current Names	J	
	chassis_0	
	slave	
		J

Figure 3-26. Select a chassis to be programmed.

If the setup consists of a single chassis, the window in Figure 3-26 will not appear. Instead, after selecting **"Chassis>>Program a Chassis"**, as shown in Figure 3-25, the programming operation will start immediately.

Once the programming operation starts, a few windows will appear. The first of them will be the main status window, shown in Figure 3-27.

Atlas II - Programming Chassis	×
Series 2 Programming	
Generating Binary Files:	
Programming Unit:	

Figure 3-27. Hardware-programming status window.

The status window will be displayed on the desktop until the programming operation is complete. This will be the case regardless of the outcome (success or failure) of the operation.

The image of a chassis in the right side of the window is an animated image. This is one of the indications the ATLAS II software provides to indicate that the programming process is running. If at any point the animation stops, then ATLAS II has locked-up and the

user must terminate it. This can be done from the task manager by selecting the ATLAS program and clicking on the "End Task" button.

The actual workhorses of the hardware-programming process are two low-level command-line utilities. Seeing the DOS-type windows of these two utilities appear on the desktop is an indication that the programming operation is proceeding normally. These utilities are critical to the programming process and require no user input. Therefore, the user should not interact with these windows. Figure 3-28 shows one of the utility windows for reference.

F:\development\atlas\series-ii\source\driver\kc.exe	
KC.EXE : ACRA PCM Compiler [HOUND H/W Support] v2 Release 1.30.3.39 build on Jun 21 2002 - for platform Win32 Found 52 module entries - recording details done. Parsing 'F:\development\atlas\series-ii\source\configurations\demo\setup.xid Calling command line : kfetch -o.\HwInfo.xid Process started successfully	,
KPrefetch (c) ACRA Control Ltd - 2000-2001 V 0.02 build on Jun 21 2002 - for platform Win32	
Programming device : SAM/DEC/005 Mark III	
	•

Figure 3-28. Hardware-program compiler's window.

The duration of the programming process depends on the type of chassis being programmed (master or slave), the type of programming interface (PCMCI A or RS-232) and the magnitude of the changes being made to the DAM's existing programming. Usually, programming one chassis takes about ten to twenty minutes. Changing a DAM's parameters is the fastest process, while using the RS-232 link is the slowest.

If there are any problems during the process, ATLAS II will let the user know. For example, Figure 3-29 shows an error message that would appear if there was a problem communicating with the chassis being programmed.



Figure 3-29. Hardware-programming error message.

Once the error message is acknowledged, ATLAS II will close the hardwareprogramming status window (Figure 3-27) and return to the Hardware Configuration window.

If there are no errors in the programming process, ATLAS II will display a message indicating success. Figure 3-30 shows the success message, as it will appear on the screen.

	x
Programming was successful.	
Acknowledge	

Figure 3-30. Success message. Programming is complete.

3.4.2 Programming the active DAM

When a system is programmed for the first time or when comprehensive changes to the setup are made, all the units in the setup must be re-programmed. In those cases the procedure described in the previous section must be used for each chassis. However, if the only change needed is a change to a single signal's conditioning parameter (like a strain-gauge signal's offset voltage), the programming process can be optimized by telling ATLAS II to only program the active DAM.

To use this optimization select **"Chassis>>Program Active Module"** from the menubar in the Hardware Configuration window as shown in Figure 3-31.

🔁 ATLA	S II - Editing "demo" Conf	figuration	X
Setup	<u>Chassis</u> F <u>r</u> ame		
	<u>A</u> dd a Chassis	Ctrl+A ule	
32	Program a Chassis Program Active <u>M</u> odule	Ctrl+P sis_0_32_enc 32 Slave Ctrl+M Signal Name Bits Value	
J3 J4	Change Chassis Properties	Ctrl+C sis_0_J2_enc_0 16 d 0	
35	<u>R</u> emove a Chassis	Ctrl+D 16 d 0	
J6 J7	EMPTY/SPARE EMPTY/SPARE	16 d 0	
38	EMPTY/SPARE		
		16 0	
		16 d 0	
		Save Changes Cancel	
			Done Cancel

Figure 3-31. Starting a DAM-programming operation.

By selecting this option, ATLAS II will program the DAM currently displayed in the Hardware Configuration window. Since the chassis to be programmed is implicitly selected, the chassis selection window shown in Figure 3-26 won't appear. In this case, the operation cannot be canceled, so ensure that the proper unit is connected to the computer before using this feature.

The typical duration for programming a DAM is about 2 to 3 minutes. This is significantly faster than the 10 to 20 minutes it typically takes to program a full chassis. Most of the time-savings come from ignoring the rest of the DAMs in the chassis. This, however, brings up a limitation to this approach: an individual DAM can only be programmed if the entire chassis has been previously (and successfully) programmed. Remember this is an optimization included to facilitate changes to a signal's conditioning parameters. If the number of signals being transmitted by the DAM is changed, the entire system must be re-programmed because, in addition to having changes in the DAM, the frame definition has also changed.

3.5 Other Software Configuration functions

The major system configuration functions available in the ATLAS II software have been explained. Nonetheless, ATLAS II offers several other functions that give the user greater flexibility over the configuration process and allow him/her to be more productive. This section describes those functions.

3.5.1 Managing Setup files

In Section 3.3.1, "Creating a hardware setup", the process needed to create a basic hardware setup was explained. This section describes the functions that let the more advanced user manage those setup files. For ease of use, these functions are standard Windows file-management functions.

3.5.1.1 Creating a new setup

Refer to Section 3.3.1, "Creating a hardware setup" for information about creating a setup.

It should be emphasized that when a setup is created, the application doesn't just create one file. Specifically, it creates a folder with the file structures necessary for all of the components of the ATLAS II software. Figure 3-32 shows a snapshot of a Windows Explorer window displaying the contents of a setup folder.

Name 🛆	Size	Туре	Modified
dam		File Folder	7/17/2003 10:45 AM
dds		File Folder	7/17/2003 10:45 AM
🗀 dps		File Folder	7/17/2003 10:45 AM
🗀 drs		File Folder	7/17/2003 10:45 AM
i ses		File Folder	7/17/2003 10:45 AM
🗋 xid		File Folder	7/17/2003 10:45 AM
🔊 demo.sys	2 KB	System file	5/9/2003 12:29 PM
🗐 setup.xid	1 KB	XID File	5/9/2003 12:29 PM

Figure 3-32. File structure created for each setup.

As shown in Figure 3-32, the setup folder includes several sub-folders and a couple of data files. All of these files and sub-folders are created and maintained automatically. As a general rule, manually editing the contents of these files is strongly discouraged since it can corrupt the setup, rendering it unusable. A brief description of the sub-folders is included to assist in troubleshooting the application whenever problems occur:

• **dam folder** – This folder contains DAM configuration files. Do not modify any of the files in this folder. Doing so will likely cause an irreversible loss of DAM configuration information.

- **dds folder** This folder contains display configuration files. If the files in this folder are lost, the current setup can still be used to acquire and process data. Please refer to Section 3.7.1.2 "Creating a Display setup" for a complete description of display configurations.
- **dps folder** This folder contains data-processing configuration files. If the files in this folder are lost, data can still be acquired, but ATLAS II will only be able to display or record raw data (use of engineering units (EU) will be disabled). Please refer to Section 3.9.1.1 "Creating a processing setup" for a complete description of data-processing configurations.
- **drs folder** This folder is not used by the current version of ATLAS II. It exists for support of future application features.
- ses folder This folder contains system-events configuration files. If the files in this folder are lost, the software will still be able to acquire, display, and record data either in raw units or in EU. However, ATLAS II will loose its ability to automatically react to events detected during data acquisition. Please refer to Section 3.12, "Using System Events (Automating ATLAS II)" for a complete description of system events configurations.
- **xid folder** This folder contains the hardware-programming source files. Do not edit the files in this folder unless the ramifications of the changes are completely understood. If the files in this folder are lost, the software can still acquire and process data. However, these files must be re-created before any changes to the setup's signals can be implemented.
- *.sys file The .sys file is the main setup file. It holds all of the configuration information (except for specific DAM settings which are inside the dam folder). The name of the file is always the same as the setup's name. If this file is damaged or lost, the setup will be lost.
- **setup.xid file-** This file is the master source file for the hardware-programming process. It has the same name in all setups. Never edit this file manually. If this file is lost, the software can still acquire and process data. However, the file must be re-created before any changes to the setup's signals can be implemented.

3.5.1.2 Opening an existing setup

To open an existing setup, select "Setup>>Open" from the Hardware Configuration window's menubar. The setup selection window, shown in Figure 3-33 will appear. This window allows the user to select a setup file.

The setups listed in the "**Specify Name**" drop-down list are restricted to those existing in the *configurations* folder inside the ATLAS II installation folder. Therefore, if a setup's folder is moved from the configurations folder (or made invisible/hidden to Windows Explorer), access to that setup will be lost.

Þ	ATLAS II - Oper	n Setup	×	l
	— System Identifi Specify Name	er	•	
		ОК	Cancel	

Figure 3-33. Loading an existing setup.

Once a setup from the list is selected, click the "**OK**" button and ATLAS II will load that setup and make it the active setup. By clicking the "**Cancel**" button, ATLAS II will return to the Hardware Configuration window without making any changes to the active setup.

3.5.1.3 Saving a setup

To save a setup, select "Setup>>Save" from the Hardware Configuration window's menubar. ATLAS II will simply overwrite all of the files for the active setup.

Saving a setup causes ATLAS II to re-calculate all of the frame parameters. It will also cause it to generate or update all of the hardware-programming and configuration files.

When changes to a DAM's configuration are made and saved, ATLAS II will automatically perform a save-setup operation. This ensures that the changes to a DAM are always checked for system-wide effects. Once the changes to the DAM configuration are saved, the user is not required to explicitly save the setup.

There's an exception to the auto-save. The only occasion where changes to a DAM configuration don't cause a save-setup operation is when a DAM is removed from a chassis (replace it with the "empty/spare" DAM). The DAM will be removed and the setup will be aware of that, but since this is a null operation (the new DAM doesn't have any settings), the user must explicitly save the setup to force a complete update of the configuration files.

3.5.1.4 Using an existing setup as a template

Sometimes during testing, there will be a time when an active setup's configuration is changed to experiment with some parameter's settings. A "save as" feature is offered to allow the user to save the new configuration with a different name, in order to preserve the original one.

Select "Setup>>Save As..." from the Hardware Configuration window's menubar. The window in Figure 3-34 will appear.

ATLAS II - Save Setup As 🔀
– System Identifier –
Specify Name
OK Cancel

Figure 3-34. Using a setup as a template.

Enter the name for the new setup in the "Specify Name" control and click the "OK" button. ATLAS II will make a copy of the active setup and give it the name specified. Furthermore, ATLAS II will make the new setup the active one. Now modifications can be made without affecting the original setup.

If the **"Cancel"** button is clicked, ATLAS II will return to the Hardware Configuration window without making any changes to the active setup.

3.5.2 Managing a Chassis

The main goal of the design of the Hardware Configuration window is to make it appear as much like the actual hardware as possible, thus allowing the application to be more intuitive. The best way to achieve that goal was to make the window look like a DAS' chassis together with a snapshot of one the DAMs in it.

This section explains the process of adding multiple chassis to a setup and how to customize all chassis in the setup to conform to specific test requirements.

3.5.2.1 Modifying a Chassis' properties

Every chassis in a DAS has a number of properties that characterize it. When a setup is created, ATLAS II will automatically add a 6-slot chassis to it. To allow the user to control the definition of the chassis in the setup, ATLAS II provides the user with a chassis-properties editor window.

To edit chassis properties select "Chassis>>Change Chassis Properties" from the Hardware Configuration window menubar. The window shown in Figure 3-35 will appear on the screen.

Þ	ATLAS II - Seleo	t Chassis	[×
	— System Chassis		1	
	Current Names	٧	1	
		chassis_0		
		slave	E	
		OK	Cancel	

Figure 3-35. Chassis selection window.

Click in the **"Current Names"** drop-down list control to see the complete list of chassis. Once the chassis of interest appears, select it and click the **"OK"** button. The chassis properties window shown in Figure 3-36 will appear on the screen.

Every chassis is defined by three properties: name, size, and position. Each property is described in detail next:

• Size- The number of slots in a chassis. ATLAS II supports all currently available chassis sizes: 3, 6, 9, and 13-slot units. The number of slots refers to the number of *user* slots available in the chassis. Therefore, a 6-slot chassis actually has 7 slots: one for the encoder and 6 user slots for any DAMs other than encoders.

Slot J2 is considered a system slot rather than a user slot because it is strictly reserved for an encoder DAM. An encoder DAM is required in each chassis, and it can only be installed in slot J2. All other slots in a chassis are free to be used with any other DAM the user chooses.

Þ	🔁 ATLAS II - Edit Chassis 🔀						
	— Chassis Propert	ies	ī				
	Chassis Name	chassis_0					
	Chassis Type	KAM/SYS/06U 💽					
	Chassis Position	1 💌					
	<u> </u>	OK Cancel	1				

Figure 3-36. Chassis properties window.

- Name The chassis' name identifies the unit throughout the software. The user can specify any string, but do not include spaces in the name (up to 25 characters). If spaces are included, ATLAS II will automatically replace them with underscore (_) characters.
- **Position** When the user adds a chassis to a setup, it gets added to the end of the "chassis chain". Remember that chassis order is one of the parameters that influence the order of words (signal samples) in the data frame. Moreover, the master chassis must always be the first chassis in a setup. The list of options for this property will be restricted to the current number of chassis in the active setup. This means that the user cannot add one or more chassis to a setup by modifying this property.

Once in the chassis properties window, all of the properties of a chassis can be modified. If slots are added to the chassis, ATLAS II will leave the new slots empty. If the chassis size is decreased, ATLAS II will automatically remove from the data frame all of the signals defined in the DAMs that were removed.

All changes to a chassis' properties are in effect as soon as the **"OK"** button is selected. If the user does not want to make any changes, click the **"Cancel"** button. As soon as the chassis properties window closes, the Hardware Configuration window will appear.

3.5.2.2 Adding a Chassis to a setup

To add a chassis to a setup, select "Chassis>>Add a Chassis" from the Hardware Configuration window's menubar. The window shown in Figure 3-37 will appear.

By default ATLAS II will create a 6-slot chassis. If a different size is required, click on the **"Chassis Type"** drop-down list and select the proper size. All possible chassis sizes

are available. Moreover, ATLAS II will automatically install a KAM/ENC/003 encoder DAM in the first slot of the chassis. All other slots will be empty.

Þ	ATLAS II - Add (hassis	\times
	— New Chassis Pro	perties	1
	Chassis Name		
	Chassis Type	KAM/SYS/06U	
		OK Cancel	

Figure 3-37. Adding a chassis to the active setup.

Enter a chassis name in the appropriate control and click the "**OK**" button to add the chassis to the active setup. If no chassis is required, click the "**Cancel**" button. As soon as the "add-a-chassis" window closes, the Hardware Configuration window will appear and the new chassis (if one is created) will be the active chassis. The Hardware Configuration window will display the configuration of the encoder in slot J2.

3.5.2.3 Removing a Chassis from a setup

To remove a chassis from a setup, select "Chassis>>Remove a Chassis" from the Hardware Configuration window menubar. The chassis selection window shown in Figure 3-35 will appear.

Click in the **"Current Names"** drop-down list control to see the complete list of chassis. Once the chassis being deleted is selected, click the **"OK"** button. ATLAS II will immediately remove all references to the selected chassis (including all signals originating from DAMs in the selected chassis) from the active setup.

If no chassis needs to be deleted, click the "Cancel" button. As soon as the chassis selection window closes, the Hardware Configuration window will appear.

3.5.3 Finding a signal's definition

As a hardware setup becomes larger and more complex, it becomes difficult to remember all the necessary parameters for each signal. Furthermore, it can be quite difficult to identify the chassis and the slot the signal originates from.

To have ATLAS II display the configuration of the DAM that generates a signal, select **"Frame>>Show Signal Definition"** as shown in Figure 3-38.

ATL	AS II - Editing "demo" Co	nfiguration		×
Setup	Chassis Frame			
	Edit Frame Prope	erties Ctrl+F		
	C Show <u>S</u> ignal Defi	inition Ctrl+Z j_j2_enc	J2 Slave	
32	KAM/ENC/003 -	Tx Signal Name	Bits Value	
33	EMPTY/SPARE	✓ chassis_0_J2_enc_0	16 4 0	
34	EMPTY/SPARE			
J5	EMPTY/SPARE		16 a 0	
36	EMPTY/SPARE		16 d 0	
J7	EMPTY/SPARE			
38	EMPTY/SPARE		16 a 0	
			16 d 0	
			16 d 0	
			16 d 0	
			16 d 0	
		Save Changes Cancel]	
				Done Cancel

Figure 3-38. Looking up a signal's definition.

The signal selection window (shown in Figure 3-39) will appear. The options in the **"Current Signals"** drop-down list will change depending on the active setup.

- System Configuration	η	
Current Signals	slave_J2_enc_0	-
	ок	Cancel

Figure 3-39. Signal selection window.

Click in the drop-down list control to see the complete list of signals. It may be necessary to scroll up (or down) the list to find the signal of interest. Once the signal is selected, click the **"OK"** button. The Hardware Configuration window will immediately change to display the DAM that sources the selected signal. This function works within the context of the active setup. This means it will look into all the chassis in the setup to find the specified signal. It doesn't matter if the signal originates in a chassis other than the active chassis.

If the signal of interest is not in the drop-down list, there are two possible causes. First, the signal was recently added or removed from the active setup and the change wasn't made permanent (forgot to save the setup). Second, the specified signal doesn't exist in the active setup. In this case, a different setup can be loaded to search for the signal.

3.6 Acquiring Data

Once the system has been configured and the hardware has been programmed, ATLAS II is ready to acquire data. The ATLAS II data-acquisition routines are designed to work in a continuous mode. In other words, once acquisition is enabled, ATLAS II will acquire data frames until the acquisition is stopped or a system event (see Section 3.12 "Using System Events (Automating ATLAS II)" for more details about events) commands it to stop. This is true regardless of the other functions that can be performed while the acquisition is active (data display, archiving, etc.).

3.6.1 Starting a DAQ session

A DAQ session is the interval of time during which ATLAS II is acquiring data frames, regardless of its duration in time.

To start a DAQ session, select **Acquisition**>>**Start Data Acquisition** from the menubar of the ATLAS II main window as shown in Figure 3-40.

🔁 ATLA	S II - Syste	m Status				_ 🗆	×
<u>S</u> ystem	<u>A</u> cquisition	<u>R</u> ecording	Utilities	Help			
System		a <u>A</u> cquisitic a Acquisitio				Event	
	Data Visu	alization	•				1
Samp	Set Upda		Ctrl+L	Bit Rate Dropout:	0.000EH s T:	FO OTT	
	N/A		0	0	N	/A	
	N/A			0	N	/A	
	N/A		0	0	N	/A	
	N/A		0	0	N	/A	
Data	Recording S	tatus ——					-
Condit	ional Setup 🛛	default.drs	Re	cording Mo	ide 📃	OF	
	File Format 🛛		Da	ata Format			
Fi	File Duration 600 [sec] File Mode						
	Status 🛛	Data record	ling is disab	led.			
						exit	

Figure 3-40. Starting a DAQ session.

The setup selection window (Figure 3-41) should appear immediately. This window allows the user to specify the configuration parameters required for successful decoding of the incoming data frames.

ATLAS II - Set Communications	×
Communication R5-422 Decoder 0	
System Configuration	
OK Cancel	

Figure 3-41. DAQ setup window.

The setup selection window allows the user to customize the "Communications" and "Setup Name" parameters. The Decoder parameter is an indicator and thus, it cannot be modified. It is displayed to give the user a context for the other two parameters.

As explained previously, the system computer that runs the ATLAS II software uses a PCMCIA decoder card to read the data frames sent by the DAS units in the ATLAS II system. Modern computers usually have pairs of PCMCIA ports. If needed, more than one decoder can be installed in the PCMCIA slots in the system computer. ATLAS II currently supports the concurrent use of up to four (4) data decoder cards.

The decoder indicator tells the user which decoder card's parameters are being modified in the current window. Decoder cards are listed in the order they were installed in the computer starting with decoder zero (0) for the first card. ATLAS II will automatically display a DAQ setup window, see Figure 3-41, for each decoder card it finds in the computer. For example, if only one decoder card is installed, only one DAQ setup window will appear when the DAQ session is started. If another decoder card is installed in the computer, once the DAQ setup window for Decoder 0 is closed, ATLAS II will display the DAQ setup window for Decoder 1.

The "Communication" drop-down list lets the user select the communications protocol to use when communicating with the DAS unit connected to this decoder card. The options are: RS-422 and TTL. Make sure the correct protocol is selected. Otherwise ATLAS II will not be able to decode the incoming frames and will tell the user that there's no data being transmitted (at best) or that there are frame errors in the transmission.

The "Setup Name" drop-down list lets the user select the setup that defines the format of the data frames that will be received at this decoder card. Remember that each hardware setup (with its signal definitions) describes the structure of a data frame. If a setup dif-

ferent from the one actually programmed in the hardware is selected, ATLAS II will not be able to successfully decode the incoming data frames, and as with the "Communication" parameter, ATLAS II will tell the user that no data is being transmitted (at best) or that there are frame errors in the transmission. Acquisition from a properly configured decoder-DAS pair is typically error-free.

Once the correct setup is selected, click the "**OK**" button. ATLAS II will immediately look for data frames to decode and process. If at any time ATLAS II appears to be locked-up after clicking the "**OK**" button, there are probably no data frames coming in. Check that the appropriate decoder card is connected to a DAS unit and that the DAS unit is powered on.

If no data is to be acquired *from a specific decoder*, click the "Cancel" button in the DAQ setup window for that decoder. The user is not required to always acquire data from all installed decoder cards. Just make sure that each data stream is coming into the appropriate decoder card.

After closing the DAQ setup window(s), ATLAS II will return to the main window. This time, however, the user should see data acquisition status information continuously updating the main window. An example is shown in Figure 3-42.

3.6.2 Stopping a DAQ session

As soon as a DAQ session is started, ATLAS II updates the "Acquisition" menu in the main window to reflect the new system state. One of the changes implemented is that the "Start Data Acquisition" menu option will be disabled and the "Stop Data Acquisition" option next to it will be enabled.

To stop a DAQ session, select **Acquisition>>Stop Data Acquisition** from the menubar of the ATLAS II main window. The activity LED in the main window should turn red immediately. All DAQ status information should be set to the default values and the main window will look as if the application just started.

Stopping the data acquisition does not stop data recording. However, if data acquisition will not be re-activated soon, data recording should be stopped since ATLAS II will not receive additional data frames to record.

Another way data acquisition can be stopped is by exiting the application. Before it terminates, ATLAS II will attempt to stop all on-going processes (acquisition, display, recording, etc.). This is not the best way to terminate these processes since they are in effect being aborted, but there will be no data corruption by exiting this way.

System Se — Data Ac	quisition <u>R</u> ecord tup dummy.sys;	ing <u>U</u> tilities (<u>H</u> elp		
Data Ad	and the second second			(ž.	
1000 March 10000					Events
6.0 3.0	quisition Status —				
Sampling	Rate 300.0	Channels 21	Bit Rate 10	5.263E+3	ON
	Chassis	Link	Dropouts	TSLD	
	chassis_0	0	0	0:00:00:07	7
	N/A	0	0	N/A	
	N/A	0	0	N/A	
	N/A	- 0		N/A	
Condition File	cording Status	Da [sec] File M	cording Mode ata Format / 10de / led.	ſ	

Figure 3-42. Main window showing active DAQ status.

3.6.3 Reading the DAQ Satus information

Figure 3-42 shows the ATLAS II main window after starting a typical DAQ session. In this section we'll discuss the significance of the DAQ status information presented in the window.

First, the "System Setup" indicator displays the name of the active hardware setup. Notice that there's a semicolon (;) after the setup name ("dummy.sys"). This is important. Remember that the software has the capability to acquire data from multiple decoder cards simultaneously and that each decoder card will be receiving data frames of a specific format. ATLAS II uses the semicolon to separate the setups of each active decoder card. In the case of Figure 3-42, "dummy.sys" is listed first. This means that the first decoder card is currently configured to decode data frames defined according to the "dummy" hardware setup.

The semicolon after the first setup name tells the user that there is a second decoder card in the computer. However, by not listing another setup name after the semicolon, ATLAS II is telling the user that the second decoder card is not active in the current DAQ session.

If a DAQ session is started in a configuration where the first decoder card is not used, but the second card is used, ATLAS II will display the semicolon before the setup name. If a DAQ session is initiated were two decoder cards are used, ATLAS II will display two setup names separated by a semicolon. The order of the setup names corresponds with the order of the decoder cards.

The next portion of DAQ status information displays the system values for the following parameters: sampling rate, channels, and bit rate. These are called "system" values because they reflect the total system load for the DAQ session instead of the values for any particular setup. If the DAQ session uses a single decoder card, there's only one active setup and therefore the values for the three parameters will reflect those of the active setup. However, if the DAQ session uses multiple decoder cards, there will be multiple active setups and the values for the three parameters will be the sum of the values of each setup.

Of course, the system's sampling rate is not additive. This parameter will be the same regardless of the number of decoder cards active in the DAQ session. This brings up the issue that data should not be acquired simultaneously from setups that have different sampling rates. Although ATLAS II does not prevent the user from doing it, it would be nearly impossible to make sense of the timing of the data frames from the different decoder cards.

The other two parameters (channels and bit-rate) are additive parameters. This means that ATLAS II will display in the main window the sum of the values of each active setup. If the DAQ session has two active setups with the following parameters,

- Setup A: channels 30, bit-rate 45kbps
- Setup B: channels 92, bit-rate 140kbps

Then ATLAS II will show system values of 122 channels and 185kbps.

Next to the Bit-rate indicator in the window is the activity LED. In Figure 3-42 the LED is shown with green color and the text "ON". This is the way it should look after a DAQ session has begun. ATLAS II is currently acquiring data and that the rest of the main window's DAQ status information is relevant.

If the activity LED is red after ATLAS II has started a DAQ session, ATLAS II could not successfully start the acquisition process. In this case there will be no data updates because the DAQ session was never started. Failure to start a DAQ session suggests that there is a problem with one or more decoder cards.

After a DAQ session has been started successfully, the user can look at the table section for details about every DAS units status. This section of the window can display status information of up to four (4) DAS units. The units are listed in the order they were configured in the setup. Furthermore, multiple setups are listed in the same order they have in the "System Setup" display. If the DAQ session is acquiring data from two setups with the following units,

- Setup A units: chassis_0, chassis_1
- Setup B units: master, slave

The units will be listed as chassis_0, chassis_1, master, and slave in the status table (assuming Setup A is being decoded by card0 and Setup B by card1).

All of the information in the table section of the window is updated every time a data frame is read. If everything is OK, the user will see status updates showing up at a constant rate. If no updates are occurring, there is a problem in the system. More than likely the software has stopped receiving data frames because of a power failure or a bad connection. Check all the communications connections and verify all the units are powered on before trying to make any changes to the software.

The first status parameter for each chassis is its Link status. If the indicator is green, there is no problem communicating with that chassis. If the indicator is red, the communications link with the chassis has been broken. This status is a snapshot, i.e., it tells the instantaneous status of the link. To determine long-term trends, a backlog number is displayed in the center of the Link indicator.

The backlog is a measure of the efficiency of communications with a chassis. This number indicates the number of data frames that are currently sitting in the decoder card's internal buffer. Ideally this number should always be at zero. This condition means the application is keeping up with data transmissions from the chassis. Obviously, the system can sustain that condition forever. On the other hand, if the backlog number is continuously increasing, it means data frames are accumulating in the decoder card's buffer. Since the card's buffer is finite, this condition is not sustainable. If it continues, it will get to a point were the buffer will eventually be full. When this happens, the card will discard the whole buffer to make space for the incoming data frames. Hundreds (maybe thousands, depending on the setup's characteristics) of data frames can be lost every time this overflow happens. It should be emphasized that only a *continuously* increasing backlog number that is bad. It is completely normal for the backlog to *momentarily* increase depending on the load on the system computer (the number of tasks active at a time). In these cases, the backlog can increase by hundreds of frames, but it should then start decreasing until it eventually gets back to zero. The backlog indicator should not be of concern until it is seconds away for an overflow condition. Moreover, a backlog that is not zero, but is constant (assume it always stays at 87 frames) is also not a problem because the system can sustain that condition indefinitely. Those 87 frames (in this example) will not be lost or out of order, and will be processed as soon as the system has the resources to do so (which may be just after the user tells it to stop acquiring data). The user must still check the system to prevent the condition from deteriorating.

Next to the Link/Backlog indicator is the Dropouts indicator. A dropout is defined as an instance where communications problems with the chassis cause the loss of one or more data frame. A dropout can be thought of as the condition that causes the Link indicator to turn red. The Dropouts indicator tells the user how many instances of improper communications have been detected since the start of the DAQ session.

Even though, in most cases, it is not acceptable to lose even a single data frame, a nonzero Dropouts indicator does not necessarily mean trouble. For instance, it is possible for the system to detect a few Dropout conditions (around five) shortly after power has been applied to the chassis. In addition, Dropouts may have happened at an early stage of the process (and their source is eliminated afterwards) and the system could have been running error-free for hours or days since.

To help put in context the effect of Dropouts, ATLAS II offers the TSLD parameter. The name stands for Time-Since-Last-Dropout. It is a counter that starts counting when a DAQ session is started and resets every time a Dropout is detected. As mentioned in the previous paragraph, the system may not be having problems if the Dropouts indicator is 43, and the TSLD shows 12 days.

The format of the TSLD indicator is Days:Hours:Minutes:Seconds. This allows ATLAS II to keep tabs on long-term DAQ sessions without losing the time resolution needed to detect high-frequency Dropout occurrences. As is the case with the other status parameters, the TSLD is updated continuously at a rate of once every second.

Using Figure 3-42 as our reference again, notice that there's only one chassis listed: chassis_0. The other entries in the status table are "N/A". This means there is only one active chassis in the current DAQ session. This should agree with the contents of the active setup(s). All chassis included in all active setups should each have an entry in the status table.

3.7 Displaying Data

As mentioned earlier, when a DAQ session is started, ATLAS II updates the "Acquisition" menu in the main window to reflect the new system state. One of the changes implemented is that the "Data Visualization" sub-menu will be enabled. This sub-menu is enabled only during data acquisition. As soon as the acquisition is stopped, ATLAS II will disable the menu.

The "Data Visualization" sub-menu has two options: "Display Digital Data" and "Display Graphical Data". Figure 3-43 shows a screen snapshot of the sub-menu. The two options in the sub-menu are exclusive. This is because the options allows the user to configure the data display "mode". ATLAS II will pass the "mode" information to the data visualization component, which will then adjust itself accordingly.

The user is allowed to change the selection at any time without affecting the application. Both options are discussed in the next section.

ystem 📕	Acquisition Recording	Utilities He	elp		
System	Start Data Acquisition			2	vento
- Data	Data Visualization	Þ		Digital Data	Ctrl
Samp -	Set Update Rate	Ctrl+U	Display - Dropouts	<u>G</u> raphical Data TSLD	Ctrl
	chassis_0	0	0	0:00:01:12	
	N/A	0	0	N/A	
	N/A	0	0	N/A	
	N/A	0	0	N/A	
Conditio F	Recording Status	Data	ording Mode a Format 🗍 ode 🗍	•	

Figure 3-43. Data Visualization sub-menu.

Opening the data display window does not prevent the user from examining the status information in ATLAS II' main window. The main window will stay open and can be viewed (and more importantly, interact with its menus) at any time. In fact, ATLAS II main window and data display window have been designed so that the user can place them next to each other on the desktop without any overlap between the windows, if ATLAS II is ran on a system with the recommended display resolution (or higher). Furthermore, running the ATLAS II software on a computer with a resolution lower than 1024x768 is not recommended.

3.7.1 Displaying Graphical Data

To display graphical data, select Acquisition>>Data Visualization>>Display Graphical Data from the menubar of ATLAS II' main window. The data display window shown in Figure 3-44 should appear immediately.

When data monitoring is completed, click the **Close Display Window**" button to close the data display window.

The window in Figure 3-44 shows a typical display. When the window is opened for the first time, no data signal will be displayed, since the user must specify which signals to display.

3.7.1.1 Display/Monitor a signal

The data display window allows the user to monitor the current readings of up to eight (8) signals simultaneously in real-time. The top-left side of the data display window has eight drop-down signal-list controls to permit selection of the signals to monitor. Each of these controls has the complete list of signals from the active setup(s). By default, all controls are set to "none" which means no signal is being displayed.

To view a signal in both the digital display and the graph, click on one of the signal-list controls and select a signal from the drop-down list. As soon as the selection is made, ATLAS II will start updating the signal's current value in the digital indicator right next to the signal-list control where the signal was selected.




Figure 3-44. Data display window in Graphical mode.

When a signal is selected in one of the signal-list controls, ATLAS II will also add the signal to the graph in the lower half of the window. As shown in Figure 3-44, each of the eight signal-list controls has a different color in the inverted-triangle-shaped icon at the right end of the control. The color of the icon is the color ATLAS II will use to plot the signal in the graph. To identify the signal in the graph, just refer to the color code in the signal-list control.

If at any time a single signal must analyzed in depth, remove all other plots from the graph by selecting "none" from each of the other signal-list controls. ATLAS II will always display a value of zero and units of "counts" for all "none" signals.

3.7.1.2 Creating a Display setup

Most of the time the same set of signals will be monitored for very long periods of time. In those instances, it is not efficient to have to specify the set of signals to be monitored each time the data display window is opened. To help the user in those situations, ATLAS II supports the creation of independent display setups.

A display setup is a configuration file that tells ATLAS II how to setup the data display window. Everything that's configurable in the window is stored in the file, so the display only needs to be configured once. In addition to creating a display setup file, ATLAS II remembers which setup file was used last. This way, when the data display window is opened, ATLAS II will set all parameters exactly as they were the last time the window was active.

The most important part of creating a display setup file is configuring the data display window exactly as required by the test. After this is done, click the **"Save Display Setup"**. A file dialog window will show up immediately (as shown in Figure 3-45). Enter a name for the new setup file and click the **"Save"** button. The display setup file has now been created.

Notice in Figure 3-45, that by default, ATLAS II will create the display setup file in the dds folder corresponding to the active setup (refer to Section 3.5.1.1 for more information about a setup's file structure). Even though any file destination can be used for the display setup file, saving it inside its parent hardware setup folder is recommended. Remember that the signals available for graphing are relative to the active setup. It may be useless to try to use this *.dds file when a different setup is active, as the signals to display may not exist in that other setup.

Open Display Cor	figuration File.				<u>? ×</u>
Look jn:	🔁 dds		•	🕂 🖻 🖆 🎟 -	
History Desktop My Computer My Network P	E test.dds				
	File <u>n</u> ame:			•	<u>O</u> pen
	Files of <u>t</u> ype:	Custom Pattern (*.dds)		•	Cancel

Figure 3-45. Creating a display setup file.

3.7.1.3 Loading a Display setup

To load a display setup file, click the "Load Display Setup" button in the data display window. A file dialog window will be displayed (as shown in Figure 3-46). Select the display setup file of interest and click the "Open" button. ATLAS II will reconfigure the data display window to use the settings from the file just loaded.

By default, ATLAS II will look for the display setup file in the dds folder corresponding to the active setup (refer to Section 3.5.1.1 for more information about a setup's file structure). This is another reason to store *.dds files in the location ATLAS II suggests. It will streamline the file-management process by automatically locating files relevant to the active system.

Open Display Co	nfiguration File.				? ×
Look jn	: 🔂 dds		•	+ 🗈 💣 🎟+	
History Desktop My Computer My Network P	E test.dds				
	File <u>n</u> ame: Files of <u>t</u> ype:	Custom Pattern (*.dds)		•	<u>O</u> pen Cancel

Figure 3-46. Loading a display setup file.

3.7.1.4 Displaying Processed (EU) data

The ATLAS II data display window can present data in two formats: raw and processed. Raw data is the default data presentation mode. In this mode, all signal values are displayed in counts. Counts are the "raw" unit of every sample in the data frames transmitted by the DAS units in the system. The count value will range from 0 to 65536, representing the 16-bit data word for every channel.

ATLAS II also has the ability to present data in engineering units (processed data). To enable this mode, click the **"Showing Raw Data"** button in the data display window, see Figure 3-44. Data display window in Graphical mode.. The button's text will change to **"Showing Processed Data"** and ATLAS II will immediately switch to displaying data in engineering units. Beware that ATLAS II' ability to display EU data is dependent on the user setting up a data-processing configuration file. This file, discussed in Section 3.9, gives ATLAS II the instructions necessary to convert the raw data to engineering units.

When the user enables the presentation of EU data, ATLAS II will try to convert the incoming raw data to EU data using the active data-processing configuration file. If no configuration file has been loaded or the file's signals do not match the currently active setup, the results of the data conversion may not be correct. In the best case, ATLAS II will display raw data instead of EU data. In the worst case, ATLAS II will display a value of zero for a signal for which there's no entry in the data-processing configuration file.

3.7.1.5 Customizing the Graphing window

The ATLAS II data display window can be customized to provide the user with the best data visualization experience for the test data. Instead of being a one-size-fits-all design, the user can change the amount of data ATLAS II displays to enable the software to keep up with the test requirements.

The "Update Rate" control in the right-center section of the window is the most important tool. This control sets the duration of the system update cycle. Update Rate is expressed in milliseconds/update. For example, an Update Rate of 300 milliseconds will cause ATLAS II to refresh the data display window (both digital and graphical components) once every 300 milliseconds. This does not mean that data acquisition is going to slow down (or speed up for that matter). Update Rate only changes how much new data will be presented with each refresh of the graph. Moreover, it defines how fast new values will be presented in the digital indicators. The Update Rate has a range of 10-10,000 milliseconds.

Below the Update Rate control is another control called "window". This parameter controls the size (in seconds) of the graph "window", in other words, the size of the time slice that will be presented in the data graph. If the test data measures low frequency events, a longer time will be needed to capture enough data to see an event. Conversely, if the test data measures high frequency events, only a brief instant should be shown to be able to discriminate the details in the data. The "window" parameter lets the user customize the graph display to accommodate any type of test data.

3.7.1.6 Optimizing the Display's performance

Now that most of the ATLAS II main features have been described, it is appropriate to discuss how the system's parameters interact with one another.

The previous section presented a discussion of a couple of parameters that control how ATLAS II displays data. It has also been mentioned that ATLAS II provides two different display options. The next step is to discuss how changes in these parameters affect ATLAS II' response time. Remember, all of these parameters work within the context of a hardware setup.

An important parameter to keep in mind is the system's bit-rate. This rate is the system's throughput and is constant and continuous throughout a DAQ Session. This means that with no other features active, the ATLAS II system will be loaded to varying degrees according to the active setup's bit-rate. Displaying data, whether digitally or graphically only adds to the system's load.

By default, ATLAS II operates with an update rate of 300 milliseconds. This rate is appropriate for most relatively slow systems (systems whose bit-rate is less than 100 kbps). However, if the setup defines a higher bit-rate, the user may notice that the backlog indicator in the main screen starts to increase with time. When this happens, the first response should be to close the data display window to measure the effect of that process on the system load.

If closing the data display window has a significant effect on the system load, minimize the impact of data visualization by only displaying digital data. If displaying only digital data is not sufficient to stabilize the system backlog, the next step is to modify the system update rate. Try to use an update rate that is a multiple of the sampling rate. This produces a fundamental size for a data block and will help simplify finding the optimum update rate.

If closing the data display window doesn't have a significant effect on the system load, the system is at its maximum load level. In this case the system's sampling rate should be decreased. Reducing the sampling rate will decrease the system's bit-rate. If it is not possible to decrease the sampling rate, consider upgrading the system computer to obtain additional resources.

The most important thing to remember is that ATLAS II is flexible enough to help the user balance the test requirements with the system computer's available resources.

3.7.2 Displaying Digital Data

To display digital data, select **Acquisition>>Data Visualization>>Display Digital Data** from the menubar of ATLAS II' main window. The data display window shown in Figure 3-47 should appear immediately.

After data monitoring is complete, click the "Close Display Window" button to close the data display window.

TLAS II - Data Display				
Signals		Value	Units	Data Display Setup
chassis_0_J2_enc_0	∇	54.321E+3	counts	series-ii\source\
chassis_0_J5_strain_1	-	65.535E+3	counts	Load Display Setup
chassis_0_J5_strain_3	V	65.535E+3	counts	Save Display Setup
chassis_0_J5_strain_5	∇	20.771E+3	counts	Showing Raw Data
chassis_0_J5_strain_7	∇	65.535E+3	counts	Close Display Window
none	∇	0.000E+0	counts	Update Rate 300 [msec]
none	∇	0.000E+0	counts	
none		0.000E+0	counts	

Figure 3-47. Data display window in Digital mode.

The only difference between the graphical and digital modes of the data display window is the existence of the graph. All other controls and indicators are the same in both windows modes. For a complete description of all controls and indicators in the data display window, please refer to the previous section, "Displaying Graphical Data".

The main benefit of the digital display mode is its lower system load. If the DAQ session is pushing the computer's resources to the limit while displaying data in graphical mode, switching to digital mode will improve the situation. Moreover, if ATLAS II is being operated remotely (over a TCP/IP network), the lower bandwidth of the network usually means that the user will not be able to use the graphical display mode at all. If that's the case, the digital mode can be used to have a complete look at the acquisition in real-time.

3.8 Controlling the System Update Rate

As described in Section 3.7.1.5, The ATLAS II permits the user to set the systems update rate when using the data display window. However, there will be times when the systems update rate must be modified and the data display window is not active. In those cases, ATLAS II gives the user another way of modifying the system's update rate.

To modify the update rate, select "Acquisition>>Set Update Rate" from the menubar in the ATLAS II main window. The window shown in Figure 3-48 will appear.

ATLAS II - Set Update Rate	×
Active Configuration Update Rate 300 [milliseconds/refresh]	Ī
OK Cancel	

Figure 3-48. Modifying the system's Update Rate.

Enter the desired value for the Update Rate and click the "**OK**" button. The Update Rate has a valid range of 10-10,000 milliseconds. ATLAS II will immediately use the new update rate. Even though the data display window may not be open, remember that the update rate controls the refresh rate of the data acquisition process, in other words, the frequency at which ATLAS II reads blocks of data frames from the active decoder cards in the computer.

Click the "**Cancel**" button if the update rate displayed will not be modified. Upon cancellation, ATLAS II will close the window and immediately return to the application's main window without making any changes.

3.9 Processing Data

In Section 3.7.1.4 ATLAS II capability to display processed data was described. However, in order for ATLAS II to display processed data, the user must tell the software how to generate that data.

3.9.1 Configuring Data Processing

To configure the data conversions for all signals in a DAQ session, select System>>Configure Data Processing from the menubar of the ATLAS II main window, see Figure 3-49.

🔁 ATLAS II - System Status			_	
System Acquisition Recording	<u>U</u> tilities į	<u>H</u> elp		
Configure <u>H</u> ardware	Ctrl+C			Events
Configure Data Processing	Ctrl+P			a venes
Configure System Events Enable System Events Disable System Events	Ctrl+E Ctrl+N Ctrl+M	Bit Rate 105. Dropouts	263E+3	277
Exit	Ctrl+W	0	N/A	
N/A	0	0	N/A	
N/A	0	0	N/A	
N/A	0	0	N/A	
Data Recording Status		cording Mode		072
				-
File Format		ata Format		_
File Duration 600 [see	c] File N	1ode		
Status Data record	ing is disab	led.		
			ex	it

Figure 3-49. Configure data processing window.

The Data-Processing configuration window in Figure 3-50 should appear. However, unlike the window shown in Figure 3-50, the configuration window will be empty the first time it is opened and whenever ATLAS II cannot find the previously active data-processing setup file. In this case, the user must create a new data processing setup file or open an existing one.

etup File Path F:\development\atlas\series-ii\source\ci dummy.dps	onfigurations\dummy\dps\		3 11:48:06 AM
Signal Name	Physical Units	Volts to P Slope	hysical units Intercept
chassis_0_J2_enc_0	counts	1.000E+0	0.000E+0
chassis_0_J3_dec_0	counts	2.000E+0	0.000E+0
chassis_0_J4_analog_0	counts	3.000E+0	0.000E+0
chassis_0_J4_analog_1	counts	4.000E+0	0.000E+0
chassis_0_J4_analog_2	counts	5.000E+0	0.000E+0
chassis_0_J4_analog_3	counts	6.000E+0	0.000E+0
chassis_0_J4_analog_4	counts	7.000E+0	0.000E+0
chassis_0_J4_analog_5	counts	8.000E+0	0.000E+0
chassis_0_J4_analog_6	counts	9.000E+0	0.000E+0
chassis_0_J4_analog_7	counts	10.000E+0	0.000E+0

Figure 3-50. Data-Processing configuration window.

The Data-Processing configuration window allows the user to specify the conversion factors ATLAS II uses to convert raw data into engineering units (EU). As of this software revision, ATLAS II performs the same conversion operation on all signals: a first-order linear mapping.

The configuration window has a file path indicator near the top of the window with a "last updated" indicator next to it. Those two indicators (no data input allowed since these are output values) describe the currently active data-processing file. All changes made to the data-processing configuration will be applied to that file.

The other component of the window is the configuration table. This table lists all of the signals in the data-processing setup. For each signal, the user can specify the physical units of measurement and the coefficients for the linear data conversion. ATLAS II will process all signals according to the following equation:

Measurement (EU) = [Measurement (counts)]*Slope + Intercept

The data-processing window can display up to ten signals simultaneously. If a dataprocessing setup includes more than ten (10) signals, use the "**Previous**" and "**Next**" buttons to examine other signals in the setup. As their names imply, those buttons let the user navigate to the previous or next "page" of signals. ATLAS II will gray out the appropriate button when scrolling gets to either end of the list.

To exit the window and save all changes to the file listed in the file path indicator, click the **"Done"** button. ATLAS II will immediately return to the main window.

If no changes are necessary, click the **"Cancel"** button. ATLAS II will immediately return to the main window without making any changes to the active setup file.

3.9.1.1 Creating a processing setup

To create a data-processing setup, select **File>>New** from the menubar in the Data Processing Configuration window as shown in Figure 3-51. As soon as **New** is selected from the menu, ATLAS II will prompt the user for the name of the new setup as shown in Figure 3-52. Names for ATLAS II data-processing setups have the same restrictions as normal Microsoft Windows files.

Notice in Figure 3-52 that ATLAS II automatically saves the new data-processing setup file to the "dps" folder inside of the active hardware setup folder. In other words, by default the data-processing file will be stored in the following path:

..\ATLAS II\configurations\[active hardware setup]\dps\[new dps file]

This path is always in spite of the fact that a data-processing setup can include signals from multiple hardware setups. In those cases, ATLAS II will save the new file in the dps folder of the first hardware setup used. Nevertheless, remember that ATLAS II does not prevent the user from storing the files somewhere else in the computer; this is just the default location.

Data-processing setup files work within the context of a DAQ session (refer to Section 3.6.1 for a complete description of DAQ sessions). Therefore, the user must specify the hardware setups that are active for a data-processing setup file, exactly as is done when a DAQ session is started; the ATLAS II provides the same interface for both operations.

<u>N</u> ew	Ctrl+N			
Open	Ctrl+O		Last Updated	:
Save	Ctrl+S	gurations\dummy\dps\	03/24/2003	3 11:48:06 AM
Save <u>A</u> s			Volts to Pf	nysical units
Denien Creter Cerfinnetien	chi n	Physical Units	Slope	Intercept
Review System Configuration	Ctrl+R	counts	1.000E+0	0.000E+0
⊆lose	Ctrl+W			
jchassis_U_J3_dec_U		counts	2.000E+0	0.000E+0
chassis_0_J4_analog_0		counts	3.000E+0	0.000E+0
chassis_0_J4_analog_1		counts	4.000E+0	0.000E+0
		,		
chassis_0_J4_analog_2		counts	5.000E+0	0.000E+0
chassis_0_J4_analog_3		counts	6.000E+0	0.000E+0
chassis_0_34_analog_4		counts	7.000E+0	0.000E+0
chassis_0_J4_analog_5		counts	8.000E+0	0.000E+0
chassis_0_J4_analog_6		counts	9.000E+0	0.000E+0
chassis_0_J4_analog_7		counts	10.000E+0	0.000E+0

Figure 3-51. Creating a new data-processing setup.

When a name for the new data-processing setup file is specified, ATLAS II will present the user with the DAQ Setup window. This window, first shown in Figure 3-41, is shown again in Figure 3-53 for reference purposes.

ATLAS II uses the DAQ setup window to determine the active signals for the conversion process. The information in this window also specifies the format of the signals in the data frame. This is because ATLAS II assumes that the order of the signals in the configuration table is the same as that present in the data frames. This assumption is based on the fact that each hardware setup is related to a specific data-decoder card and the signal order within each hardware setup is the signal order of the data frame.

Specify a name f	or the new file.				? ×
Save jn:	🔁 dps		•	+ 🗈 💣 🎟-	
History Desktop My Computer My Network P	dummy.dps				
	File <u>n</u> ame:	system		•	<u>S</u> ave
	Save as <u>t</u> ype:	Custom Pattern (*.dps)		•	Cancel

Figure 3-52. Specify a name for the new .dps file.

It should be pointed out that ATLAS II does not prevent the user from manually changing the signal order in the configuration table. This functionality simplifies the creation of the data-processing setup. Nevertheless, the user is warned that modifying the signal order in the configuration table (from that in the individual hardware setups) will cause ATLAS II to produce erroneous EU data.

Þ	ATLAS II - Set Communications	\times
	Transmission Protocols Communication R5-422 Decoder 0	
	- System Configuration	1
	Setup Name Select a Setup 💽	
	OK Cancel	

Figure 3-53. DAQ setup window.

Once a name for the new data-processing setup file and the names of the systems setups from which to get the signal list will be determined have been specified, the ATLAS II will populate the configuration table with all the signals and set default values for the conversion coefficients. ATLAS II will set all "Slope" values to one (1) and all "Intercept" values to zero (0). This default configuration will produce EU values that are the same as the raw "counts" value. This allows the user to display data in the processed data mode even if the conversion factors for all signals haven't been set. At this point all conversion parameters can be set to their real test values.

To exit the window and save all changes to the file listed in the file path indicator, click the **"Done"** button. ATLAS II will immediately return to the main window.

If no changes are necessary, click the "**Cancel**" button. ATLAS II will immediately return to the main window without making any changes to the active setup file.

3.9.1.2 Opening an existing processing setup

To open an existing processing setup, select **"File>>Open"** from the Data Processing Configuration window's menubar. The file dialog window shown in Figure 3-54 will appear. This window allows the user to select what processing setup to open.

Choose the file t	o open:			? X
Look jn:	🔄 dps		- 🗢 🗈 💣 🎟	
History History Desktop My Computer My Network P	dummy.dps			
	File <u>n</u> ame:	dummy.dps	•	<u>O</u> pen
	Files of <u>type</u> :	Custom Pattern (*.dps)	•	Cancel

Figure 3-54. Loading an existing processing setup.

Once a processing setup from the list has been selected, click the "**Open**" button and ATLAS II will load that setup and make it the active processing setup. If no new file is needed, click the "**Cancel**" button and ATLAS II will return to the Data Processing Configuration window without no changes to the active processing setup.

3.9.1.3 Saving a processing setup

To save a processing setup, select "File>>Save" from the Data Processing Configuration window's menubar. No windows will appear as part of the save procedure. Instead, just look at the "Last Updated" indicator in the right side of the main window. ATLAS II updates this indicator every time the active processing setup is saved.

When the Data Configuration window is closed by clicking the **"Done"** button, ATLAS II will automatically perform a save-setup operation. This is done to make sure changes to the configuration are always detected.

3.9.1.4 Using an existing processing setup as a template

Sometimes during testing, changes to the active processing setup's configuration may need to be made in order to experiment with different configurations. In those situations, keeping the original setup configuration intact may be useful so the system can revert to it in the case that the new configuration doesn't work. For this purpose, ATLAS II offers the "save as" operation.

When the **"File>>Save As...**" option is selected from the Data Processing Configuration window's menubar, the file dialog window in Figure 3-55 will appear.

Save current file	as				<u>? ×</u>
Save jn:	🔁 dps		•	🗢 🗈 💣 🎟 •	
History Desktop My Computer My Network P	dummy.dps				
	File <u>n</u> ame:	dummy.dps		•	<u>S</u> ave
	Save as <u>t</u> ype:	Custom Pattern (*.dps)		_	Cancel

Figure 3-55. Using a processing setup as a template.

Enter the name for the new processing setup in the "File Name" control and click the "Save" button. ATLAS II will make a copy of the active processing setup and give it the name specified. Furthermore, ATLAS II will make the new processing setup the active one. Now the user can make any modifications to the processing setup's configuration safely, since the original setup is still available.

If the **"Cancel"** button is clicked, ATLAS II will return the user to the Data Processing Configuration window without making any changes to the active processing setup.

3.9.2 Enabling/Disabling Data Processing

ATLAS II can present data in two formats: raw (counts) or processed (EU). Raw data is the default data presentation mode. In this mode, all signal values are displayed in counts. Counts are the "raw" unit of every sample in the data frames transmitted by the DAS units in the system.

ATLAS II also has the ability to present data in engineering units (processed data). To enable this mode, click the **"Showing Raw Data"** button in the data display window. The button's text will change to **"Showing Processed Data"** and ATLAS II will imme-

diately switch to displaying data in engineering units. Beware that ATLAS II ability to display EU data is dependent on the user setting up a data-processing configuration file.

When the presentation of EU data is enabled, ATLAS II will try to convert the incoming raw data to EU data using the active data-processing configuration file. If no configuration file has been loaded or the files signals do not match the currently active setup, the results of the data conversion will not be correct. In the best case, ATLAS II will display raw data instead of EU data. In the worst case, ATLAS II will display a value of zero for a signal for which there is no entry in the data-processing configuration file.

To disable data processing, click the **"Showing Processed Data"** button in the data display window. The button's text will change to **"Showing Raw Data"** and ATLAS II will immediately switch to displaying data in counts.

3.10 Reviewing the Active System Configuration

Section 3.3 described how to create and manage hardware setup files. These setup files contain a complete description of the hardware configuration in a DAS units' chassis. This section describes how to review a system's complete configuration (both hardware and software settings).

Because a DAQ session can consist of multiple hardware setups (depending on the number of DAS units in the system), the data-processing information cannot be reviewed in the Hardware Configuration window. Moreover, data-processing setup files can include information about multiple hardware setups, but these files only carry software settings. Therefore, ATLAS II offers another tool that gives the user a complete snapshot of the active system's configuration. All hardware and software settings are presented.

To review the configuration of the active system, select **"File>>Review System Con-figuration"** from the menubar of the Data-Processing configuration window as shown in Figure 3-56.

🔀 ATLAS II - Data Processing Configuration 🛛 🛛 🔀						
File						
New	Ctrl+N					
Open	Ctrl+O		Last Updated			
<u>S</u> ave	Ctrl+S	gurations\dummy\dps\	03/24/2003	3 11:48:06 AM		
Save <u>A</u> s				ysical units		
<u>R</u> eview System Configuration	Ctrl+R	Physical Units	Slope	Intercept		
	Carrie	counts	1.000E+0	0.000E+0		
Close	Ctrl+W	counts	2.000E+0	0.000E+0		
chassis_0_34_analog_0		counts	3.000E+0	0.000E+0		
chassis_0_34_analog_1		counts	4.000E+0	0.000E+0		
chassis_0_J4_analog_2		counts	5.000E+0	0.000E+0		
chassis_0_J4_analog_3		counts	6.000E+0	0.000E+0		
chassis_0_J4_analog_4		counts	7.000E+0	0.000E+0		
chassis_0_J4_analog_5		counts	8.000E+0	0.000E+0		
chassis_0_J4_analog_6		counts	9.000E+0	0.000E+0		
chassis_0_J4_analog_7		counts	10.000E+0	0.000E+0		
Previous			Done	Cancel		

Figure 3-56. Reviewing a system's configuration.

The Active System Configuration window shown in Figure 3-57 should appear immediately. This window displays all hardware and software parameters within the context of the active system. ATLAS II builds this information by compiling all of the hardwarerelated settings for the hardware setups included in the active data-processing setup.

Signal Name	Physical Units	pSlope	pIntercept	Chassis-Slot	Module-Channel	
chassis_0_J2_enc_0	counts	1.000000E+0	0.000000E+0	chassis_0-02	chassis_0_J2_enc	
chassis_0_J5_strain_0	counts	2.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-0	
chassis_0_J5_strain_1	counts	3.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-1	
chassis_0_J5_strain_2	counts	4.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-2	
chassis_0_J5_strain_3	counts	5.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-3	
chassis_0_J5_strain_4	counts	6.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-4	
chassis_0_J5_strain_5	counts	7.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-5	
chassis_0_J5_strain_6	counts	8.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-6	
chassis_0_J5_strain_7	counts	9.000000E+0	0.000000E+0	chassis_0-05	chassis_0_J5_strain-7	
chassis_0_J6_digital_0	counts	1.000000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-0	
chassis_0_J6_digital_1	counts	1.100000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-1	
chassis_0_J6_digital_2	counts	1.200000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-2	
chassis_0_J6_digital_3	counts	1.300000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-3	
chassis_0_J6_digital_4	counts	1.400000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-4	
chassis_0_J6_digital_5	counts	1.500000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-5	_
chassis_0_J6_digital_6	counts	1.600000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-6	
chassis_0_J6_digital_7	counts	1.700000E+1	0.000000E+0	chassis_0-06	chassis_0_J6_digital-7	_
chassis_0_J7_strain_0	counts	1.800000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-0	
chassis_0_J7_strain_1	counts	1.900000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-1	
chassis_0_J7_strain_2	counts	2.000000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-2	
chassis_0_J7_strain_3	counts	2.100000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-3	
chassis_0_J7_strain_4	counts	2.200000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-4	_
chassis_0_J7_strain_5	counts	2.300000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-5	_
chassis_0_J7_strain_6	counts	2.400000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-6	_
chassis_0_J7_strain_7	counts	2.500000E+1	0.000000E+0	chassis_0-07	chassis_0_J7_strain-7	_
chassis_0_J8_strain_0	counts	2.600000E+1	0.000000E+0	chassis_0-08	chassis_0_J8_strain-0	
chassis_0_J8_strain_1	counts	2.700000E+1	0.000000E+0	chassis_0-08	chassis_0_J8_strain-1	_
chassis_0_J8_strain_2	counts	2.800000E+1	0.000000E+0	chassis_0-08	chassis_0_J8_strain-2	_
chassis_0_J8_strain_3	counts	2.900000E+1	0.000000E+0	chassis_0-08	chassis_0_J8_strain-3	
chassis_0_J8_strain_4	counts	3.000000E+1	0.000000E+0	chassis_0-08	chassis_0_38_strain-4	
chassis_0_J8_strain_5	counts	3.100000E+1	0.000000E+0	chassis_0-08	chassis_0_38_strain-5	
•			1	•	•	

D' 2	A	n ,		• 1
Figure 3-5/.	Active	System	Configuration	window.

Use the horizontal scrollbar to view additional signal parameters. The first five columns of parameters exist for all signals. These parameters are identified by their respective column's label. The rest of the columns display parameters that vary depending on the type of transducer from which they originate. Those parameters start with the column labeled "Channel-Settings". For these parameters, the actual table cell includes both the parameter name and it's setting.

Use the vertical scrollbar to view additional signals. To help track a single signal's parameters, the user can click on the signal name. This will cause ATLAS II to highlight the complete row making it easy to focus in the signal's parameters.

As shown in Figure 3-57, the Active System Configuration window has an option to produce a hardcopy of the contents of the window. When the **"Print Configuration"** button is pressed, ATLAS II will send a printer-friendly version of the table to the default printer. Please, remember that it may take Windows several seconds to process the print request.

To exit the Active System Configuration window, click the **"Done"** button. ATLAS II will return to the Data Processing Configuration window.

3.11 Recording (Archiving) Data

No data acquisition system is complete without the ability to record the test data acquired. ATLAS II is capable of recording the incoming data to a file. This section describes the application interface that can be used to control the data recording routines.

3.11.1 Starting a Data Recording session

A Data Recording session is the interval of time during which ATLAS II is recording the incoming data frames, regardless of its duration in time.

To start a Data Recording session, select **Recording>>Start Recording** from the menubar of the ATLAS II main window as shown in Figure 3-58.

🔁 ATLAS II - System Statu	5			
System Acquisition Recording	<u>U</u> tilities	<u>H</u> elp		
System Setup dumr	ure Data <u>R</u> e		itrl+R	Events
	<u>ecording</u>		itrl+S itrl+X	
Sampling Rate 300.0 Ch	annels 21	Bit Rate 10	5.263E+3	OTI
Chassis	Link	Dropouts	TSLD	
N/A	0	0	N/A	
N/A	0	0	N/A	
N/A	0	0	N/A	
N/A	0	0	N/A	
Data Recording Status				
Conditional Setup default.dr	s Re	cording Mode		•••
File Format	Da	ata Format 🗌		
File Duration 600 [s	ec] File f	4ode 📃		
Status Data recording is disabled.				
			е	×it

Figure 3-58. Starting a data recording session.

The data-recording setup window (Figure 3-59) will appear. This window allows the user to specify the configuration parameters required for the successful recording of incoming data frames.

🔁 ATLAS II - Configure Data Recordii	ng 🔀
Data Destination	
Data File	
	b
Recording Settings File Duration 600 [sec]	Samples 0.000E+0
Rec Mode Single-File 💽	File Format ASCII
File Mode Delete incomplete files 💌	Data Format Raw (counts) 💌
	OK Cancel

Figure 3-59. The data-recording setup window.

There are several configuration parameters in the configuration window. A description for all parameters is offered below:

- Data Destination Section: When the Rec Mode is set, ATLAS II changes the Data Destination section to display the appropriate path control. If Rec Mode is Single-File, the path control will show a Data File label as shown in Figure 3-59. This control will let the user specify the name of the new *file* to which data is to be saved. Use the browse button next to the control to select the destination folder where the file will be saved.
- File Duration This control specifies the size, in seconds, of each acquisition file created during the data-recording session. The minimum file size is ten (10) seconds. The maximum file size is one day (86,400 seconds).
- **Rec Mode** The data-recording mode. This control has two possible settings: Single-File and Continuous. It allows the user to specify whether the datarecording operation will be limited to one file or if it will continue indefinitely until the user manually stops it.

If **Rec Mode** is Continuous, the path control will show a **Data Directory** label. This control will let the user specify the name of the *folder* in which data will be saved. ATLAS II will automatically name the data files it creates according to the system date and time. Finally, the user can use the browse button next to the control to select the destination folder where the files will be saved.

- File Mode Controls what happens when the data-recording session is terminated. In the current software revision it has only one possible value: Delete incomplete files. This means that when the user commands ATLAS II to stop data recording, ATLAS II must stop data recording immediately and delete any data files that didn't accumulate the data samples specified in "File Duration".
- **Samples** This indicator (no data input allowed) displays the size of the acquisition file in samples. ATLAS II will calculate this number based on the value of "File Duration" and the system's sampling rate. It is displayed to give the user an idea of the space requirements of the recording operation.
- File Format Controls how ATLAS II stores sampled values in the data file. It has three possible settings:
 - **ASCII** ATLAS II will store samples in text format. This format provides the greatest compatibility with other applications (any word processor or spreadsheet application can read the file). It also generates the largest data files.
 - Zip Same as ASCII mode. However, once ATLAS II completes a data file, it will create a compressed (.zip) file that includes both the data file and its associated header file. This file format is the recommended format as it maintains data compatibility without sacrificing storage. The format of the compressed file is the industry-standard ZIP format.
 - **Binary** ATLAS II will store samples in binary format. This format generates the smallest data files at the expense of data compatibility. Only ATLAS II will be capable of reading data files generated in this format.
- **Data Format** Specifies the type of data samples to be stored. ATLAS II will generate data files according to this setting regardless of the data display mode during the data-recording session. It has two possible settings:
 - Raw (counts) Samples will be stored in their original (counts) format.
 - **Processed (EU)** ATLAS II will process all signals according to the *ac-tive* data-processing setup file and store the resulting EU values in the data file.



Make sure the correct data-processing setup file is loaded before starting a data-recording session that uses the Processed (EU) format. If the wrong file is selected, the data will not be valid.

3.11.2 Stopping a Data Recording session

As soon as a data-recording session is started, ATLAS II updates the "**Recording**" menu in the main window to reflect the new system state. Another change implemented is that the "**Start Recording**" menu option will be disabled and the "**Stop Recording**" option next to it will be enabled.

To stop a data-recording session, select **Recording** >>**Stop Recording** from the menubar of the ATLAS II main window. The data-recording activity LED in the main window should turn red immediately. In addition to the activity LED, the data-recording status information is reset and the main window will look as if the application had just started.

Stopping data recording does not stop data acquisition. The user can stop and re-start data recording at any time during a DAQ session. The only dependency between the two processes is that there must be an active DAQ session before data can be recorded. However, even this restriction exists only in practical terms. The user *can* have an active data-recording session when there is no acquisition enabled, but it should not be performed as ATLAS II has no data to record.

Another way data recording can be stopped is by exiting the application. Before it terminates, ATLAS II will attempt to stop all on-going processes (acquisition, display, recording, etc.). However, this is not the best way to terminate these processes since they are in effect being aborted, but there will be no data corruption. Be aware that even in that case, the "File Mode" setting still controls how recording is going to be terminated.

3.11.3 Reading the Data Recording Status information

Figure 3-60 shows the ATLAS II main window during a typical data-recording session. In this section we'll discuss the significance of the data-recording status information presented in the bottom section of the window.

The first status indicator to notice is the data-recording activity LED. This LED is similar in function to the DAQ activity LED shown in the upper part of the window. Its color is red (with an "OFF" label) when data recording is disabled and green (with an "ON" label) when data recording is enabled.

The "Conditional Setup" indicator is not used by the current version of ATLAS II. It should always display the text "default.drs" as shown in Figure 3-60.

em <u>A</u> cquisition <u>R</u> ecordi	ling <u>U</u> tilities <u>H</u> elp
stem Setup dummy.sys;	8
Data Acquisition Status —	
Sampling Rate 300.0	Channels 21 Bit Rate 105.263E+3
Chassis	Link Dropouts TSLD
chassis_0	0 0:00:01:0
N/A	0 N/A
N/A	0 N/A
N/A	0 N/A
Data Recording Status	drs Recording Mode Continuous Zip Data Format Processed (B [sec] File Mode Delete incomplete f

Figure 3-60. Main window showing active data-recording status.

Most of the indicators in the data-recording status area are the same parameters presented in the data-recording setup window (Figure 3-59). Refer to the previous section for a description of those parameters.

The remaining indicator is the Status indicator. This indicator serves as a generalpurpose status display. Its data varies depending on the state and progress of the datarecording operation. For example, whenever data recording is not active, the indicator will display the text "Data recording is disabled."

When a data-recording session is started, the "Status" indicator will change to display the text "Filling Buffer: ## of ## Samples" as shown in Figure 3-60. ATLAS II will continuously update the indicator to reflect the progress of the data-recording operation.

3.12 Using System Events (Automating ATLAS II)

To optimize its use and enhance user productivity, ATLAS II provides a tool that allows the user to automate its response to certain events. That tool is called "System Events". This section describes the application interface used to control the system events engine included in ATLAS II.

Within the scope of ATLAS II, system events are a collection of stimulus and response (in this case event and response) combinations that give ATLAS II a sophisticated and automated way to behave under different test conditions. Examples of system events are:

- Highlight a particular signal's plot whenever its value goes above a threshold.
- Start recording data when the value of signal X crosses a threshold.
- Send an e-mail to a staff member when the value of signal X crosses a threshold.

As illustrated by these examples, in each case there is an event (a signal crossing a threshold value) and a response (highlight plot, start recording, or send e-mail). ATLAS II allows the user to create lists of events that the application will monitor. Furthermore, the user can create a list of responses for *each* event. This way the user can create arbitrarily complex and very specific patterns of behavior for ATLAS II.

The rest of this section will describe in detail how to define events and the response of ATLAS II to their occurrence.

3.12.1 Introduction to System Events

To configure system events, select **System>>Configure System Events...** from the menubar of the ATLAS II main window as shown in Figure 3-61. The System Events Configuration window (Figure 3-62) will appear immediately.

The System Events Configuration window is divided into four main groups: menubar, active setup, events configuration, and responses configuration. The menubar is a normal Windows-application menubar. Its options will be discussed later on in this Chapter.

🔁 ATLAS II - System Status			
System Acquisition Recording	<u>U</u> tilities <u>F</u>	<u>H</u> elp	
Configure <u>H</u> ardware	Ctrl+C		Events
Configure Data Processing	Ctrl+P		
Configure System <u>Events</u>	Ctrl+E	Bit Rate 105.2	263E+3
Enable System Events Disable System Events	Ctrl+N Ctrl+M	Dropouts	TSLD
E⊻it	Ctrl+W	0	N/A
N/A	0	0	N/A
N/A	0	0	N/A
N/A	0		N/A
Data Recording Status			
Conditional Setup default.drs	Re	cording Mode	271
File Format	Da	ta Format	
File Duration 600 [sec	:] File N	1ode	
Status Data recordi	ng is disabl	ed.	
·			exit

Figure 3-61. Configuring System Events.

Before starting the description of system events, it is worthwhile to mention a couple of points about them.

First, the user can operate ATLAS II completely without ever setting up and enabling system events. This is an advanced feature included for customizing ATLAS II, and its use is recommended for advanced users only. To use events, the user has to understand the effect of the event on the acquisition system and the nature of the responses that can be defined.

Moreover, the user must understand there are different types of system events. Some events are single-occurrence, which means the responses associated with them are themselves events (short duration actions), and they cannot be reset. Because they cannot be reset, these events are very susceptible to noise in the discriminator signal. The user must take into consideration the effect of a specific event being triggered repeatedly (maybe at a fast rate) because its discriminator signal is noisy.

Other events have more of a "state marker" nature. This means that the response causes a state change in the program and their signaling is persistent. These events can be reset. As a matter of fact, ATLAS II will automatically monitor the discriminator signal for this type of event and reset the responses when appropriate. These events are not as susceptible to noise in the discriminator signal.

🔁 System Events Configural	tion	2
<u>File</u> <u>C</u> onfiguration		
System Events File:		
웹 <not a="" path=""></not>		
- Signals Source		
Data Processing File:		
8		
Event Definitions		
Events Source	Operator	Threshold Physical Units 🔺
		+
		+
	Edit Event	Add Event Remove Event
Responses List		<u> </u>
	Edit Response	Add Response Remove Response
		Accept Cancel

Figure 3-62. System Events Configuration window.

The active setup area (shown in Figure 3-63), lets the user examine the system configuration to which the system events will be associated.

System Events File:
名 <not a="" path=""></not>
🖵 Signals Source
Data Processing File:
<u>1</u>

Figure 3-63. Active setup area of the SE Configuration window.

The "System Events File" indicator displays the name of the system events setup file being edited. If the setup has not been saved or if no setup has been loaded, the indicator will display <Not A Path> (as shown in Figure 3-63).


The middle of the window shows the events configuration area. This section of the window (shown in Figure 3-64) is where the user will define and manage all the events ATLAS II needs to monitor. To make an event the active event (for editing purposes), click the entry for that event in the "Event Definitions" table. The editing buttons (Edit, Add, and Remove) always act on the active event.

Events Source	Opera	ator	Threshold	Physical Units

Figure 3-64. Events configuration area of the SE Configuration window.

The bottom of the System Events Configuration window (Figure 3-65) shows the responses configuration area. This section of the window is where the user will define and manage all the responses that ATLAS II must execute whenever a specific event (called the source event) is detected. To make a response the active response (for editing purposes), click the entry for that response in the "Responses List" table. Just like when editing events, the editing buttons (Edit, Add, and Remove) always act on the active response. To find the definition for a particular response the user must first make active its source event. Every time an event is selected in the "Event Definitions" table, ATLAS II automatically loads the Responses List table with the responses specific to that event. Remember that each event can trigger multiple responses. In fact, the user can create an event with no responses (not very practical) just as easily as creating an event with a dozen responses.

-	Edit Res	se 📔 Add Respo	nse Remo	ľ



3.12.2 Creating a new events setup

There are several ways to create a new system events setup file. The user can create the setup file first and then add configuration information to it or a configuration can be created and then saved in a system events setup file. For simplicity, this section only describes how to create a system events setup file using the second approach.

The first step in creating a system events setup is to associate the setup with a dataprocessing setup file. This is required because system events operate on processed (EU) data. Moreover, the data-processing setup file provides the list of signals that can be used as event sources. Thus, associating the system events setup with a data-processing setup guarantees that both the correct signals and their respective EU conversion parameters will be valid.

To associate the system events with a data-processing setup, click the folder icon to the right of the "Data Processing File" indicator (see Figure 3-63). ATLAS II will open a file dialog window that can be used to browse through the computer's directory structure and select a data-processing file. Once a file is selected, its complete path will be displayed in the "Data Processing File" indicator.

3.12.2.1 Defining a system event

Once a data-processing setup file has been associated with the system events, the user can define any number of events for ATLAS II to monitor.

To create a new event definition, click the **Add Event** button in the Events Configuration area of the System Events Configuration window (see Figure 3-64). The Event Definition window (Figure 3-66) will appear immediately.

🔁 Define a new System Event			×
Event Definition			1
Signal Name	Operator	Threshold Physical Units	
GBU_12345 💽	Invalid operator	0.000E+0	
			1
		Accept Cancel	
			-

Figure 3-66. Event Definition window.

Click the **Signal Name** control (it is a drop-down list) to select a signal for the event source. Once the signal is selected, ATLAS II will update the **Physical Units** indicator. ATLAS II will assume the values entered in this window are expressed in the units shown in the **Physical Units** indicator.

Next to the **Signal Name** control is the **Operator** control. This control lets the user specify the condition for triggering the event. Figure 3-67 shows all of the available options for the operator control as of this release of ATLAS II.

🔁 Define a new System Event		×
- Event Definition	Invalid operator	
Signal Name	< (Less than) <= (Less than or Equal to)	Threshold Physical Units
GBU 12345	\checkmark = (Equal to)	0.000E+0
	>= (Greater than or Equal to)	
	> (Greater than)	
	<> (Not Equal To)	Accept Cancel

Figure 3-67. Operator options for event triggering.

Enter the discriminator value in the **Threshold** control. Again, ATLAS II assumes that threshold is expressed in the units indicated by **Physical Units.** This completes the definition of an event.

Once the definition is complete, click the **Accept** button. This will return the user to the "System Events Configuration" window. At this point, ATLAS II will display the newly

created event in the "Events Definitions" table and will make it the active event. Figure 3-68 shows an example of how the "System Events Configuration" window will appear.

Since the new event is already set as the active event, the response(s) for this specific event can now be defined.

System Events Configuration	n		
ile <u>C</u> onfiguration			
System Events File:			
입 <not a="" path=""></not>			
Data Processing File:			
	es-ii\source\configurations\PW_GB	U\dps\power-works	s.dps 🗁
Event Definitions			
Events Source	Operator	Threshold	Physical Units
windy_battery_monitor	< (Less than)	26.000E+0	Volts
			_
	Edit Event	Add Event	Remove Event
		Add Evenic	Remove Event
Decrement link			
Responses List			A
	Edit Response	Add Response	Remove Response
			Accept Cancel
		-	

Figure 3-68. Example of a newly created event.

3.12.2.2 Defining a response to an event

Responses have to be associated to an event. Therefore, before defining any responses the user has to activate (select in the Event Definitions table) the event. Once activated,

the user can define multiple responses for ATLAS II to execute when the event is detected.

To create a new response definition, just click the **Add Response** button in the Responses Configuration area of the System Events Configuration window (see Figure 3-65). The Response Definition window (Figure 3-69) will appear immediately.

Define a response to the system event.	×
Response to Event – No Response	
Comments	*
	Accept Cancel

Figure 3-69. Response Definition window.

The main control of the Response Definition window is the **Response to Event** dropdown list. This control lets the user choose what type of response should be created. When the user selects a different response type, ATLAS II will change the contents of the window to show the controls appropriate for the type of response selected.

As of this writing, ATLAS II supports five categories of responses. These are:

- No Response
- Highlight Channel Plot
- Application Event
- Send E-mail
- Send Pager

"No response" option:

The first category, "No Response", is a no-operation response. Even though this could be considered of very little practical value, it is a great troubleshooting tool, because the contents will be written to the log file. When "No Response" is selected, ATLAS II will record the data in the **Comments** control into the application's event log. This event log is created automatically in the system's temporary folder every time ATLAS II executes. It is a text file that can be used to record information about the application's execution. Moreover, whenever an error happens during the execution of the program, ATLAS II saves a description of the error to the event log together with some troubleshooting information.

The "No Response" option is not the only one that saves event information to ATLAS II event log. All response types save a description of their occurrence to the log. However, as the name implies, the "No Response" option doesn't cause any ATLAS II actions while the other response types will cause ATLAS II run-time actions.


"Highlight Channel Plot" option:

The "Highlight Channel Plot" option, shown in Figure 3-70, does not require any additional parameters. This response will command ATLAS II to highlight the plot of the event source's signal in the Data Display window. Highlighting the plot means that the signal's plot will be drawn with a thick line and that its digital value indicator will be colored with a red background and set to blink.

The highlighting will stay enabled for as long as the event is in the specified range. As soon as the signal value moves outside the events range, ATLAS II will return the plot and digital value indicator to their normal state.

Just as with the "No Response" case, anything the user enters in the **Comments** control will be recorded in the event log when the source event is detected.

🔁 Define a response to the system event.	×
Response to Event – Highlight Channel Plot	
Comments	
Accept Cancel	



"Application Event" option:

The "Application Event" option, shown in Figure 3-71, contains a sub-category of responses. This means that the user has several options for applications events to be executed when the source event is detected. "Application Event" means that all of the specified responses will change the execution flow of ATLAS II when the associated event occurs.

🔁 Define a response to	the system event.			×
Response to Event -	Application Event]		
Comments	✓ Display notice Start Recording Stop Recording Stop Acquisition Shutdown ATLAS			Ī
			Accept Canc	el

Figure 3-71. Response Definition window showing Application Event option.

- Application Event: Display Notice When this option is selected or specified, ATLAS II will display a standard message box. The message box will have an "Acknowledge" button and will contain the text entered in the Comments control. As of this release of ATLAS II, the notice window is a modal window. This means ATLAS II execution is halted until the notice is acknowledged.
- Application Event: Start Recording When this option is selected or specified, ATLAS II will start recording data when the event is detected. Data will be recorded according to the last data-recording configuration used. Therefore, before setting this response option, verify that the data-recording configuration that ATLAS II will use is the correct one.
- Application Event: Stop Recording When this option is selected or specified, ATLAS II will stop recording data as soon as the event is detected. Refer to Section 3.11.2 "Stopping a Data Recording session" for more information on the process of stopping a data-recording session.
- Application Event: Stop Acquisition When this option is selected or specified, ATLAS II will stop acquiring data when the event is detected. This response is equivalent to the user selecting Acquisition>>Stop Data Acquisition from the menubar of ATLAS II' main window. Remember that terminating an acquisition session automatically disables the monitoring of system events.

• Application Event: Shutdown ATLAS II – When this option is selected or specified, ATLAS II will shut itself down when the event is detected. This response is equivalent to the user selecting System>>Exit from the menubar of the ATLAS II main window or just clicking the Exit button in the ATLAS II main window.

Just as with the "No Response" case, anything the user enters in the **Comments** control will be recorded in the event log when the source event is detected.

"Send E-mail" option:

The "Send E-mail" option, shown in Figure 3-72, commands ATLAS II to send an e-mail whenever the source event is detected. The response parameters allow the user to specify for whom the message is intended and the contents of the message.

Because ATLAS II will send an e-mail *every time* the event is signaled, this response can have very undesired results if it is associated with a noisy signal as its event source. Be aware of this when configuring this type of response.

Define a response to the system event.		×
Response to Event - Send E-mail		
То	Subject	
Comments		
		*
	Accept	Cancel

Figure 3-72. Response Definition window showing Send E-mail option.

The fields of the "Send E-mail" option are:

- **To** Specifies the complete address (i.e., <u>name@entity.domain</u>) of the intended recipient. This release of ATLAS II does not support multiple recipients for an e-mail. If multiple recipients are required, create a separate "Send E-mail" response for each recipient.
- **Subject** The topic of the message.
- **Comments** The body of the message. ATLAS II doesn't have a pre-set limit for the size of the message.

ATLAS II also needs information defining the source of the e-mail. Because the source is the same for every message, its configuration window is outside of the Response Definition window. To set the e-mail source parameters, select **Configuration>>E-mail Set-tings** from the menubar of the System Events Configuration as shown in Figure 3-73.

System Events Configuration			X
File Configuration			
Sy <u>E-mail Settings Ctrl+E</u> Sy Pager Settings Ctrl+A SINUL A Patrl>			
- Signals Source			
Data Processing File:			
%F:\development\atlas\series-i	\source\configurations\PW_GB	U\dps\power-works	s.dps 🕒
Event Definitions			
Events Source	Operator	Threshold	Physical Units 🔺
windy_battery_monitor	< (Less than)	26.000E+0	Volts
			IIII
			<u> </u>
			v
	Edit Event	Add Event	Remove Event
Responses List			A
			v
	Edit Response	Add Response	Remove Response
			Accept Cancel

Figure 3-73. Configuring the e-mail sender's parameters.

The E-mail Account Setup window (Figure 3-74) will appear immediately. In this window the user can specify the parameters for the e-mail account responsible for generating all of the ATLAS II e-mail messages. In other words, this is the address displayed in the "From" field in the recipient's e-mail client.

The most important parameter is the "E-mail server". This is the address of the mail server used by users in the network in which ATLAS II is running. No e-mail will be

delivered if this parameter is not correct. The company's network administrator usually is the person who manages the address of the e-mail server.

If the e-mail server requires users to sign on, the user must specify the user name and password in the "Username" and "Password" controls respectively. Again, this is information can be provided by the network administrator.

E-mail Account Setup	×
E-mail Server:	
Username:	
Password:	
ок	ancel

Figure 3-74. E-mail Account Setup window.

ATLAS II will store the account information in its configuration file. The data is encrypted before being stored, so there is little risk of security problems.

"Send Pager" option:

The "Send Pager" option, shown in Figure 3-75, commands ATLAS II to send a page whenever the source event is detected. The response parameters allows the user to specify the recepient and the contents of the message.

Because ATLAS II will page the recipient *every time* the event is signaled, this response can have very undesired results if it is associated with a noisy signal as its event source. Please be aware of this when configuring this type of response.

Define a response to th	e system event.	×
Response to Event	Send Pager	
Service #	Unit #	🗖 alpha-numeric
Comments		
		×
		Accept Cancel

Figure 3-75. Response Definition window showing Send Pager option.

The fields of the "Send Pager" option are:

- Service # The phone number that ATLAS II dials to access to the paging network.
- Unit # The number of the recipient's unit within the paging network.
- Alphanumeric Check this box if the recipient's unit accepts alphanumeric messages. Leave it un-checked if the recipient's pager only accepts numeric messages.
- **Comments** The body of the message. The user can enter any text in this area. ATLAS II doesn't have a pre-set limit for the size of the message.

Once the definitions are completed, click the **Accept** button. This will return the user to the "System Events Configuration" window. ATLAS II will display the newly created response in the "Responses Definitions" table and will make it the active response. Figure 3-76 shows an example of how the "System Events Configuration" window will look after an event with one response has been defined.

So far, this section has described how to create a basic system-events configuration: One event with one response. However, the configuration has not yet been saved. The last step in creating a system events setup is to save the configuration to a file. There are several ways this can be accomplished.

To create a setup file the user clicks the **Accept** button in the "System Events Configuration" window. If a file has not been specified for the active configuration, ATLAS II will display a file dialog window. Use this window to select a destination folder for the new file. ATLAS II will suggest the following path:

..ATLAS II\configurations\[active hardware setup]\ses

Notice that the **Accept** button is a "save-and-exit" option. This means that ATLAS II will save the active system events configuration, close the "System Events Configuration" window and return to ATLAS II' main window.

If the **Cancel** button is clicked in the file dialog that appears to save a new file, ATLAS II will still close the "System Events Configuration" window and return to ATLAS II main window. Any configuration data that has not been saved will be lost.

System Events Configuration			×
Eile Configuration			
System Events File:			
% <not a="" path=""></not>			
Signals Source			
Data Processing File:			
-	source\configurations\PW_GBU\	dps\power-works.dp	os 🗁
Event Definitions			
Events Source	Operator	Threshold 1	Physical Units 🔺
windy_battery_monitor	< (Less than)	26.000E+0	Volts
			•
	Edit Event	Add Event	Remove Event
			Kelilöve Event
Responses List			
Application Event - Start Recor	ding		
	Edit Response A	dd Response	emove Response
		A	ccept Cancel
]			

Figure 3-76. Example of a newly created event and response.

3.12.3 Editing an event setup

The previous section discussed how to create a new system events setup file. This section will discuss the process of modifying an existing setup. This will allow the user to fine-tune the responses to the events or to add more event-response pairs to a setup.

3.12.3.1 Editing a system event

In this discussion it is assumed that an event setup similar to the one in Figure 3-76 has been loaded. The information on the screen may be different if another setup is used. Nevertheless, the actions and windows that must be executed will be the same.

To edit an existing event, the user must first make that event the active event by clicking on it. This will highlight the event's row in the "Event Definitions" table. Once highlighted, click the **Edit Event** button right below the "Events Definition" table. The "System Event Editor" window (as shown in Figure 3-77) will appear.

System Event Editor					×
- Event Definition					
Signal Name	Op	erator	Threshold	Phys	sical Units
windy_battery_monitor	< (Les	ss than)	26.000E+	D Volts	
				ОК	Cancel
					·

Figure 3-77. System Event Editor window.

The "System Event Editor" window has the same design as the "Event Definition" window (shown in Figure 3-66) used to define the event. They were designed that way to improve ease-of-use. Moreover, because their design is the same, their use is also the same, i.e., editing an event is done with the same process as defining a new event. Please refer to Section 3.12.2.1 "Defining a system event" for more information on defining a system event.

3.12.3.2 Editing a response to an event

To edit an existing response two things must be done. First, the user must activate the source event for the response the active event by clicking on it. This will highlight the event's row in the "Event Definitions" table. Next, the user must activate the response the active response by clicking on it. This will highlight the response's row in the "Responses List" table. Once the response is highlighted, click the **Edit Response** button

right below the "Responses List" table. If the user clicks the **Edit Response** button before selecting the source event or before selecting any response, ATLAS II will display a window (Figure 3-78) alerting the user of the missing steps.

	×
ОК	
	o select an ever onses to enable OK

Figure 3-78. Application notice for invalid request.

Once the response is highlighted, click the **Edit Response** button right below the "Responses List" table. The "System Response Editor" window (Figure 3-79) will appear.

🔀 System Response Editor	×
Response to Event Application Event	
Start Recording	
Comments	
	*
	Accept Cancel

Figure 3-79. System Response Editor window.

The "System Response Editor" window has the same design as the "Response Definition" window (Figure 3-69) used to define the response. They were designed that way to improve ease-of-use. Moreover, because their design is the same, their use is also the same, i.e., editing a response is done with the same process as defining a new response. Please refer to Section 3.12.2.2 "Defining a response to an event" for more information on defining a system response.

3.12.4 Managing System Events Setup files

Section 3.12.2 "Creating a new events setup" explained the process used to create a basic system events setup. This section describes the functions that let the user manage the

files where the setups are stored. To simplify the learning process, the functions used are standard Windows file-management functions.

3.12.4.1 Opening an existing system events setup

To open an existing system events setup, select **"File>>Open"** from the "System Events Configuration" window's menubar. ATLAS II will immediately display a standard Windows file dialog window. Use this window to select the system events setup to open. By default, ATLAS II restricts the file types displayed in the file dialog window to those with a ".ses" extension. That extension is the only extension ATLAS II supports for system events setup files.

Once a setup has been selected, click the **"Open"** button and ATLAS II will load it. If the existing active system events setup is adequate, click the **"Cancel"** button and ATLAS II will return to the "System Events Configuration" window without making any changes to the active system events setup.

3.12.4.2 Saving a system events setup

To save a setup, select **"File>>Save"** from the System Events Configuration windows menubar. There will not be any visible confirmation of the save, (no windows will appear). ATLAS II will simply overwrite the file for the active system events setup.

As discussed in Section 3.12.2 "Creating a new events setup", ATLAS II will perform a "save-and-exit" operation when the user clicks the **Accept** button in the "System Events Configuration" window. This is true whether or not the setup being saved is a new setup or an existing one. If the setup is a new one, a file dialog window will appear just as described in Section 3.12.2.

However, if the setup is an existing one, ATLAS II will not display the file dialog window. It will, nonetheless, perform the save before exiting the "System Events Configuration" window, overwriting the previous system events file with the new information.

3.12.4.3 Using an existing system events setup as a template

Sometimes during testing, there may be a times when changes to the active system events setup's configuration are desireable. In those situations, it may be important to keep the original setup configuration intact as a backup. To help the user execute that testing, ATLAS II offers the "save as" operation.

When the **"File>>Save As..."** is selected from the "System Events Configuration" window's menubar, ATLAS II will display a file dialog window so the user can choose the new name for the setup.

Enter the name for the new setup in the "File name:" control and click the "Save" button. ATLAS II will make a copy of the active system events setup and give it the specified name. Furthermore, ATLAS II will make the new setup the active one. Now modifications to the setup's configuration can be safely made, knowing the original setup is still available in case it is needed.

If the **"Cancel"** button is clicked, ATLAS II will return the user to the "System Events Configuration" window without making any changes to the active system events setup.

3.13 Other Software Utilities

This section describes a utility that supplements the data acquisition process. This utility can help the user set up the system, but it is not required for the correct utilization of the rest of the ATLAS II software features.

3.13.1 PATSyM Diagnostics Utility

If the ATLAS II system contains a PATSyM module, this software can be used to monitor the GPS data link. To activate the GPS Communications window, select **Utilities>>Test GPS Communications** from the menubar of the ATLAS II main window as shown in Figure 3-80. Selecting this option brings up the GPS Communication window shown in Figure 3-81.

ATLAS II - System Status				_ 🗆 🗵
System Acquisition Recording	Utilities	<u>H</u> elp		
System Setup dummy.sys;	⊆alibr	te Strain Gaug ate Strain Gau		Events
Data Acquisition Status	Lest :	itrain Gauges		
Sampling Rate 300.0 Char	Test (PS Communica	ations -3	077
Chassis	Link	Dropouts	TSLD	
N/A	0	0	N/A	
N/A	0	0	N/A	
N/A	0	0	N/A	
N/A	0	0	N/A	
Data Recording Status				
Conditional Setup default.drs	R	ecording Mode		•
File Format		ata Format 🗌		
File Duration 600 [sec] File	Mode		
Status Data recordir	ng is disal	oled.		
				exit

Figure 3-80. Testing a PATSyM's communications link.




Figure 3-81. GPS Communications window.

Among other features, the GPS window allows the user to: monitor the GPS timing information, monitor the current number of satellites in view, control the GPS module, and, most importantly, determine whether the GPS receiver has a valid solution (i.e., whether its locked to UTC). The "GPS Valid" LED will be green when the system is locked to UTC.

The GPS Communication window, seen in Figure 3-81, can be broken down into four distinct parts. The top part contains the specific RS-232 settings and protocol. The software configures the computer serial port automatically; if any errors are detected sending or receiving serial commands, the error is flagged. In the left part of the window, a series of inline switches can be used to control the GPS device. The default settings should be used for most applications. In the center of the window, several commands can be sent to the PATSyM to select the operating mode. Device 1 turns on the PATSyM module. This is the default state of the module every time it is powered on. Device 2 sends a command that instructs the PATSyM to shut off the GPS communication and enable two-way user communication with the DAS. The Device 2 option should be selected prior to programming the DAS if the RS-232 communication goes though the PATSyM module. Devices 3 and 4 are features that are not supported at the moment, but will be supported at a later time.

The GPS Communications window contains no specific acquisition-hardware settings; the ATLAS II system can be properly configured without entering this window. If the

ATLAS II system contains a PATSyM module and is wired as recommended in this document, this window must be accessed to turn off GPS data-transmission before a DAS chassis can be programmed.

Chapter 4. References

Berg, D.E, Zayas, J.R.. 2001. Accurate GPS Time-Linked Data Acquisition System (ATLAS II) User's Manual. Sandia National Laboratories; Albuquerque, NM-SAND2001-1289.

Berg, D.E., and Zayas, J.R. 2001. "Accurate Time-Linked Acquisition System Field Deployment and Operational Experience," AIAA 2001-0038, *Proceedings of the 2001* ASME Wind Energy Symposium, Reno, NV, January 8–11, 2001.

Berg, D.E., Rumsey, M.A., and Zayas, J.R. 2000. "Hardware and Software Developments for the Accurate Time-Linked Data Acquisition System," AIAA 2000-0052, *Proceedings of the 2000 ASME Wind Energy Symposium*, Reno, NV, January 10–13, 2000, pp. 306-316.

Robertson, P.J., Berg, D.E., Zayas, J.R., and Gass, K.L. 1999. *Final Report and Documentation for the GPS-10K70 Board Design*. Sandia National Laboratories; Albuquerque, NM.

Berg, D.E., Robertson, P., and Zayas, J. 1999. *ATLAS II: A Small, Light Weight, Time-Synchronized Wind-Turbine Data Acquisition System*. Presented at the 1999 ASME Wind Energy Symposium in Reno, NV, January 11-14, 1998. Sandia National Laboratories; Albuquerque, NM.

Berg, D.E., Rumsey, M., Robertson, P. 1998. *Development of a Light-Weight, Wind-Turbine-Rotor-Based Data Acquisition System*. Presented at 1998 ASME Wind Energy Symposium/36th AIAA Aerospace Sciences Meeting and Exhibit in Reno, NV, January 12-15, 1998. Sandia National Laboratories; Albuquerque, NM.

Berg, D.E., Robertson, P.J., and Ortiz, M.F. 1998. *Development and Application of a Light-Weight, Wind-Turbine Rotor-Based Data Acquisition System*. Presented at Wind-power '98, Bakersfield, CA, April 27-May 1, 1998. Sandia National Laboratories; Albuquerque, NM.

Berg, D.E., and Robertson, P.J. 1998. "Precise Time Synchronization Data Acquisition with Remote Systems" *Proceedings of 1998 International Telemetering Conference*, San Diego, CA, October 26–29, 1998.

Nicolet Instrument Technologies, Inc. 1996. *Nicolet MicroPro Remote Data Acquisition System Operation Manual, Version 1.40.* P/N 269-923000. Madison, WI.

Zond Systems, Inc. 1994. Advanced Data-Acquisition System. Tehachapi, CA.

This page intentionally left blank.

Chapter 5. Technical Support

ACRA Control, Inc., 44145 Airport View Drive Hollywood, MD 20636 John Kolb 301-373-9220

Sandia National Laboratories P.O. Box 5800 Albuquerque, NM 87185-0708 Jose Zayas 505-284-9446 This page intentionally left blank.

Appendix A: Citel Protection Devices Specification Sheets

CITEL[™]

Two Pair Plug-In Module for Telephone and Data Lines E280



Citel E280 modules have been designed to dissipate the worst of power surges. They use a high speed gas tube/diode association that can arrest a surge in less than one nanosecond and provide high power handling with a tight clamping ratio.

All Citel plug - in modules protect two pairs(4 wires). They protect data lines such as RS422, RS423, RS485, RS232, DDS/56k lines, T1/E1 lines, ISDN, telephone lines, LANs on twisted pairs, Category 5 lines...etc.

E280 modules are used in conjunction with Citel bases: B10, FP10-110, B25, BN08, BN16, BN32 and F22S/MB. They permit on site repair or replacement by non-technical personnel. Each module is color coded for easy distinction between voltages or applications.

Ultra fast response time - less than 1 ns


Multi-stage circuitry

Modular presentation

Electrical Specifications E280


	E280T	E280 - 48V	E280 - 24V	E280 - 12V	E280 - 6V
Application:	Telephone Lines	Leased Lines	4-20 mA loop Lines	Telemetry	RS485
Series Resistance:	4.7 ohms	4.7 ohms	4.7 ohms	4.7 ohms	4.7 ohms
Capacitance:	70 pF	200 pF	300 pF	400 pF	900 pF
Maximum Line Current:	200mA	200mA	200mA	200mA	200mA
Maximum Line Voltage:	170V	48V	24V	15V	6V
Clamping Voltage:	190V	60V	30V	20V	10V
Residual Voltage:	220V	70V	35V	30V	20V
Power Handling: (8/20µs- 10 x's)	10 kA	10 kA	10 kA	10 kA	10 kA
Electrical. Diagrams:	2	1	1	1	1

Electrical Diagrams



- P: 3- Element Gas Tube D: Clamping Diode R: Resistor D3: 3 Element Clamping Diode

Mechanical Diagrams



Appendix B: DAQ Parts List

Parts List for Series II Data Acqusition Systems

Ground Based Data Acquisition System-Master

Item Description	Manufacturer	Part number	Qty
Enclosure 24x16x8 in. alum box w/bkpnl	Circle AW	24168-4XA	1
24 volt DC to 5 volt DC converter	Astrodyne	DH50S2405	1
24 volt DC to 8 volt DC converter	Astrodyne	QB14S24075MC	1
KAM 500 6 slot unit	ACRA Control Inc.	KAM/SYS/09U	1
Lightning protection bases	Citel, Inc.	FPSU16	4
Lightning protection modules	Citel, Inc.	E-280-6v E280-12v	32
Analog connector jamb nut-male	Spacecraft Components	SCPT07A20-24P	6
Analog connector cable end-female	Spacecraft Components	SCPT06F20-24S	6
Strain gage connector jamb nut-female	Spacecraft Components	SCPT07A20-24S	2
Strain gage connector cable end-male	Spacecraft Components	SCPT06F20-24P	2
DC power connector jamb nut-female	Spacecraft Components	PT07A8-4P	1
DC power connector cable end-male	Spacecraft Components	PT06P8-4S	1
Antenna GPS connector jamb nut-male	Spacecraft Components	JT07H-10-13P	1
Antenna GPS connector cable end-female	Spacecraft Components	JT06P-10-13S	1
Antenna box connector jamb nut-female	Spacecraft Components	JT07H-10-13S	1
Antenna box connector cable end-male	Spacecraft Components	JT06P-10-13P	1
Programing connector jamb nut-female	Spacecraft Components	LJT07-11-13S	1
Programing connector cable end-male	Spacecraft Components	LJT06-11-13P	1
Antenna cables and connectors (coax)	Amphenol	SMA	2
Fiber optics transmitter (DTE)	Fiberplex Inc.	FOI 2951-ST	1
Fiber optic cable with ST connectors	generic	multi-mode	1
Aluminum heat sink solid (K-500 side)	generic	1.50x3.25w6.25l	1
Aluminum heat sink solid (K-500 bottom)	generic	1.25x3.25x6.25	1
GPS Antenna	custom	N/A	1
GPS Receiver	custom	N/A	1
GPS Receiver box	custom	N/A	1

Note: One fiber optic transmitter is used for PC connection & one for each slave unit

Parts List for Series II Data Acqusition Systems


Ground Based Data Acquisition System power Supply

Item Description	Manufacturer	Part number	Qty
Enclosure 12x12x6 in. aluminum box w/bkpnl	Circle AW	12126-4XACHC	1
UPS Power Supply	Electro-automatic	EA-UPS 724-06A 24V / 5,6A	1
UPS battery	Electro-automatic	EA-BU 724-07A 24V / 6,5Ah	1
DIN rail mounting	Electronic supply house	N/A	1
AC power connector jamb nut-male	Spacecraft Components	PT07A8-3P	1
AC power connector cable end-female	Spacecraft Components	PT06P8-3S	1
DC power connector jamb nut-female	Spacecraft Components	PT07A8-4S	1
DC power connector cable end-male	Spacecraft Components	PT06P8-4P	1

Parts List for Series II Data Acqusition Systems

Windy-Rotor Based Data Acquisition System

Item Description	Manufacturer	Part number	Qty
Enclosure 12x12x6 in. aluminum box w/bkpnl	Circle AW	12126-4XACHC	1
Power Supply 24 volt and 5 volt DC	Cosel U.S.A.inc.	MMB75A	1
Power Supply shield	custom	N/A	1
KAM 500 6 slot unit	ACRA Control Inc.	K-500	1
Lightning protection bases	Citel, Inc.	FPSU16	4
Lightning protection modules	Citel, Inc.	E-280-6v E280-12v	32
Stand offs	generic	2.5 x .25	20
Strain gage connector jamb nut-female	Spacecraft Components	SCPT07A20-24S	6
Strain gage connector cable end-male	Spacecraft Components	SCPT07A20-24P	6
DC power connector jamb nut-female	Spacecraft Components	PT07A8-4S	1
DC power connector cable end-male	Spacecraft Components	PT06P8-4P	1
Antenna GPS connector jamb nut-male	Spacecraft Components	JT07H-10-13P	1
Antenna GPS connector cable end-female	Spacecraft Components	JT06P-10-13S	1
Antenna box connector jamb nut-female	Spacecraft Components	JT07H-10-13S	1
Antenna box connector cable end-male	Spacecraft Components	JT06P-10-13P	1
Programing connector jamb nut-female	Spacecraft Components	LJT07-11-13S	1
Programing connector cable end-male	Spacecraft Components	LJT06-11-13P	1
Antenna cables and connectors (coax)	Amphenol	SMA	2
Telemetry & Programming modems	Cirronet	WIT 2410	2
GPS Antenna	Liapac	GLP1-RA	1
GPS Receiver	Rockwell	Jupiter	1
GPS Receiver box	custom	N/A	1
RS-422 to RS-232 converter	Antona	ANC-6090	1



Appendix C: DAQ Units Layout Schematics

Figure 5-1: ATLAS II Master Unit

ALUMINUM Mounting Plate		
	24 Volt UPS	
	24 Volt Battery	
AC		DC Powerunit 02/17-03

Figure 5-2: ATLAS II Master Power Unit




Figure 5-3: ATLAS II-Rotor Unit

Appendix D: Configuring Modems

D.1 Programming the Remote and Base Modems

D.1.2 Program the Remote RS-232 Modem

The remote RS-232 modem handles all asynchronous communications on the rotor. It must be programmed once to set the communications protocol parameters properly. Although only the bare module will be used in the RBU, it must be mounted in a complete modem housing, with RS-232 interface and serial cable connection, to be programmed.

- 1. Connect the modem 9-pin connector to the computer serial port and the power cable to the 8 V power source (usually a 8-VDC transformer that plugs into a 110 VAC wall outlet).
- 2. Start the COM2400 program (a DOS program located in directory COM24) and set the communciation rate to 38,400 bps using the computer's <PgUp> or <PgDn> key. The communication rate is displayed on bottom left of the screen
- 3. Turn on the power to the modem.
- 4. The COM2400 program should display the modem firmware version and whether the modem is programmed as REMOTE or BASE. If the display is garbage characters, shift the program communication rate up or down and cycle the modem power again. The unit is probably programmed to operate at either 9,600, 19,200, 38,400 or 57,600.
- 5. After the version message is displayed, quickly press the F3 key to get the ">" prompt. Then proceed to program the modem unit. Enter the following commands (followed by the Enter key) at successive > prompts:
 - a) wn0 (sets network number to 0)
 - b) wb0 (sets base/remote to remote)
 - c) wdaa (sets destination address to AAH)
 - d) wsaa (sets source address to AAH)
 - e) wt0 (sets channel access mode to CSMA)
 - f) wp1 (sets transmit power to 100 mW)
 - g) sy0 (sets sync/async to asynchronous mode)
 - h) sd020 (sets data transmit rate to 38,400 bps)



Use the computer's <PgUp> or <PgDn> key to change the program communication speed to 38,400 before you con-

tinue – the speed is displayed at the bottom left of the screen.

- i) sp0 (sets packet mode to point-to-point)
- j) ph9c (sets hop duration to 9CH)
- k) pk0a (sets minimum packet length to 0AH)
- l) plf0 (sets maximum packet length to F0H)
- m) pt03 (sets packet timeout duration to 03H)
- n) pm40 (sets packet link margin to 40H)
- o) pr10 (sets ARQ retry limit to 10H)
- p) py02 (sets ARQ per-hop limit to 2H)
- q) pb08 (sets CSMA backoff constant to 08H)
- r) pp20 (sets CSMA persistence to 20H)
- s) ps0a (sets TDMA time slot to 0AH)
- t) pd0 (disables diversity antenna switching)
- u) m> (stores configuration to memory)
- v) z> (exits modem control mode)
- 6. The modem module should now be programmed, in asynchronous mode, and capable of communication. To check configuration settings, press F1 twice (to toggle DTR off and back on), and then press F3 once (to transmit "wit:2400", which places the modem in configuration mode). Then check the settings programmed under Step 5, above. The current setting for each command can be displayed by typing the two-letter command followed by ? (i.e., sy?, to determine whether modem is set in sync or async mode).

D.1.3 Program the Base RS-232 Modem

The Base RS-232 modem handles all asynchronous communications on the ground. This modem module will be mounted in a modem case for normal use and will be located near the master GBU.

- 11. Connect the modem 9-pin connector to the computer serial port and the power cable to a 110 VAC power source.
- Start the COM2400 program (a DOS program located in directory COM24) and set the communication rate to 38,400 bps using the computer's <PgUp> or <PgDn> key. The communication rate is displayed at the bottom left of the screen.
- 8. Turn on the power to the modem.
- 9. The COM2400 program should display the modem firmware version and whether it is REMOTE or BASE. If the display is garbage characters, shift the program communication rate up or down and cycle the modem power again. The unit is probably programmed to operate at either 9,600, 19,200, 38,400, or 57,600.

- 10. After the version message is displayed, quickly press the F3 key to get the ">" prompt. Then proceed to program the modem unit. Enter the following commands (followed by the Enter key) at successive > prompts:
 - w) wn0 (sets network number to 0)
 - x) wb1 (sets base/remote to base)
 - y) wdaa (sets destination address to AAH)
 - z) wsaa (sets source address to AAH)
 - aa) wt0 (sets channel access mode to CSMA)
 - bb) wp1 (sets transmit power to 100 mW)
 - cc) sy0 (sets sync/async to asynchronous mode)
 - dd) sd020 (sets data transmit rate to 38,000 bps)

NOTE

Use the computer's $\langle PgUp \rangle$ or $\langle PgDn \rangle$ key to change the program communication speed to 38,400 before you continue – the speed is displayed at the bottom left of the screen.

- ee) sp0 (sets packet mode to point-to-point)
- ff) ph9c (sets hop duration to 9CH)
- gg) pk0a (sets minimum packet length to 0AH)
- hh) plf0 (sets maximum packet length to F0H)
- ii) pt03 (sets packet timeout duration to 03H)
- jj) pm40 (sets packet link margin to 40H)
- kk) pr10 (sets ARQ retry limit to 10H)
- ll) py02 (sets ARQ per-hop limit to 2H)
- mm) pb08 (sets CSMA backoff constant to 08H)
- nn) pp20 (sets CSMA persistence to 20H)
- oo) ps0a (sets TDMA time slot to 0AH)
- pp)pd0 (disables diversity antenna switching)
- qq) m> (stores configuration to memory)
- rr) z> (exits modem control mode)
- 11. The modem module should now be programmed, in asynchronous mode, and capable of communication. To check configuration settings, press F1 twice (to toggle DTR off and back on), and then press F3 once (to transmit "wit:2400", which places the modem in configuration mode). Then check the settings programmed under Step 5, above. The current setting for each command can be displayed by typing the two-letter command followed by ? (i.e., sy?, to determine whether modem is set in sync or async mode).

D.2 Programming the Data Transmit and Receive Modems

D.2.1 Program the Transmit Data Modem to be Mounted in the RBU

The transmit data modem transmits acquired data from the RBU. Although only the bare module will be used in the RBU, it must be mounted in a complete modem housing, with RS-232 interface and serial cable connection, to be programmed.

- 12. Connect the modem to the computer serial port and the power cable to the 110 V power source.
- 13. Connect module signal pin 4 (CFG) to signal pin 1 (GND) on the modem module 11pin connector. This jumper must be kept in place throughout the following procedure. This will require removal of the modem housing cover to allow access to the module connector.
- 14. Start the COM2400 program (a DOS program located in directory COM24) and set the communication rate to 38,400 bps using the computer's <PgUp> or <PgDn> key. The communication rate is displayed at the bottom left of the screen.
- 15. Turn on the power to the modem.
- 16. The COM2400 program should display the modem firmware version and whether it is REMOTE or BASE. If the display is garbage characters, shift the program communication rate up or down and try again. It's probably programmed for 9600, 19,200, 38,400, or 57,600.
- 17. After the version message is displayed, quickly press the F3 key to get the ">" prompt. Then proceed to program the modem unit. Enter the following commands (followed by the Enter key) at successive > prompts:
 - ss) wn1(sets network number to 1)tt) wb0(sets base/remote to remote)uu) wdaa(sets destination address to AAH)vv) wsaa(sets source address to AAH)ww)wt0xx) wp1(sets transmit power to 100 mW)
 - yy) sy1 (sets modem into synchronous mode this will not be effective until z> is entered to terminate programming)
 - zz) sd01f (sets data transmit rate to 38,400 bps)

|--|

Use the computer's <PgUp> or <PgDn> key to change the program communication speed to 38,400 before you con-

sp0 (sets packet mode to point-to-point) aaa) (sets hop duration to 41H) bbb) ph41 (sets minimum packet length to 0AH) ccc) pk0a ddd) plff (sets maximum packet length to FFH) (sets packet timeout duration) eee) pt03 (sets packet link margin) fff) pm40 (sets ARQ retry limit to 10H) ggg) pr10 hhh) py02 (sets ARQ per-hop limit to 2H) iii) pb08 (sets CSMA backoff constant to 08H) jjj) ppff (sets CSMA persistence to FFH) kkk) (sets TDMA time slot to 0AH) ps0a lll) pd0 (disables diversity antenna switching) (stores configuration to memory) mmm) m> z>(exits modem control mode) nnn)

tinue – the speed is displayed at the bottom left of the screen.

- 18. Remove the jumper inserted in step 2, above.
- 19. The modem module should now be programmed and in synchronous mode and no longer capable of communication with the computer. To check configuration settings, power off the modem and then perform steps 2, 4, and 5, above. The current setting for each command can be displayed by typing the two-letter command followed by ? (i.e., sy?, to determine whether the modem is set in synchronous or asynchronous mode).

D.2.2 Program the Receive Data Modem

The receive data modem receives the acquired data signal from the RBU installed on the rotor. It must be located next to the master GBU. This unit will usually be situated in a modem case, so signal and power are already supplied to the module – just remove the top of the case to access the 13-pin data connector.

- 20. Jumper signal pin 4 (CFG) to signal pin 1 (GND) on the 13-pin connector. This jumper must be kept in place throughout the following procedure.
- 21. Start the COM2400 program (a DOS program located in directory COM24) and set the communication rate to 38,400 bps using the computer's <PgUp> or <PgDn> key. The communication rate is displayed at the bottom left of the screen.
- 22. Turn on the power to the modem.
- 23. The COM2400 program should display the modem firmware version and whether it is REMOTE or BASE. If the display is garbage characters, shift the program

communication rate up or down and try again. It's probably programmed for 9600, 19,200, 38,400, or 57,600.

24. After the version message is displayed, quickly press the F3 key to get the ">" prompt. Then proceed to program the modem unit. Enter the following commands (followed by the Enter key) at successive > prompts:

000)	wn1	(sets network number to 1)
ppp)	wb1	(sets base/remote to base)
qqq)	wdaa	(sets destination address to AAH)
rrr) wsaa	(sets sou	rce address to AAH)
sss)	wt0	(sets channel access mode to CSMA)
ttt) wp1	(sets tra	nsmit power to 100 mW)
uuu)	sy1	(sets sync/async to synchronous mode - this will not be
	effective	e until $z > is$ entered to terminate programming)

vvv) sd014 (sets data transmit rate to 57,600 bps)



Use the computer's $\langle PgUp \rangle$ or $\langle PgDn \rangle$ key to change the program communication speed to 57,600 before you continue – the speed is displayed at the bottom left of the screen.

www)	sp0	(sets packet mode to point-to-point)
xxx)	ph41	(sets hop duration to 41H)
yyy)	pk0a	(sets minimum packet length to 0AH)
zzz)	plff	(sets maximum packet length to FFH)
aaaa)	pt03	(sets packet timeout duration)
bbbb)	pm40	(sets packet link margin)
cccc)	pr10	(sets ARQ retry limit to 10H)
dddd)	py02	(sets ARQ per-hop limit to 2H)
eeee)	pb08	(sets CSMA backoff constant to 08H)
ffff)	ppff	(sets CSMA persistence to FFH)
gggg)	ps0a	(sets TDMA time slot to 0AH)
hhhh)	pd0	(disables diversity antenna switching)
iiii)m>	(stores co	onfiguration to memory)
jjjj)z>	(exits mo	odem control mode)

- 25. Remove the jumper inserted in Step 1, above.
- 26. The module should now be programmed and in synchronous mode, and no longer capable of communication with the computer. To check configuration settings, power off the modem, and perform steps 1, 3, and 4, above. The current setting for each command can be displayed by typing the two-letter command followed by ? (i.e., sy?, to determine whether the modem is set in sync or async mode).

Distribution List

R. N. Clark USDA Agricultural Research Service P.O. Drawer 10 Bushland, TX 79012

Trudy Forsyth NREL 1617 Cole Boulevard Golden, CO 80401

Dave Jager NREL 1617 Cole Boulevard Golden, CO 80401

Byron Neal (3) USDA Agricultural Research Service P.O. Drawer 10 Bushland, TX 79012

Richard Santos NREL 1617 Cole Boulevard Golden, CO 80401

Dave Simms (3) NREL 1617 Cole Boulevard Golden, CO 80401

MS-0708	D. E. Berg, 6214
MS-0708	P. L. Jones, 6214
MS-0708	J. Ortiz-Moyet, 6214
MS-0708	M. A. Rumsey, 6214
MS-0708	H. J. Sutherland, 6214
MS-0708	P. S. Veers, 6214 (10)
MS-0708	J. R. Zayas, 6214
MS-0899	Technical Library, 9616 (2)
MS-9018	Central Technical Files, 8945-1
MS-0161	Patent & Licensing Office, 11500