



Determinants of the Performance of Arsenic Adsorbent Media

A comparison of field and laboratory studies



**Malcolm Siegel, Alicia Aragon, Hongting Zhao,
Malynda Aragon, Randy Everett
Melody Nocon, Brian Dwyer**

**Sandia National Laboratories
Albuquerque, NM**

March 30, 2006



Arsenic Water Technology Partnership Background

- **Congressional Appropriation - \$13M FY03 – FY06**
- **DOE- funded peer-reviewed, cost-shared research program to develop and demonstrate innovative technologies for removal and disposal of arsenic from drinking water**
- **Partner Roles**
 - Bench-Scale Studies (AwwaRF)
 - Demonstration Studies (Sandia)
 - Economic Analysis/Outreach (WERC)
- **Focus on small systems**
 - 40% of resources directed to rural and Native American utility needs
 - Minimize costs - capital, operating, maintenance
 - Minimize residual quantities & disposal costs





Other Sandia Pilot Test Team Members

**William Holub Jr., Jerome Wright, Justin Marbury,
Emily Wright, Michelle Shedd, Carolyn Kirby, Paul
McConnell, Linnah Neidel, Nik Rael, Andres
Sanchez, David Stromberg, Tom Hinkebein,
Frederick Partey (NMT)**



Overall Objective



Full scale treatment
12-24 months

Reduce time and costs required to determine the most effective adsorptive treatment technology for small systems for a variety of water qualities.



Pilot scale
6-12 months



**RSSCT &
isotherm**
Days-weeks




Focus of Talk

- Compare different methods to estimate arsenic loading capacity of 5 different adsorptive media in natural water
 - Pilot-scale test in community water systems
 - Rapid small scale tests (RSSCT) in lab
 - Batch (isotherm) tests in lab
- What is most cost-effective way to predict media performance in small systems?
- Current talk describes status of on-going efforts.
 - Focus on results from first pilot site – Socorro, NM.
- Information available at www.arsenicpartners.org
 - Follow link to Pilot studies results

Pilot Test in Socorro, New Mexico

Socorro



Pilot Test: Socorro, NM

- 100% groundwater source for drinking water
- 2 warm springs (90°F) provide 500 gpm, 35 – 55 ppb As(V) by gravity flow.
- Formerly site of tap for bottled water company;
- Optimal F for oral health
- Phase 1: Feb-Oct 2005
 - Tested
 - Fe oxides: AD33, ARM200
 - Resin - AsX^{np}
 - Ti-oxide - Metsorb
 - Zr-oxide - Isolux
 - EBCT study of AD33
 - 3,4,5 min



New Mexico Pilot Sites – Water Quality

Site	Total As/As(III)	V (ppb)	SO ₄ (ppm)	Fe (ppm)	pH
Socorro	45 ppb / 0 ppb	11	29	0.05	8.0
Anthony	20 ppb / 18 ppb	2	180	0.15	7.7
Rio Rancho	19 ppb / < 1 ppb	15	100	<0.10	7.7
Jemez Pueblo	20 ppb / 19 ppb	<1	24	1.2	7.5

Site	Cond. (μS/cm)	TOC (ppm)	Ca Hard (ppm CaCO ₃)	Alkalinity (ppm CaCO ₃)	SiO ₂ (ppm)
Socorro	360	0.5	44	120	25
Anthony	1380	0.8	66	180	37
Rio Rancho	630	ND	62.5	184	22
Jemez Pueblo	770	2.0	155	290	50










Chemical Compositions of Media


Media	Constituents (XRD)	Dominant Elements (EDS)
Isolux 302M	Amorphous zirconium oxide/hydroxide	Zr, O
Metsorb	Crystalline TiO_2 (<i>Anatase</i>)	Ti, O
ARM200	Amorphous Iron oxide/hydroxide (or very poorly crystalline <i>Hematite</i>)	Fe, O
ArsenX ^{np}	Amorphous iron oxide/hydroxide Resin impregnation	Fe, O, C
AD33	Iron oxide/hydroxide (<i>Goethite</i>)	Fe, O

SEM Photos of Adsorption Media



Socorro Pilot Phase I and IIa Events


S4 = ARM200 (FeOx); S5 = AsXnp (resin); S6 = Metsorb (TiOx);
S9 = AD33 (FeOx)




Not a linear scale!

Media Performance Socorro, NM

S4 = ARM200 (FeOx); S5 = AsXnp (resin); S6 = Metsorb (TiOx);
S7 = Isolux (ZrOx); S9 = AD33 (FeOx); influent BV= S6 (proxy)



Calculation of Column Arsenic Loading Capacity








Media Performance in Socorro, NM

Parameter	ARM200 (FeOx)	Metsorb (TiOx)	*ArsenX ^{np} (Resin)	Isolux (ZrOx)	AD33 (FeOx)
BV to 10 ppb	8,600	13,000	27,000	32,000	43,000
Capacity at 10 ppb, mg/g	0.60	0.70	1.38	1.67	3.56
Capacity at 35K BV, mg/g	1.17	1.39	1.75	1.67	3.01
Depletion - C/Co at 35K BV	0.88	0.60	0.35	0.38	0.15
BV at C/Co = 0.8	33,000	87,000	53,000	63,000	>270,000
Capacity at C/Co = 0.8	1.15	2.26	2.10	2.23	> 4.5

*ArsenX^{np} batch was defective


Pore Water Analyses show homogeneous flow



**1 month pH
adjusted influent**

After 4 months pH - adjusted influent

Spent Core Analyses – AD33 (4 min EBCT)



Arsenic leached from 1 g samples taken every 1.5 inches.

Sorption equilibria:

$$K_d^{\text{top}} = 7604/0.045 = 152080 \text{ ml/g}$$

$$K_d^{\text{bot}} = 1917/0.005 = 383400 \text{ ml/g}$$

Total arsenic content

- Assume As loading constant for 1.5" thick disks.

- Sum media mass and As content to obtain average concentration and capacity of column.

As capacity = 5.08 mg As/g media.

As Capacity from mass balance on pilot effluent/influent

> 4.48 mg/g As mg /g media

Agreement within 10%!!



Laboratory Studies

Objective: Compare predictions of media performance obtained from different kinds of tests to results of pilot test.

- **Materials characterization**

- Pre-test and post studies, temperature-ageing studies
- XRD, Surface area (BET), pore size distribution
- Particle morphology and surface chemistry
- Attrition loss
- Post-mortem pore fluids and solids

- **Batch sorption studies**


- Kinetic (15°C and 40°C)
- Isotherms (linear, Freundlich, Langmuir)

- **Rapid small scale column tests (RSSCTS)**

- Proportional Diffusivity (PD) and Constant Diffusivity (CD)

XRD Studies Used to Evaluate Potential Changes in Mineralogy of Media

ARM200



Ageing: Possible silica polymorphs : opal, quartz, beta quartz

Recrystallization may impact performance.



Pore Characteristics

Media	BET Surface Area (m ² /g)	Average Pore Diameter (Å)	Total Pore Volume (TPV) (cm ³ /g)
Isolux 302M	499	23	0.29
Metsorb	211	64	0.34
ARM200	262	99	0.65
ArsenX ^{np}	120	174	0.05
AD33	147	245	0.90


Media have different pore size distributions.



Batch Sorption Studies

- **Solution:solid (ml/g)** **750-800**
- **Equilibration time** **24 hrs (per kinetic studies)**
- **Particle size** **325 – 400 mesh**
- **pH (initial)** **7.7 – 8.1**
- **pH(final)** **7.5 – 7.7**
- **Arsenic analysis** **ICP-MS**
- **Isotherm fits** **Langmuir and Freundlich**
- **Final As** **3 - 80 ppb**

Isotherm Studies



$$n_F=0.3131, K_F=2.1E4$$

● Column data



RSSCT Design and Practice

- **Crush media to much smaller sizes**
 - **Smaller media, faster kinetics**
- **Reduce column diameter**
 - **Smaller column, higher HLR**
- **Apply a higher hydraulic loading rate**
 - **Faster HLR, smaller boundary layer, faster kinetics**
 - **Reduces external mass transfer resistance**
- **Shorter EBCT (Empty Bed Contact Time)**
- **Dimensional analysis and similitude**
 - **Attention to dimensionless parameters**
- **Two RSSCT designs:**
 - **Proportional Diffusivity: duration 2-5 weeks**
 - **Constant Diffusivity: duration 2-10 days**





Theoretical Scaling Relationships

Diffusivity factor (x) Relationship between D_s and particle size	$\frac{D_{s,RSSCT}}{D_{s,pilot}} = \left[\frac{R_{RSSCT}}{R_{pilot}} \right]^x$
Non-constant D_s (x = ?)	$\frac{EBCT_{RSSCT}}{EBCT_{pilot}} = \left[\frac{R_{RSSCT}}{R_{pilot}} \right]^{2-x}$
Proportional D_s (x = 1)	$\frac{EBCT_{RSSCT}}{EBCT_{pilot}} = \left[\frac{R_{RSSCT}}{R_{pilot}} \right]$
Constant D_s (x = 0)	$\frac{EBCT_{RSSCT}}{EBCT_{pilot}} = \left[\frac{R_{RSSCT}}{R_{pilot}} \right]^2$




Socorro PD RSSCTs




Comparison of Breakthrough for AD-33


AD33 - 2 min EBCT



AD33- 4 min EBCT




AD33 - 5 min EBCT



**PD
results
closer to
Pilot.**


10 ppb Breakthrough and Capacity



Capacity is better estimator than BVs.

10 ppb Breakthrough and Capacity

Metsorb Capacity







Estimates of Arsenic Sorption Capacity from Different Tests

	AD33	ARM200	Metsorb
BV to 10ppb (pilot)	43,000	8,600	13,000
<u>As</u> at 10ppb (pilot)	3.56 mg/g	0.6 mg/g	0.7 mg/g
BV to 10ppb (RSSCT)	43,000 (PD)	6000 (CD)	12,800 (PD)
<u>As</u> at 10 ppb (RSSCT)	3.39 mg/g (PD)	0.42 mg/g (CD)	0.69 mg/g (PD)
<u>As</u> at 10 ppb (Freundlich)	5.0 mg/g	3.6 mg/g	1.2 mg/g


BV = bed volumes, PD = proportional diffusivity, CD = constant diffusivity

As = capacity calculated from loading or batch test

Shape of Mass Transfer Zone Determines Capacity



Later breakthrough



Earlier breakthrough

LES = Length of Equilibrium Bed

LUB = Length of Unused Bed




Bed Efficiencies of Sorbent Media Columns

Bed Efficiency = 10 ppb pilot capacity/45 ppb batch capacity x 100%


	AD33 (4 min)	ARM200	AsX^{np}	Metsorb
<u>As</u> at 10ppb (pilot)	3.6 mg/g	0.6 mg/g	1.4 mg/g	0.7 mg/g
<u>As</u> at 10 ppb (Freundlich)	5.0 mg/g	3.6 mg/g	4.6 mg/g	1.3 mg/g
<u>As</u> at 45 ppb (Freundlich)	7.7 mg/g	8.0 mg/g	10 mg/g	4.5 mg/g
Bed Efficiency %	47	8	14	16

Pore Water Analyses Profiles are consistent with calculated bed efficiencies.




Efficiencies: 8%

Larger Length of Unused Bed (LUB)



16%



Efficiency: 47%

Smaller LUB



Summary

- **Pilot Test Demonstration Objectives**

- Generate cost/performance data for innovative technologies for small communities

- **Objectives of this study**

- Determine efficient method to predict media performance

- **Pilot Study Results for Socorro, NM**

- AD-33 GFO media and Isolux ZrO_2 media show best performance
- Capacities calculated from solution mass balance are lower than capacities from other methods

- **RSSCT and Batch Tests**

- RSSCT provide inconsistent results – need for additional replicate tests
- Batch Tests – Freundlich isotherm fits data
- Good agreement between arsenic capacity of media calculated from analysis of spent media (AD33) and batch tests



Unanswered Questions

- **Can a comprehensive lab-based study of media properties replace the need to carry out site-specific field tests for predictions of media performance?**
 - **Relate pore structure to performance?**
 - **Effect of major ions on performance?**
 - **Effect of hydraulic properties on performance?**
 - **Backwashing may create fines and decrease BVs**
- **Comparison to full-scale treatment plant results?**

Other Studies in New Mexico

Jemez
Pueblo

Rio Rancho

Anthony



**Site of full-scale
EPA study:**

allows comparison of
capacity at 4 scales





- **Thank you for staying**

Questions?

- **Happy Trails!**