



ADVANCED REACTOR SAFEGUARDS

A Novel Nuclear Material Control Technique for Pebble Fueled Reactors (PFR): FY22 Mid-year Review

PRESENTED BY

Claudio Gariazzo, Argonne National Laboratory
Sunil Chirayath, Texas A&M University

4 May 2022

APT #175026


Argonne
NATIONAL LABORATORY

U.S. DEPARTMENT OF
ENERGY

Introduction





- A PFR uses several hundred-thousands of fuel pebbles
 - 5 to 10 g of LEU per pebble
- Different batches of pebbles in the same PFR, based on
 - ^{235}U enrichment
 - Date of introduction
 - Neutron moderating (graphite)
 - Neutron absorbing
- Pebbles continuously flow through the reactor, discharged at the PFR vessel bottom, and re-inserted at the PFR vessel top depending on the re-fueling scheme.



Motivation for Study


- Nuclear Material Accountancy and Control (NMAC) are essential for implementing safeguards
- Item accounting of pebbles is unfeasible
 - $\sim 10^5$ pebbles in reactor vessel
- Burnup measurements (gamma spectroscopy) are part of process
 - Uncertainty of using burnup as distinguishing characteristic
 - Similar burnup achieved by different paths
 - Complementary research
- Vendor stated interest in identifying pebble types:
 - “A capability to distinguish pebbles by batch is needed”



Objective

- Develop a unique technique for identifying pebble type for nuclear material accountancy and process control

Extrinsic, non-radiological features to be used for accounting and control




Pebble Sorting Assembly Prototype

Methodology



- Embedded inert identifiable microspheres in the outer graphite layer (5 mm thick) of the pebble
- Imaged (ultrasound scan) outer graphite layer for pebble classification
- Batch accounting – categorized by sets of item specifications
 - Enrichments
 - Pebble purpose (fuel, absorber, moderator)
 - Date of core introduction





Surrogate pebble with YSZ microspheres in graphite mold

Operational Impact



- Microsphere specifications:
 - Neutronically inert
 - Maximum thermal conductivity
 - Minimal thermal expansion
 - 1-mm diameter
 - Initially yttria-stabilized zirconia (YSZ), later alumina (Al_2O_3)
- Pitch (interstitial spacing) of microspheres serve as unique pebble-type identifier
 - Averaged



Pebble Preparation



| Sample Number | Qualitative Description |
|---------------|---|
| Sample #1 | Spherical, 6cm diameter, no YSZ microspheres |
| Sample #2 | Spherical, 6cm diameter, approximately 100 YSZ microspheres in the pebble |
| Sample #3 | Spherical, 6cm diameter, approximately 200 YSZ microspheres in the pebble |



Ultrasound Experimental Setup



- Experimental setup with pebble sorting system




Image Acquisition and
Analyzing System

"Singulizer"

Chute


Ultrasound
Imaging Probe

Carousel


Ultrasound Imaging – Static Scans

x-axis: Normalized voxel intensity (range 0.5 to 1.0)


y-axis: Percent of voxels for a given intensity




Sample #1 with no microspheres



Sample #2 with 100 microspheres





Sample #3 with 200 microspheres




| Sample | Mean % of Voxels |
|--------|------------------|
| 1 | 3.61 |
| 2 | 5.81 |
| 3 | 6.34 |

Ultrasound Imaging – Static Scans


- Segmented images for pebble samples



Sample #1 with no microspheres



Sample #2 with 100 microspheres




Sample #3 with 200 microspheres

Ultrasound Imaging – Rotating Scans

2D views of Sample #1
(no microspheres)

Histograms of upper half
region from captured
images

Segmented 2D images




Ultrasound Imaging – Rotating Scans

2D views of Sample #2
(100 microspheres)

Histograms of upper half
region from captured
images

Segmented 2D images




Ultrasound Imaging – Rotating Scans

2D views of Sample #3
(200 microspheres)


Histograms of upper half
region from captured
images

Segmented 2D images




Ultrasound Imaging – Rotating Scans


Sample #1



Sample #2



Sample #3



| Sample | Mean % of Voxels |
|--------|------------------|
| 1 | 19.16 |
| 2 | 21.55 |
| 3 | 26.80 |


Microsphere Modification

YSZ Microspheres


6mm spacing



Projection Image



%Points: 11.42




Hist.% (0.5 to 1)


12mm spacing



Projection Image



%Points: 11.28




Hist.% (0.5 to 1)

Alumina Microspheres


6mm spacing



Projection Image



%Points: 20.29




Hist.% (0.5 to 1)


12mm spacing



Projection Image



%Points: 14.51





Hist.% (0.5 to 1)

Pebble Mockup



Projection Image





Recent Development

- Microsphere material changed
 - YSZ → Alumina
- Graphite (moderator) pebbles provided by Kairos
 - 4cm diameter (not 6cm)
 - Extrinsic features: grooves on surface
 - 10 pebbles for testing
- Scanning medium cannot be any liquid or liquid-like substance
 - Scans must be completed dry
 - Option for scanning after pebble discharge for batch accounting: TBD
- Other scanning methods/technologies under consideration

Remaining FY22 Work


- Exploring non-liquid medium for scans
- Engaging with designers and fuel fabricators
- Investigating other imaging technologies
 - Candidate technologies under consideration at TAMU and Argonne



Conclusions



- Laboratory setup deployed with sorting and scanning technology
 - At TAMU by EOY22
- Engagement with industry requires reconsideration of scanning technologies
 - Candidate technologies available





Questions?

A decorative graphic in the bottom left corner consisting of two concentric arcs, one light green and one light orange, and a small black circle at the bottom left, with a horizontal line extending to the right.